
## MVSY-188 series

#### **SOLENOID VALVE**






#### Caution

- Don't continuously energize for over 2 hours.
- The total energizing time of a day is not allowed to exceed the total non-energizing time even if it is intermittent energizing.


### **Specification**

N	lodel	4E1	4E2	4E2 C.P.R			
Bore No.		8A					
Port size		Rc1/4					
No. of port		5					
No. of position		2		3			
Medium		Air					
Operating perssure range		0.15~0.7 MPa		0.2~0.7 MPa			
Proof pressure		1 MPa					
Effective orifice	Body ported	15 r	nm²	16.3/27/12.4 mm <sup>2</sup>			
	Manifold	13 mm <sup>2</sup>		13.5/18.4/11 mm <sup>2</sup>			
Reponse time		23 ms		50 ms			
Ambient temperature		+5~+50°C					
Max. operating frequency		5 Hz					
Voltage		AC110V, 220V (50/60)Hz, DC24/12/6V					
Power consumption		AC=1.6/2.5VA, DC6=1.2W, DC12/24=0.55W					
Available voltage range		±10%					
Insulation class		B class					
Weight		77 g	102 g	106 g			

## Order example of valve




## Order example of manifold



MVDY - 100 - WA2J2


Order example of wire

MODEL



1: 1000mm 2: 2000mm 3: 3000mm

\* Use the same wire with MVDY.





## MVSY-188 Dimensions







### MVSY-188-4E1


























#### MVSY-188-4E2C.P.R


## MVSY-188-4E2C MVSY-188-4E2P MVSY-188-4E2R







## Flow features







#### MVSY-188M-4E1/4E2



( ): Dimension for LJ plug type.





# MVSY-188 Manifold

## SOLENOID VALVE




## MVSY-188-5B\*






No. of stations	Р	L
2	46	66
3	65	85
4	84	104
5	103	123
6	122	142
7	141	161
8	160	180
9	179	199
10	198	218

## MVSY-188M-5M\*





<b>+</b>	
A	4 14 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
В	B 4.9 4 4 7 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4
7 24 19	2×N-Rc1/4

( ): Dimension for **LJ** plug type.

No. of stations (N)	Р	L
2	49	61
3	68	80
4	87	99
5	106	118
6	125	137
7	144	156
8	163	175
9	182	194
10	201	213




# MVSY-188 Mounting bracket & Spacer assembly




## SOLENOID VALVE


## Order example of bracket





## Order example of spacer assembly




### MVSY-188-1A













## MVSY-188-2A











# MVSY-188 Spacer assembly


## **SOLENOID VALVE**



#### for body ported type


## MVSY-188-5BP

Individual SUP spacer assembly




#### MVSY-188-5BR

Individual EXH spacer assembly



## MVSY-188-5BPR


Individual SUP spacer assembly+Individual EXH spacer assembly



## for manifold type


#### MVSY-188M-5MP

Individual SUP spacer assembly



#### MVSY-188M-5MR

Individual EXH spacer assembly



## MVSY-188M-5MPR

Individual SUP spacer assembly+ Individual EXH spacer assembly

