WEIKAV维咖



NUT75 快速上手指南 QUICK START GUIDE

NO：202604001HFD

Mode Pairing Settings

Bluetooth Mode:

Press Q/W/E briefly to switch Bluetooth channels 1/2/3; blue light flashes slowly.
Press and hold FN+Q/W/E for 3 seconds; blue light flashes quickly to enter pairing mode.
When connected successfully, the key lights follow the lighting effects.
Bluetooth: NUT75BT1, NUT75BT2, NUT75BT3

2.4G Mode:

Short press FN+R to switch to 2.4G mode; green light flashes slowly.
Press and hold FN+R for 3 seconds; green light flashes quickly to enter pairing mode.
Insert the 2.4G receiver. When connected successfully, the key lights follow the lighting effects.
2.4G：NUT75 2.4G

Wired Mode:

Short press FN+T to switch to wired mode; white light flashes slowly. Connect the data cable.
Wired: NUT75

Lighting Effects Function

Combination Keys	Lighting Effects
FN+|	Main Backlight Mode Switch
FN+Backspace	Side Light Effect Switch
FN+Del	Switch Indicator Color Next to Knob: 7 single colors
FN+Home	Switch Indicator Mode Next to Knob: Always On, Breathing, Off
FN+ ↑ / ↓	Main Backlight Brightness +/-
FN+←/→	Main Backlight Speed +/-

Charging Indicator

- Low Battery: Left Ctrl light flashes red slowly.
- Charging: Left Ctrl light stays red.
- Full Charged: Left Ctrl light stays green.
- Turn On/Off Left Ctrl Light: FN + Left Ctrl (on by default).
- Sleep Mode: First-level sleep after 5 minutes, deep sleep after 30 minutes. No key loss in 2.4G mode.

FN Combination Key Functions

Combination Keys	WIN Function	MAC Function
FN+F1	My Computer	Screen Brightness-
FN+F2	Homepage	Screen Brightness+
FN+F3	Email	-
FN+F4	-	-
FN+F5	Player	-
FN+F6	Stop	-
FN+F7	Previous	Previous
FN+F8	Play/Pause	Play/Pause
FN+F9	Next	Next
FN+F10	Mute	Mute
FN+11	Volume-	Volume-
FN+12	Volume+	Volume+
FN+ESC (Long press for 3 s)	Factory Reset	
FN+WIN	Lock WIN key (white light stays on), not available on MAC	
FN+M (Long press for 3 s)	WIN system (blue light flashes 3 times); MAC system (white light flashes 3 times)	
FN+D (Long press for 3 s)	Red light flashing: enter ultra-low latency mode; White light flashing: enter normal latency mode (default)	
FN+Space	Check battery level: 1~0 indicates current battery level (only in wireless mode, without cable connected)	
FN + Right Shift	Switch to low power mode.:Once enabled, all keyboard area lights and rear side lights will be turned off; only the Caps Lock indicator, triple-mode switching indicator, and Win key on/off indicator remain lit.	

Product Specifications

- Product Dimensions: L 314.8 × W 136.8 × Front H 19 × Rear H 37.2
- Product Weight: Kit ≈ 1575±10g, Assembled ≈ 1830±10g
- Connection: Wired / 2.4G / Bluetooth
- Compatible Systems: Windows 8 and above, macOS
- Power Consumption:
  1. Powered by Lithium Battery:
  - Factory default lighting effect & maximum brightness: 180mA±10%
  - Primary keys brightest white + side strip flowing light: 160mA±10%
  - Full white backlight of the whole device: 150mA±10%
  - All backlights off: 18mA±10% - Sleep current: Less than 0.5mA
  - Low Power Mode: Total current approx. 2mA
  2. Powered by USB 5V:- Battery charging current: 500mA±10%

Warranty Service Card

Thank you for purchasing and using our Weikai products! To protect your rights and interests, this product is provided with Three Guarantees after-sales service in accordance with the national **Regulations on the Repair, Replacement and Return of Microcomputer Commodities**. The product warranty terms are as follows:

1. Please note: This guide serves as the warranty certificate. It must be stamped by the seller to be valid and should be properly kept.
For purchases made online (e-commerce platforms), no stamp is required; the electronic purchase record from the platform shall prevail.
2. Warranty Period: 12-month functional warranty starting from the date of purchase (excluding man-made damage).
3. Service Content:
1) Within 7 days from the date of purchase, products with undamaged packaging that do not affect resale can be returned or exchanged.
2) Within 15 days from the date of purchase, products with undamaged packaging that do not affect resale can be replaced with products of equal value.
3) Within the warranty period, under normal use and maintenance, one-year warranty service is provided for failures caused by the product's components.
4. The following situations are **NOT** covered by the Three Guarantees service:
1) The product has exceeded the valid service or free repair period.
2) Damage caused by use, maintenance or storage in violation of the product instructions.
3) Damage caused by disassembly by non-authorized repair personnel.
4) No valid warranty certificate or valid invoice (except those that can prove the product is within the validity period).
5) Unauthorized alteration of the warranty certificate.
6) The sticker on the bottom of the product has been removed by the consumer.
7) The anti-counterfeit label is lost, damaged or unidentifiable.
8) The product model or serial number on the warranty certificate does not match the actual product.
9) Product failure or damage caused by force majeure (such as earthquake, fire, flood, etc.).
10) Damage caused by using pirated software or virus infection during use.
11) Product failure caused by human factors (e.g. improper operation, transport damage, collision, incorrect voltage input, etc.).
12) Other failures or damages not caused by product design, technology, manufacturing or quality issues.

CHARGING INSTRUCTIONS

1. IT IS RECOMMENDED TO CHARGE THE KEYBOARD ONLY USING THE USB PORT ON THE COMPUTER;
2. DO NOT CHARGE THE KEYBOARD WITH A QUICK CHARGE PHONE CHARGER;
3. DO NOT USE A SUBSTANDARD, NON-STANDARD POWER ADAPTER TO CHARGE THE KEYBOARD;
4. DO NOT USE AN OVERVOLTAGE AND OVERCURRENT POWER ADAPTER TO CHARGE THE KEYBOARD;
5. KEEP AWAY FROM HIGH TEMPERATURE DEVICES WHILE CHARGING;
6. TURN OFF THE POWER SWITCH WHEN NOT IN USE FOR A LONG TIME;

FAILURE AND DAMAGE OF COMMERCIAL BATTERIES AND CIRCUIT BOARDS CAUSED BY THE USE OF FAST CHARGING HEADS ARE NOT COVERED BY THE WARRANTY

WEIKAV维咖



NUT75 快速上手指南
QUICK START GUIDE

NO：202604001HFD

模式配对设置

蓝牙模式:
短按Q/W/E切换蓝牙1/2/3通道，蓝光慢闪；长按FN+Q/W/E 3秒，蓝灯快闪，进入配对，连接成功，键灯跟随灯效；
蓝牙设备名称：NUT75 BT1，NUT75 BT2，NUT75 BT3

2.4G模式:
短按FN+R切换2.4模式，绿灯慢闪；长按FN+R 3秒，绿灯快闪进入配对，接入2.4G接收器，连接成功，键灯跟随灯效；
2.4G设备名称：NUT75 2.4G

有线模式:
短按FN+T切换有线模式，白灯慢闪，接入数据线
有线设备名称:NUT75

灯效功能

组合按键	灯效
FN+|	主背光模式切换
FN+Backspace	侧灯灯效切换
FN+Del	切换旋钮旁指示灯颜色：七单色
FN+Home	切换旋钮旁指示灯模式：常亮、呼吸、熄灭
FN+↑/↓	主背光亮度+/-
FN+←/→	主背光速度+/-

充电指示灯

- 低电：Ctrl_L红色灯慢闪烁。
- 充电：Ctrl_L红色灯常亮。
- 满电：Ctrl_L绿色灯常亮。
- 关闭/开启Ctrl_L灯：FN+Ctrl_L（默认开启）
- 休眠：一级休眠5分钟，深度休眠30分钟

FN组合按键功能

组合按键	WIN功能	MAC功能
FN+F1	我的电脑	屏幕亮度-
FN+F2	主页	屏幕亮度+
FN+F3	邮件	--
FN+F4	--	--
FN+F5	播放器	--
FN+F6	停止	--
FN+F7	上一曲	上一曲
FN+F8	播放/暂停	播放/暂停
FN+F9	下一曲	下一曲
FN+F10	静音	静音
FN+11	音量-	音量-
FN+12	音量+	音量+
FN+ESC（长按3秒）	恢复出厂设置	
FN+WIN	锁WIN键（白光常亮），MAC无	
FN+M（长按3秒）	WIN系统（蓝光闪3次）；MAC系统（白光闪3次）	
FN+D（长按3秒）	红光闪烁，进入最低延时；白光闪烁，进入常规延时（默认）	
FN+Space	查询电量，1-0显示当前电量，（仅无线模式下，不插线）	
FN+右shift	切换为低功耗模式（开启后键区灯与背部侧灯全部关闭，仅保留大小写指示灯，三模切换指示灯，win键开启/关闭指示灯）	

产品参数

- 产品尺寸：长314.8*宽136.8*前高19*后高37.2
- 产品重量：套件≈1575±10g 成品≈1830±10g
- 适配系统：WIN7/10/11、MAC
- 功耗：1.锂电池供电：
  出厂默认灯效和最高亮度：180mA±10%　主键区白光最亮+侧灯流光：160mA±10%
  整机全白光功耗：150mA±10%　关闭全部背光：18mA±10%
  休眠电流：小于0.5mA　低功耗模式：整机电流约2mA
  2.USB 5V供电
  电池充电电流：500mA±10%

保修服务卡 Warranty Service Card

感谢您购买并使用维咖产品！为了保护您的权益，本产品在国家规定的《侨过计算机商品修理更换退货责任规定》，为您提供三包售后服务，
产品保修说明如下：
一、请注意：此指南为质保凭证，必须有销售商的加盖印章为有效并妥善保存；
线上(电商平台)购买无需加盖印章，以平台的电子购买记录为准。
二、保修期：自购买之日起功能质保12个月（人为损坏除外）
三、服务内容：
1.自购买之日起七日内，包装未损坏，不影响再次销售的产品，可进行退换。
2.自购买之日起十五日内，包装未损坏，不影响再次销售的产品，可更换同等价值产品。
3.自购买之日 起，在正常使用和维护下，由本机元器件引发之故障，提供一年保修服务。
四、下列范围不属于三包服务范围：
1.已超出有效服务或免费维修期限的。
2.未按产品使用说明的要求使用、维护、保管而造成损坏的。
3.非承担三包维修者拆动造成损坏的。
4.无有效三包凭证及有效发票的(能证明该商品有效期限内的除外)。
5.擅自涂改三包凭证的。
6.消费者自行拆除产品底部贴纸之产品。
7.消费者遗失产品防伪卷标贴纸或产品防伪卷标贴纸破损难辨真伪商品。
8.三包凭证上的产品型号或编号与商品实物不相符的。
9.因不可抗力(如地震、火灾、水灾等)原因造成产品不良或损坏的。
10.使用盗版软件造成损坏的,或者使用过程中感染病毒造成产品损坏的。
11.人为因素造成产品不良(如:错误操作、搬运损坏、磕碰、输入不合适电压等)
12.其他非产品设计、技术、制造、质量等问题而导致的不良或损坏。
13.警告！因电池的特殊性，切记不可用尖锐物或硬物等对电池进行戳碰和拆解，以免对人体造成伤害。

产品合格证

充电说明

1.建议仅使用电脑USB接口对键盘进行充电；
2.请勿使用快充手机充电器对键盘充电；
3.请勿使用劣质非标电源适配器对键盘进行充电；
4.请勿使用过压过流电源适配器对键盘进行充电；
5.充电时请远离高温设备；
6.长时间不使用时请关闭电源开关；

因使用快充等充电头引起商品电池及电路板故障与损坏，则不在保修范围内。