



USER INSTRUCTION MANUAL



ZEROSCALE
WATER TREATMENT PLANT
ZEROSCALE WATER

40 NB MULTIPORT VALVE

Uchch Guvatta Aur Dakshata Ka Nishan



Front View



Rear / Position View

Please Read This Manual Carefully Before Installation & Operation

Specifications

Connection Size:	40 NB (1.5")
Body Material:	High Durability Composite (UV Resistant)
Operation:	Manual, 6-Position Rotary Handle
Suitable For:	Sand Filters & Carbon (Activated Charcoal) Filters
Orientation:	Left to Left (L → L)



Valve Positions & Operation Guide

■ IMPORTANT: NEVER SHIFT THE HANDLE WHILE THE PUMP IS RUNNING.

Always switch OFF the pump before changing the valve position to prevent damage to the valve mechanism.

1 FILTER

Normal operation. Water flows down through the filter media and out through the outlet for regular filtration.

2 BACKWASH

Reverses water flow to lift and flush trapped dirt from the filter media, cleaning the bed bottom-up.

3 RINSE

Resettles the filter media and flushes remaining loose particles to waste after backwashing.

4 WASTE

Drains water directly to waste, bypassing the filter — used for fast drain-down or startup flushing.

5 RECIRCULATE

Circulates water through the system without filtering — used for chemical mixing or testing.

6 NOT IN USE

Position reserved / closed — no flow through the valve in this setting.



Standard Operating Sequence (Backwash Cycle)

1. Switch OFF the pump.
2. Turn handle to BACKWASH position — run for 5–10 minutes until waste water runs clear.
3. Switch OFF the pump. Turn handle to RINSE position.
4. Switch ON the pump — run for 1–2 minutes to resettle the media.
5. Switch OFF the pump. Turn handle back to FILTER position for normal operation.
6. Switch ON the pump to resume filtration.



Installation, Maintenance & Safety

Installation Guidelines

- ✓ Mount the valve securely on top of the filter tank using the correct thread/gasket, ensuring the 'TOP' marking faces upward.
- ✓ Confirm the flow orientation is Left → Left (L → L) as marked on the valve body before final tightening.
- ✓ Use PTFE tape or approved thread sealant on all threaded connections to prevent leakage.
- ✓ Ensure inlet and outlet pipework is properly supported — do not let pipe weight rest on the valve body.
- ✓ Do not over-tighten fittings; hand-tight plus a quarter turn with a wrench is usually sufficient for composite bodies.

Maintenance Tips

- ✓ Perform a Backwash + Rinse cycle regularly (frequency depends on water quality and usage) to maintain filter efficiency.
- ✓ Inspect the handle and position markings periodically to ensure the indicator aligns correctly with the actual flow path.
- ✓ Check all joints for leaks every few months and re-tighten or reseal as needed.
- ✓ Keep the valve body clean and away from direct prolonged sunlight where possible to maximize UV-resistant material life.
- ✓ Do not use harsh chemical cleaners on the valve body — clean with a soft cloth and mild soap water only.

Safety Precautions

- ✓ NEVER shift the handle position while the pump is running — always switch OFF the pump first.
- ✓ Do not exceed the rated working pressure and temperature specified for the valve and filter system.
- ✓ Keep the valve assembly away from open flame or excessive heat sources.
- ✓ In case of leakage or unusual noise, switch off the system immediately and contact your dealer or Aqua Filtration System support.
- ✓ This product should be installed and serviced by a qualified technician for best results.

Need Help or Spares?

Contact our support team using the details below, or order genuine spares directly through WTPeSTORE™ at www.wtpestore.co.in