

z.ebe

Attributes

```
ebe name=z
nodes: p n
rparms:
+ r=1.0
+ c=1.0
outparms_ac: i_ac v_ac S
```

Description

z.ebe is an impedance connected between nodes p and n and is available only for ac simulation. The phasor branch current, branch voltage, and complex power are made available as output variables.