

z_polar.ebe

Attributes

```
ebe name=z
nodes: p n
rparms:
+ mag=1
+ theta_deg=0
outparms_ac: i_ac v_ac S
```

Description

`z_polar.ebe` is an impedance connected between nodes `p` and `n` and is available only for ac simulation. It is specified in polar form. The phasor branch current, branch voltage, and complex power are made available as output variables.