

tc1@tc1: ~

File Edit Tabs Help

Raspberry Pi 3 Model B Rev 1.2, 1GB

Raspberry Pi Software Configuration Tool (raspi-config)

- 1 System Options Configure system settings
- 2 Display Options Configure display settings
- 3 Interface Options Configure connections to peripherals**
- 4 Performance Options Configure performance settings
- 5 Localisation Options Configure language and regional settings
- 6 Advanced Options Configure advanced settings
- 8 Update Update this tool to the latest version
- 9 About raspi-config Information about this configuration tool

<Select>

<Finish>

tc1@tc1: ~

File Edit Tabs Help

Raspberry Pi Software Configuration Tool (raspi-config)

- I1 SSH Enable/disable remote command line access using SSH
- I2 RPi Connect Enable/disable Raspberry Pi Connect
- I3 VNC Enable/disable graphical remote desktop access
- I4 SPI Enable/disable automatic loading of SPI kernel module
- I5 I2C Enable/disable automatic loading of I2C kernel module**
- I6 Serial Port Enable/disable shell messages on the serial connection
- I7 1-Wire Enable/disable one-wire interface

<Select>

<Back>

tc1@tc1: ~

File Edit Tabs Help

Would you like the ARM I2C interface to be enabled?

<Yes>

<No>

tc1@tc1: ~

File Edit Tabs Help

The ARM I2C interface is enabled

<Ok>

tc1@tc1: ~

File Edit Tabs Help

Raspberry Pi 3 Model B Rev 1.2, 1GB

Raspberry Pi Software Configuration Tool (raspi-config)

- | | |
|------------------------|---|
| 1 System Options | Configure system settings |
| 2 Display Options | Configure display settings |
| 3 Interface Options | Configure connections to peripherals |
| 4 Performance Options | Configure performance settings |
| 5 Localisation Options | Configure language and regional settings |
| 6 Advanced Options | Configure advanced settings |
| 8 Update | Update this tool to the latest version |
| 9 About raspi-config | Information about this configuration tool |

<Select>

<Finish>