


VC-TR70 Quick Installation Guide

www.MyLumens.com

Lumens[®]

1. I/O interface




2. Precautions for Installation

2.1 Use the provided DC 12V power cord or a PoE router or hub to supply power via a network cable.

*Camera supports PoE (IEEE802.3bt)


- Optimal tracking distance : 8~15m
- Optimal installation height : 2.5m




*For best tracking results, avoid placing images of people on posters or screens behind the subject.

3. Installation on the ceiling

4.1 Fix the metal plate A on the camera base with 4 M3 silver screws.



Metal Plate A



4.2 Lock the metal plate B on the ceiling


***Caution:**

- (1) Please use a hanger that has obtained UL security approval.
- (2) Please do not block the cable hole.


4.3 Attach metal plate A to metal plate B

- Raise the camera and metal plate A to the ceiling and then move it to the right to snap it on to metal plate B.
- Finally, secure with 2 M3 silver screws and 1 M3 black screw.

*Press the [Mirror] button on the remote control to flip the image.



Metal Plate B



VC-TR70 Quick Installation Guide

www.MyLumens.com

Lumens[®]

4. View Camera Image

■ HDMI / 3G-SDI Image Output

Connect an HDMI or SDI cable to output camera video.

*VC-TR70 default resolution 1080p 59.94

■ USB Image Output

Connect to computer with a USB cable to view live image. Camera can be used as a webcam with video conferencing applications such as Skype, Zoom, Microsoft Teams and others.

■ IP Image Output

Connect camera to network router using Cat5e to view live video and control the camera via a web interface.

- Check Camera IP Address

Default is DHCP is enabled. Use remote control to check IP address by going to [Menu]> [Ethernet]> [IP Address].

*If connecting the camera directly to a computer, the default IP of camera is 192.168.100.100.

- Open a web browser, and enter the IP address in the address bar.
- Enter the account and password to log in.



- **Account: admin**
- **Password: 9999**


5. Start Tracking

Use the remote control to start the auto-tracking/ auto-framing function.

* Power / Standby LED flashes green when the tracking function of the camera is activated.

* Choose either Auto Tracking or Auto Framing function.

■ Auto Tracking




Items	Button	Function
1	On/ Off	Enable / Disable Auto Tracking
2	Full	Camera frames presenter' s full body
3	Upper	Camera frames presenter' s torso
4	Switch	Switch target to a different presenter

■ Auto Framing

With Auto-Framing technology, the camera will automatically detect the position of the human body and adjust the person to the center of the screen according to the number of people in the meeting environment to present the best image and enhance the efficiency of the meeting.



6. RS-232/ RS-422 Pin Definition



Pin No.	Function	Function	RS-232 / RS-422
1	RX-	TX-	RS-422
2	RX+	TX+	RS-422
3	GND		RS-232 / RS-422
4	TX	RX	RS-232
5	RX	TX	RS-232
6	DTR	DSR	RS-232
7	TX-	RX-	RS-422
8	TX+	RX+	RS-422

※For questions about installation, please scan the QR Code.

A support person will be assigned to assist you.



Get Help ?