altairsim — CP/NET 1.2 on two Altairs

2026-10-23 · 1cc5be2

CP/NET is the network of Digital Research. It lets a CP/M machine (the requester) use the disks and the printer of an MP/M II machine (the server). This folder has an Altair server and an Altair requester, connected by a serial line on port B of each **88-2SIO**.

File	What it is
`server.toml`	The server: MP/M II 2.1 on an Altair with **88-DCDD** floppies and an **88-VI/RTC**.
`server.dsk`	The server disk. The DBL PROM boots it into MP/M II with the CP/NET server.
`server-ss1.toml`	The server with a CompuPro **System Support 1** in place of the 88-VI/RTC.
`server-ss1.dsk`	The server disk of `server-ss1.toml`.
`requester.toml`	The requester: CP/M 2.2 on an Altair with 88-DCDD floppies.
`requester.dsk`	The requester disk: CP/M 2.2 and the CP/NET requester files.
`NETWRKIF.ASM`	The network interface of the server, for RMAC.
`SNIOS.ASM`	The network I/O system of the requester, for RMAC.
`srvbuild.toml`	The CP/M 2.2 machine with two drives that builds the server disk.
`reqbuild.toml`	The CP/M 2.2 machine with two drives that builds the requester disk.
`CPM22.DSK`	A CP/M 2.2 disk that boots, with the tools for the builds.
`SRVBUILD.DSK`	The sources and the DRI files that the server build needs.
`REQBUILD.DSK`	`SNIOS.ASM` and the requester files of CP/NET.
`MPMII_1.DSK`	The files of DRI MP/M II disk 1. A copy of it becomes the new server disk.
`RESXIOS.ASM`, `LDRBIOS.ASM`, `BOOT.ASM`, `AFORMAT.ASM`	The XIOS, the loader BIOS, the cold start loader and the disk format program of MP/M II.
`SS1XIOS.ASM`	The XIOS of `server-ss1.toml`.
`make-cpnet-disks.py`	The script that does the steps of "Build the server disk" and "Build the requester disk" in the simulator. It built `server.dsk`, `server-ss1.dsk` and `requester.dsk`.
`CPNET.DSK`	The 29 files of the DRI CP/NET 1.2 disk, on an 88-DCDD disk.
`CPNET80.IMD`	The DRI CP/NET 1.2 distribution disk, as an ImageDisk file.
`CPNET80.JPG`	A photo of the disk and its label.
`dri-cpnet.md`	Notes on the DRI *CP/NET Network Operating System Reference Manual*.

The MP/M II of the server is the one of the `mpm2` example, with a network line in place of console 1. This folder has its own copies of the MP/M II files, so that it needs no other folder.

Run it

The two machines run in two windows. Start the server first.

1. Start the server from this folder:

   ```
   cd examples/cpnet
   altairsim server.toml
   ```

2. Wait for `0A>`. The server boots into MP/M II with no CP/M first.

3. In a second window, start the requester from the same folder:

   ```
   cd examples/cpnet
   altairsim requester.toml
   ```

4. At the `A>` prompt, type `CPNETLDR`. It loads SNIOS and NDOS, and prints `<Warm Boot>`.

5. Type `LOGIN`.

6. Type `NETWORK B:=A:[0]`. Drive B: of the requester is now drive A: of the server.

The requester calls the server one time, when the requester starts. If the server is not running, port B stays unconnected. To call again, type this command at the monitor of the requester:

```
CONNECT sio0:b socket:localhost:8830
```

These commands ran on 2026-10-21. Each machine ran in its own process:

```
A>CPNETLDR

CP/NET 1.2 Loader
=================

BIOS         C700H  3900H
BDOS         B900H  0E00H
SNIOS   SPR  B600H  0300H
NDOS    SPR  AA00H  0C00H
TPA          0000H  AA00H

CP/NET 1.2 loading complete.
<Warm Boot>
A>LOGIN

A>NETWORK B:=A:[0]

A>CPNETSTS
...
Requester ID = 01H
Network Status Byte = 10H
Disk device status:
  Drive A: = LOCAL
  Drive B: = Drive A: on Network Server ID = 00H
...
A>DIR B:
B: BNKBDOS  SPR : BNKXDOS  SPR : RESBDOS  SPR : TMP      SPR
...
B: SCHED    RSP : SPOOL    RSP : MPM      SYS : MPMLDR   COM
A>PIP B:CPNET.TXT=A:IOBYTE.TXT[V]
<Warm Boot>
A>PIP A:MPMLDR.CPY=B:MPMLDR.COM[V]
<Warm Boot>
A>STAT A:MPMLDR.CPY

 Recs  Bytes  Ext Acc
   52     8k    1 R/W A:MPMLDR.CPY
```

After that, `TYPE CPNET.TXT` on the server console typed the file that the requester wrote. `cpmcp` read `MPMLDR.CPY` off `requester.dsk` on the host. It was the same, byte for byte, as `MPMLDR.COM` on `server.dsk`.

The line runs at 9600 baud. In this check, `DIR B:` of 20 files took about 11 s. The copy of the 6656-byte `MPMLDR.COM` from the server took about 33 s.

The machines

Machine	Port B	Disk
`server.toml`	`socket:8830`. It listens on TCP port 8830.	`server.dsk`
`server-ss1.toml`	`socket:8830`. It listens on TCP port 8830.	`server-ss1.dsk`
`requester.toml`	`socket:localhost:8830`. It calls the server.	`requester.dsk`

The line is a `socket:` endpoint, because it passes each byte unchanged. Both machines run the processor at 2 MHz, because the timeouts of NETWRKIF and SNIOS are instruction loops. The server also has an 88-VI/RTC and RAM to FEFFh. Start one of the two servers, not both.

The server has one console, on 2SIO port A, and one user segment, 0000h–68FFh. `MPMSTAT` on the server shows the two network processes. `NtwrkIP0` waits for port B, and `SERVR0PR` waits for a message:

```
0A>MPMSTAT
...
Process(es) DQing:
 [ABORT   ] ABORT
 [NtwrkQI0] SERVR0PR
 [CliQ    ] cli
 [ATTACH  ] ATTACH
...
Polling Process(es):
  NtwrkIP0
```

The System Support 1 server

`server-ss1.toml` is `server.toml` with a CompuPro System Support 1 at 50h in place of the 88-VI/RTC. Its XIOS, `SS1XIOS.ASM`, is the one of the `mpm2` example. "The System Support 1 machine" in the README of the `mpm2` example tells how the XIOS uses the board, and how to set a real board.

- The timer of the System Support 1 gives the tick. The handler loads the timer again after each tick. Because of that, a tick that comes while NETWRKIF has interrupts disabled waits until the next `EI`.
- At boot, the XIOS reads the clock of the System Support 1 and sets the date and time of MP/M II.
- The XIOS is one page longer. The user segment is 0000h–67FFh.

The requester is the same for the two servers. This boot of the server ran through `altairsim --mcp` on 2026-10-22:

```
BNKXIOS SPR  A300H  1A00H
MP/M II Sys  6800H  9800H
Memseg  Usr  0000H  6800H
...
0A>TOD
Thu 10/22/<6 16:12:44
```

`TOD` shows the year 2026 as `<6`. DRI's `TOD` prints two digits for the year, and counts the years from 1978.

Real Altair hardware

The disks of this folder also run on two real Altairs. Write each `.DSK` image to an 8″ disk.

Machine	Boards
Server	An 8080 at 2 MHz. RAM from 0000h to FEFFh, and the DBL PROM at FF00h. An 88-DCDD with one drive. An 88-2SIO at ports 10h–13h. An 88-VI/RTC at port FEh.
Requester	An 8080 at 2 MHz. RAM from 0000h to at least DFFFh, for the 56K CP/M, and the DBL PROM at FF00h. An 88-DCDD with one drive. An 88-2SIO at ports 10h–13h.

1. Connect the console terminal of each machine to its 2SIO port A.
2. Connect 2SIO port B of the server to 2SIO port B of the requester. Connect the transmit data of each port to the receive data of the other port. Connect the two signal grounds.
3. Set port B of each 2SIO to 9600 baud. The XIOS of the server and SNIOS set 8 data bits and 2 stop bits.
4. Hold CTS and DCD of each port B low. A 6850 with CTS high does not send, and a 6850 with DCD high does not receive.
5. Set the RTC of the 88-VI/RTC to count the 60 Hz line with no divider, and to interrupt on VI5. MP/M II takes RST 5 (0028h) as its tick. For `server-ss1.dsk`, use a System Support 1 at 50h in place of the 88-VI/RTC. Set it as "The System Support 1 machine" in the README of the `mpm2` example tells. Before the first boot, run `SS1TEST` of the `mpm2` example to test the board. "Test a real System Support 1" in its README tells how.
6. Boot each machine from the DBL PROM at FF00h. Boot the server first.

The timeouts of NETWRKIF and SNIOS are loops for a 2 MHz 8080. The builds need one machine with two 88-DCDD drives and 56K. The requester has enough memory for both builds.

The server network interface

`NETWRKIF.ASM` is DRI's `NETWRKIF.ASM` with these changes:

Change	Why
8080 code, one requester (`NmbSlvs equ 1`)	The Altair has an 8080. One line connects one requester.
The line is 88-2SIO port B: status 12h, data 13h, RDRF bit 0, TDRE bit 1	DRI's code is for the Altos SIO and CTC.
The first byte of a message is waited for with the XDOS poll function, on XIOS poll device 4	DRI's code calls the Altos XIOS console input routine. Device 4 is port B input in `RESXIOS.ASM`.
The receive timeout is about 100 ms at 2 MHz	DRI's count of 80 loops is 1.7 ms on the Altair. That is less than two characters at 9600 baud.

The rest of the file is DRI's code: the Appendix E protocol, the process, the queues and the configuration table.

While NETWRKIF waits for a message, interrupts stay on. While a message moves, NETWRKIF turns interrupts off, as DRI's code does. At 9600 baud a message of 261 bytes takes about 0.3 s, and the clock loses most of the ticks of that time.

The requester network I/O system

`SNIOS.ASM` is DRI's `SNIOS.ASM` with a new `Altair` setting:

Change	Why
The line is 88-2SIO port B: status 12h, data 13h, RDRF bit 0, TDRE bit 1	DRI's settings are for the DSC-2, the Altos and the DB82.
`ntwrkinit` resets port B and sets 8 data bits and 2 stop bits	The XIOS of the server sets its port B the same way.
The requester ID is 01h	The server has ID 00h.
No delay after each character that the requester sends	DRI's delay is about 6 ms a character at 2 MHz. The Altair server reads each character of a message as it comes.

The timeouts are DRI's counts. At 2 MHz, the requester waits about 95 ms for each character of a message.

The requester disk is a copy of `CPM22.DSK`. It has the requester files of the CP/NET disk, and a `SNIOS.SPR` that RMAC and LINK made from `SNIOS.ASM`.

The requester disk has the PIP of the CP/NET disk, PIP 1.5, in place of PIP 1.6 of the CP/M disk. PIP 1.6 sets byte 13 of the FCB to 0 before it closes a new file. MP/M II refuses that close with extended error 6. With PIP 1.6, the requester prints `NDOS Err 06, Func 10`, and the file stays on the server with the type `$01`.

The DRI disk

The CP/NET files come from the DRI CP/NET 1.2 end-user disk. It is one 8″ single-sided single-density disk in IBM 3740 format: 77 tracks of 26 sectors of 128 bytes. Track 0 holds the IBM labels. The sample sources on the disk are set for the Altos computer.

Label	DIGITAL RESEARCH END USER DISKETTE, Program CP/NET, Version 1.2
Serial	NET-000-01220
Copyright	1980 1982
Teledisk comment	`Original CP/NET distribution disk`, 2005-04-01 13:34:10
`CPNET80.IMD`	201,657 bytes, SHA-256 `958e76cb…f1fdc80d`

The disk came in `cpnet80_12.zip` (335,448 bytes unpacked, SHA-256 `9973bc86…aabb5feb`). Patrick Linstruth supplied it on 2026-10-20. The zip holds the disk as a Teledisk file, `CPNET80.TD0` (95,276 bytes, SHA-256 `d4e82888…10b5db52`). It also holds `CPNET80.JPG` and 29 files copied off the disk. In the zip, each `.COM` file is named `.CPM`.

altairsim reads ImageDisk files, but not Teledisk files. `CPNET80.IMD` was converted from `CPNET80.TD0`, and these checks were done:

- Every CRC in the Teledisk file matched: the header, the comment, each track header and the data of each sector.
- The IMD has every sector of the Teledisk file, the deleted-data marks of track 0, and the date and the comment.
- Each of the 29 files on `CPNET80.IMD` is the same as the copy in the zip. The `.ASM` files are the same up to the `Ctrl-Z` at the end of the text.

The disk holds these files:

File	Runs on	What it is
`NDOS.SPR`, `CCP.SPR`	requester	The network disk operating system, and the CCP that goes with it.
`CPNETLDR`	requester	Loads `SNIOS.SPR` and `NDOS.SPR` below the CP/M BDOS.
`NETWORK`, `LOCAL`, `LOGIN`, `LOGOFF`, `CPNETSTS`, `DSKRESET`, `ENDLIST`, `MAIL`, `XSUB`, `PIP`	requester	The CP/NET commands. `LOGIN.ASM` and `LOGOFF.ASM` are their sources.
`SNIOS.ASM`	requester	DRI's sample requester network I/O system, for a serial line with the protocol in Appendix E of the CP/NET manual.
`SERVER.RSP`	server	The MP/M II server process.
`NETWRKIF.ASM`	server	DRI's sample server network interface, for the same serial protocol.
`CPNIOS.ASM`, `CPBIOS.ASM`, `CPNOS.REL`, `CPNDOS.REL`, `CPBDOS.REL`, `MVCPNOS`	requester	CP/NOS: a requester with no disk that loads its system from the network.
`OMNINIOS.ASM`, `OMNINWIF.ASM`	both	Samples for the Corvus Omninet network, © Vano Associates. Not for a serial line.
`ULCNIOS.ASM`, `ULCIF.ASM`, `XIOSNET.ASM`	both	Samples for the ULCnet network on a Xerox 820. They need `PBMAIN.REL`, which is not on the disk.

The 88-DCDD disks

An 88-DCDD cannot read the IBM 3740 disk. `CPNET.DSK` has the 29 files of the DRI disk, on an 88-DCDD disk. The DRI copies of `SNIOS.ASM` and `NETWRKIF.ASM` are on it, not the Altair copies of this folder.

The files of `CPNET.DSK`, `SRVBUILD.DSK` and `REQBUILD.DSK` were copied on the host, with cpmtools. To do the same:

1. Start the Tarbell machine from this folder, with the `MOUNT` command. altairsim converts the `.imd` file to `CPNET80.dsk`, a raw image that a Tarbell controller reads:

   ```
   cd examples/cpnet
   altairsim tarbell -x "MOUNT fdc0:drive1 CPNET80.IMD"
   ```

2. Type `QUIT` at the `altairsim>` prompt.

3. Copy the files off `CPNET80.dsk`:

```
mkdir dri
cpmcp -f ibm-3740 CPNET80.dsk '0:*.*' dri/
```

4. Format a new 88-DCDD disk with `AFORMAT B:` on CP/M. Add 96 zero bytes to the end of the image, as on the other disks of this folder.

5. Copy the files to the new disk with `cpmcp -f altair`. `SRVBUILD.DSK` is a copy of `BUILD.DSK` of the `mpm2` example with `NETWRKIF.ASM` and `SERVER.RSP` added.

Build the server disk

`server.dsk` is built under CP/M 2.2, the same way as `MPM2.DSK` of the `mpm2` example. Sections 1.2 and 1.5 of the *MP/M II System Implementor's Guide* describe the steps. The build needs an Altair with two 88-DCDD drives and 56K of RAM, and these three disks:

Disk	What is on it
`CPM22.DSK`	The 56K CP/M 2.2b v2.3 of Mike Douglas for the 88-DCDD, from altairsim 1.3.4. It has PIP, ED, ASM, DDT, LOAD, STAT, SYSGEN and the other CP/M tools. It also has `AFORMAT.COM` 1.12, and `RMAC.COM` and `LINK.COM` from DRI MP/M II disk 2. The games, `LS.COM`, and the host-bridge programs `R`, `W` and `HDIR` are removed.
`SRVBUILD.DSK`	`RESXIOS.ASM`, `SS1XIOS.ASM`, `LDRBIOS.ASM`, `BOOT.ASM`, `AFORMAT.ASM` and `NETWRKIF.ASM`. From DRI MP/M II disk 1: `GENSYS.COM`, `MPMLDR.COM`, and the `.SPR`, `.RSP` and `.BRS` files. `SERVER.RSP` from the CP/NET disk.
A copy of `MPMII_1.DSK`	The new server disk. It has every file of DRI disk 1, and its system tracks are empty.

The build writes on all three disks. Use copies of them. On a real Altair, write each image to a disk. In the simulator, copy this folder and start the server build machine:

```
cp -R examples/cpnet ~/cpnet-server
cd ~/cpnet-server
cp MPMII_1.DSK NEW.DSK
altairsim srvbuild.toml
```

CP/M boots from `CPM22.DSK` in A:, with `SRVBUILD.DSK` in B:.

Assemble the XIOS, the network interface and the loaders

The tools are on A:, and the files that they make go to B:. `$PZ SZ` for RMAC and `.BBZ` for ASM make no listing, so that every file fits on `SRVBUILD.DSK`. At the end of the build, `SRVBUILD.DSK` has 8K free, and 2K free for the System Support 1 server.

1. Type `B:`.
2. Type `A:RMAC RESXIOS $PZ SZ`. RMAC makes `RESXIOS.REL`.
3. Type `A:LINK RESXIOS[OS]`. LINK makes `RESXIOS.SPR`.
4. Type `A:RMAC NETWRKIF $PZ SZ`. RMAC makes `NETWRKIF.REL`.
5. Type `A:LINK NETWRKIF[OS]`. LINK makes `NETWRKIF.SPR`.
6. Type `REN NETWRKIF.RSP=NETWRKIF.SPR`. An RSP is linked as an SPR, and then renamed.
7. Type `ERA *.REL`. LINK has used the `.REL` files, and B: needs their space.
8. Type `ERA *.SYM`. The build does not use the symbol files of LINK, and B: needs their space.
9. Type `A:ASM LDRBIOS.BBZ`. ASM makes `LDRBIOS.HEX`.
10. Type `A:DDT MPMLDR.COM`.
11. At the `-` prompt of DDT, type `ILDRBIOS.HEX`, then `R`. DDT puts the loader BIOS at 1700h, on top of the loader BIOS of DRI.
12. Type `G0`. DDT stops, and the `B>` prompt comes back.
13. Type `SAVE 26 MPMLDR.COM`. CP/M saves 0100h–1AFFh.
14. Type `A:ASM BOOT.BBZ`. ASM makes `BOOT.HEX`.

Steps 10 to 13 are section 1.2 of the guide.

Make MPM.SYS

1. Type `GENSYS`.
2. Give the answers of the table below. A `#` makes a number decimal. A number without it is hex.
3. Wait for `** GENSYS DONE **`. GENSYS writes `MPM.SYS` on B:.

GENSYS asks	Type
`Top page of operating system (FF) ?`	`FE`
`Number of TMPs (system consoles) (#4) ?`	`#1`
`Number of Printers (#1) ?`	`#1`
`Breakpoint RST (06) ?`	`06`
`Enable Compatibility Attributes (N) ?`	`N`
`Add system call user stacks (Y) ?`	`Y`
`Z80 CPU (Y) ?`	`N`
`Number of ticks/second (#60) ?`	`#60`
`System Drive (A:) ?`	`A:`
`Temporary file drive (A:) ?`	`A:`
`Maximum locked records/process (#16) ?`	`#16`
`Total locked records/system (#32) ?`	`#32`
`Maximum open files/process (#16) ?`	`#16`
`Total open files/system (#32) ?`	`#32`
`Bank switched memory (Y) ?`	`N`
`Number of user memory segments (#3) ?`	`#1`
`Dayfile logging at console (Y) ?`	`N`
`Accept new system data page entries (Y) ?`	`Y`
`ABORT   RSP (N) ?`	`Y`
`MPMSTAT RSP (N) ?`	`Y`
`SCHED   RSP (N) ?`	`N`
`SPOOL   RSP (N) ?`	`N`
`SERVER  RSP (N) ?`	`Y`
`NETWRKIFRSP (N) ?`	`Y`
`Base,size,attrib (69,97,80) ?`	Press `RETURN`
`Base,size,attrib (00,C0,00) ?`	`00,69,00`
`Accept new memory segment table entries (Y) ?`	`Y`

The top page is FE, because the DBL PROM is at FF00h. The server has one TMP, because 2SIO port B is the network line. MP/M II takes RST 6 for its debugger, because RST 5 is the tick of the 88-VI/RTC. The machine has no printer, so SPOOL is not added.

The two network RSPs make the operating system larger, so it starts at 6900h. Before the segment table, GENSYS prints the memory map. `CONSOLE DAT  6900H` is its lowest line. The one user segment takes all the memory below 6900h, 69h pages.

Make AFORMAT.COM

1. Type `A:ASM AFORMAT.BBZ`. ASM makes `AFORMAT.HEX`.
2. Type `A:LOAD AFORMAT`. LOAD makes `AFORMAT.COM`.

Copy the new files to A:

B: gets a different disk next, so the new files go to A: first.

1. Type `A:PIP A:=MPM.SYS[V]`.
2. Type `A:PIP A:=MPMLDR.COM[V]`.
3. Type `A:PIP A:=BOOT.HEX[V]`.
4. Type `A:PIP A:=AFORMAT.COM[V]`.
5. Type `A:`.

Make the new server disk

1. Put the copy of `MPMII_1.DSK` in B:. In the simulator, press `Ctrl-E`, type `MOUNT dsk0:drive1 NEW.DSK`, and type `RUN`.
2. Press `Ctrl-C`. CP/M reads the directory of the new disk. Without `Ctrl-C`, CP/M does not write on the new disk.
3. Type `PIP B:=MPM.SYS[V]`.
4. Type `PIP B:=MPMLDR.COM[V]`. The new `MPMLDR.COM` replaces the one of DRI.
5. Type `PIP B:=AFORMAT.COM[V]`.
6. Type `STAT B:*.PRL $SYS`. Each `.PRL` file gets the system attribute, so every user number can run it.

Write the system tracks

DDT puts `BOOT` and `MPMLDR.COM` into the memory image of SYSGEN, and SYSGEN writes them to the system tracks of B:. This is section 1.5.1 of the guide, for the SYSGEN of the Altair CP/M. Its image starts at 0900h, one 128-byte sector after another from track 0 sector 0. The DBL PROM reads `BOOT` from sectors 0 and 2, and `MPMLDR` starts at sector 3 (0A80h).

1. Type `DDT MPMLDR.COM`.

2. At the `-` prompt, type these commands, one at a time:

```
M100,1AFF,3000
M3000,49FF,A80
IBOOT.HEX
R900
M980,9FF,A00
G0
```

   The first two `M` commands move `MPMLDR` to 0A80h, through 3000h, because the two places overlap. `IBOOT.HEX` and `R900` read `BOOT` to 0900h. The last `M` puts the second half of `BOOT` in sector 2.

3. Type `SYSGEN`.

4. At `Source drive name (or RETURN to skip)`, press `RETURN`.

5. At `Destination drive name (or RETURN to reboot)`, type `B`.

6. At `Destination on B, then type RETURN`, press `RETURN`. SYSGEN prints `Function complete`.

7. At `Destination drive name (or RETURN to reboot)`, press `RETURN`. CP/M starts again from A:.

Build the System Support 1 server disk

The steps are the same, with these changes:

1. Before you assemble, type `ERA B:RESXIOS.ASM`. `SRVBUILD.DSK` has no space for the files of the build and both XIOS sources.
2. Type `A:RMAC SS1XIOS $PZ SZ`, not `A:RMAC RESXIOS $PZ SZ`.
3. Type `A:LINK RESXIOS=SS1XIOS[OS]`, not `A:LINK RESXIOS[OS]`. GENSYS reads the XIOS from `RESXIOS.SPR`.
4. In GENSYS, give `00,68,00` for the user segment.

Boot the new server disk

1. On a real Altair, put the new disk in A: of the server, and start the DBL PROM at FF00h.

2. In the simulator, type `QUIT` at the monitor. At the host prompt, type these commands:

```
cp NEW.DSK server.dsk
altairsim server.toml
```

Build the requester disk

The requester disk is a copy of `CPM22.DSK` with the requester files of CP/NET and a new `SNIOS.SPR`. The build needs an Altair with two 88-DCDD drives and 56K of RAM, and these two disks:

Disk	What is on it
A copy of `CPM22.DSK`	The new requester disk. The CP/M on its system tracks boots the requester.
`REQBUILD.DSK`	`SNIOS.ASM`. From the CP/NET disk: `NDOS.SPR`, `CCP.SPR`, `CPNETLDR.COM`, `NETWORK.COM`, `LOCAL.COM`, `LOGIN.COM`, `LOGOFF.COM`, `CPNETSTS.COM`, `DSKRESET.COM`, `ENDLIST.COM` and `PIP.COM`.

The build writes on both disks. Use copies of them, and a copy of `CPM22.DSK` that the server build did not use. In the simulator, copy this folder again and start the requester build machine:

```
cp -R examples/cpnet ~/cpnet-requester
cd ~/cpnet-requester
altairsim reqbuild.toml
```

CP/M boots from `CPM22.DSK` in A:, with `REQBUILD.DSK` in B:.

1. Type `B:`.
2. Type `A:RMAC SNIOS $PZ SZ`. RMAC makes `SNIOS.REL`.
3. Type `A:LINK SNIOS[OS]`. LINK makes `SNIOS.SPR`.
4. Type `A:PIP A:=*.SPR[V]`. PIP copies `NDOS.SPR`, `CCP.SPR` and `SNIOS.SPR` to A:.
5. Type `A:PIP A:=*.COM[V]`. PIP copies the CP/NET commands to A:. PIP 1.5 of the CP/NET disk replaces PIP 1.6 on A:.
6. Type `A:`.

The disk in A: is now the requester disk. To boot it:

1. On a real Altair, put the disk in A: of the requester, and start the DBL PROM at FF00h.
2. In the simulator, press `Ctrl-E` and type `QUIT`. At the host prompt, type these commands:

   ```
   cp CPM22.DSK requester.dsk
   altairsim requester.toml
   ```

Rebuild the disks with the script

`make-cpnet-disks.py` types the commands of "Build the server disk" and "Build the requester disk" through `altairsim --mcp`, on copies of the disks of this folder. It checks what CP/M prints after each command. It checks the system tracks and `MPM.SYS` of the new server disk, and boots the disk into MP/M II. It also checks that each requester file on the new requester disk is the same as the one on `REQBUILD.DSK`.

The script needs Python 3, the `altairsim` on your PATH, and cpmtools with the `altair` disk format. The build of 2026-10-21 used altairsim 1.3.4. Run the script from this folder, with the names of the two new disks:

```
./make-cpnet-disks.py server.dsk requester.dsk
```

For the System Support 1 server, add `--xios SS1XIOS`. The requester disk is the same:

```
./make-cpnet-disks.py --xios SS1XIOS server-ss1.dsk requester.dsk
```

A build from the same disks gives the same bytes:

Disk	SHA-256
`server.dsk`	`d7dc7e98…eb8046b6`
`server-ss1.dsk`	`2dbc6bf4…2057432b`
`requester.dsk`	`956b025a…6489f971`

The builds use the sources on `SRVBUILD.DSK` and `REQBUILD.DSK`, not the `.ASM` files of this folder. The `.ASM` files of this folder are copies of them. The MP/M II files of this folder are copies of the ones of the `mpm2` example. After you change `NETWRKIF.ASM`, put the new file on `SRVBUILD.DSK`. `cpmcp` does not write over a file, so remove the old file first:

```
cpmrm -f altair SRVBUILD.DSK 0:netwrkif.asm
cpmcp -f altair SRVBUILD.DSK NETWRKIF.ASM 0:
```

Read more

- The *CP/NET Network Operating System Reference Manual* of Digital Research, for the message format, the serial protocol and the SNIOS entry points.
- The README of the `mpm2` example, for MP/M II on the Altair.