

altairsim — Expansion boards on the Altair 680b

2026-08-08 · 114e79b

The built-in `altair680` machine is a Motorola 6800 with just its onboard console — one 6850 ACIA at `F000/F001`. Two examples here add a period expansion board to it:

- `altair680-uio.toml` — the **Universal I/O board** (`680uio`): a second serial port and a parallel port.
- `altair680-kcacr.toml` — the **KCACR audio-cassette interface** (`680kcacr`): a cassette you load and save S-record tapes from.

A Universal I/O board

`altair680-uio.toml` adds the **Universal I/O board** (`680uio`), the 680b's general-purpose expansion board: a **second 6850 serial port** and a **6820 PIA parallel port**, memory-mapped like everything on the 6800.

```
cd examples/altair680
altairsim altair680-uio.toml
```

You land at the `MON680 .` prompt, exactly as the plain `altair680` does — you are still typing at the **onboard** console. The UI/O is the *second* set of ports, sitting quietly until the guest talks to it.

Where the board lives

At its default S9 window (base `F000`) the board decodes:

Addresses	What
<code>F006</code> / <code>F007</code>	6850 ACIA — serial control/status and Rx/Tx data (<code>serial</code>)
<code>F008</code> – <code>F00B</code>	6820 PIA-C — sections A/B, control and data/DDR (<code>p1a</code> , <code>p1b</code>)
<code>F003</code>	switch inputs (<code>sense</code>) — fixed, read-only
<code>F010</code> – <code>F013</code>	8-bit non-latched output, Drive 1 + Drive 2

`SET uio0 base=0xF020` slides the serial+PIA window (the fixed `F003` and `F010 – F013` do not move); `SET uio0 pias=2` populates a second 6820 (`p2a / p2b` at `F00C – F00F`). From the `altairsim>` monitor (press `^E` at the console), `SHOW MAP uio0` prints the live map.

Reaching the second serial from the monitor

The config wires the UI/O's serial line to `out:uio-serial.log` and PIA section `pla` to `out:uio-pia.log` (both beside this file). `MON680's M addr` command examines and deposits a byte at an address, so you can drive the board by hand:

1. `M F006` and deposit `03` (ACIA master reset), then `M F006` again and deposit `D1` ($\div 16$, `8N2`) — the 6850 is not auto-configured on power-up.
2. `M F007` and deposit a byte — it is transmitted, and appears in `uio-serial.log`.

The PIA works the same way: with control bit 2 set (deposit `04` to `F008`), a byte deposited to `F009` is driven onto section A's lines and lands in `uio-pia.log`.

The two `*.log` files are created when the machine starts and are not part of the repository — they are just where this example's output goes.

See `reference/Altair 680b Universal IO Board.md` for the full register model, and the built-in `altair680` machine for the base machine this extends.

A KCACR audio cassette

`altair680-kcacr.toml` adds the **KCACR** (`680kcacr`), the 680b's audio-cassette interface: a UART at `F010` (status/control) and `F011` (data), recording **Kansas City Standard** FSK, with a loader/punch PROM at `FD00` (`builtin:kcacr`).

```
cd examples/altair680
altairsim altair680-kcacr.toml
```

A cassette (`kcacr-demo.tap`) is already in the recorder — a tiny Motorola S-record tape that deposits four bytes (`86 2A 39 00`) at `0200` . From the `.` prompt:

1. `JFD00` — run the loader PROM. It reads the tape's S-records into memory and returns to the monitor at the terminating `S9` record. (On a bad tape it prints one letter and stops: `C` = checksum/non-hex, `M` = memory error.)
2. `M0200` — examine `0200` . It reads back `86` , the first byte the tape carried.

To **save** memory back to a cassette, `JFD74` and answer the two address prompts with the start and end (four hex digits each); the loader writes S-records terminated by `S9` .

Loading real 680b software

The same `JFD00` path loads any S-record cassette. MITS's **680b Cassette BASIC** and the Editor/Assembler are on deramp.com as `.S19` files (and as `.WAV`), under `downloads/altair/software/altair_680/`. Save one beside this file, put it in the recorder in place of the demo tape (`MOUNT kc0:tape "Cassette BASIC V1.1 R3.2.S19"`), `JFD00` to load it, then `J` its start address — the loader does not care whether the tape holds four bytes or all of BASIC.

The `680kcacr` reads and writes **Kansas City** modulation only; a plain-MITS 88-ACR tape is refused. See `reference/Altair 680b KCACR.md` for the board and `roms/KCACR/` for the loader PROM.