

altairsim — The graphical front panel

2026-08-10 · b27aff8

```
cd examples/frontpanel && altairsim fp.toml
```

This is the base Altair — the machine you get by typing `altairsim` with no arguments — with one thing added: its **front-panel board is connected to altairsim-fp**, a separate program that draws the panel's lamps and switches in a window and mirrors this machine as it runs. Loading `fp.toml` prints a short note and lands you at the `altairsim>` monitor prompt, exactly like the base machine; there is no disk and no auto-boot. Drive it by hand — `MOUNT` a disk and `RUN FF00`, or single-step and watch the address, data and status lamps move.

altairsim-fp is a separate program

altairsim-fp is not part of altairsim and is not in this package. It lives in its own repository — an OpenGL rendering of the Altair's front panel that runs as a **TCP server** — and you build and run it yourself. It listens on **TCP port 8800** by default, and this machine is the client that dials it:

```
# fp.toml re-opens the base front-panel board and points it at the bridge
[[board]]
id      = "fp0"
connect = "socket:localhost:8800"
```

Get altairsim-fp from its repository and start it as that project documents. Then run this example. **Launch order does not matter:** the fp board keeps redialling `localhost:8800` on a backoff, so whether you start altairsim-fp before or after altairsim, the panel connects when it appears — and reconnects if you quit and relaunch the window.

Using it

Once both are running:

You do	What happens
Type at the <code>altairsim></code> prompt (this terminal)	The monitor runs the machine — <code>MOUNT</code> , <code>RUN FF00</code> , <code>STEP</code> , <code>EXAMINE</code> , ...
Watch the panel window	The lamps show the last bus cycle : the address and data buses, and the 8080 status word (MEMR, M1, STACK, INP, OUT, $W\bar{O}$, INTA). At speed they blur — as they did in 1975.
Flip the on-screen sense switches (SA8–SA15)	A guest <code>IN 0FFH</code> reads them back — e.g. the DBL boot PROM checks switch A12 for the console's stop-bit count.

Two monitor commands tune or drop the link:

```
DISCONNECT fp0:gui      # unplug the panel and stop redialling
SET fp0 FPS=60          # cap how many panel updates per second cross the wire
CONNECT fp0:gui socket:HOST:PORT  # or point it at a different host/port
```

More

The board, the sense-switch decode, and the exact wire protocol are documented in `docs/boards/mits-frontpanel.md`.