

altairsim — 88-UIO — two cards in one

2026-09-06 · 4d137d1

```
cd examples/uio
altairsim uio.toml
```

You will land at Altair **8K BASIC 3.2**:

```
MEMORY SIZE? ↵
TERMINAL WIDTH? ↵
WANT SIN-COS-TAN-ATN? Y

10312 BYTES FREE

ALTAIR BASIC VERSION 3.2
[EIGHT-K VERSION]

OK
```

What makes this different

The `basic8k` machine needs **two** boards — an 88-2SIO for the console terminal and an 88-ACR for the cassette. This machine has **one**: the MITS **88-UIO**, a board that carries both.

- Its **6850 serial port** sits at **0x10** — exactly where 88-2SIO Port A lives — so it is the console.
- Its **cassette section** sits at **0x06** — exactly where an 88-ACR lives — so it is the tape.

Because both halves land at the standard addresses, the bootstrap MITS shipped (`LDR8K32.HEX` , toggled in at address 0) runs **unmodified**, and 8K BASIC never learns it is talking to a combined card. The sense switches are `0x8C` (A15 = load from cassette, A11+A10 = 2SIO-style terminal), straight from the loader's own header.

Try it

↵ at each prompt takes the default, `Y` enables the math functions, then type a program:

```
10 PRINT 6*7
20 PRINT "TAPE OK"
RUN
```

Things the UIO can do that a plain ACR cannot:

```
SHOW uio0          ; see both halves: serial_port, port, standard, motor
SET uio0 standard=kansas ; SW-1: switch the modem to the Kansas City standard (2400/1200)
REWIND uio0:tape    ; the cassette has motor control, but rewinding is still your finger
```

`^E` (STOP) returns you to the `altairsim>` monitor from BASIC at any time.

What is in here

File	What it is
<code>uio.toml</code>	the machine — one 88-UIO, 16K of RAM, the front panel, the console
<code>8K BASIC Ver 3-2.tap</code>	Altair 8K BASIC 3.2, a period cassette image
<code>LDR8K32.HEX</code>	the 8K bootstrap loader, toggled in at 0

The tape comes off in about a second because `clock_hz = 0` is flat out; `SET cpu0 clock_hz=2000000` buys back the real 2 MHz machine and the ~90 seconds a 300-baud cassette actually took.