101						
101	1	2	8	4	5	flashing: Battery less than 3%,
						MUST charge ASAP ***
			_			battery only
102	1	2 2	8 2	4	5	flashing: Battery less than 3%,
						EMERGENCY chargeing Now ***
						If in this state for a long time, Battery may be damaged.
						charger inserted 🛂
201	1	2	3	4	5	flashing 5 second, wait 30 senconds, repeat
						battery volumn between 3% and 10%,
						suggest chargeing ASAP 🗯
						battery only
202	1	2	3	4	(5)	flashing only after key being pressed 5 second
						battery volumn between 10% and 20%,
						battery only
203	0	2	3	4	5	flashing only after key being pressed 5 second
						battery volumn between 20% and 40%,
						battery only
204	0	2	8	4	5	flashing only after key being pressed 5 second
						battery volumn between 40% and 60%,
205						battery only
205	1	2	8	4	5	flashing only after key being pressed 5 second
						battery volumn between 60% and 80%,
206	1	2	8	4	6	battery only
200	•		•	•	9	flashing only after key being pressed 5 second battery volumn between 80% and 100%,
						battery only
301	0 0	2	3	4	5	* *
301	•		3	4	3	always flashing battery volumn between 3% and 20%,
						charger inserted 25
302	0 0	0 0	3	4)	5	always flashing
			•	•		battery volumn less than 20% to 40%,
						charger inserted 2"
303	0 0	0 0	0 0	4)	5	always flashing
						battery volumn less than 40% to 60%,
						charger inserted 2 than 1070 to 5070,
304	0 0	0 0	1 1	0 0	5	always flashing
						battery volumn less than 60% to 80%,
						charger inserted 2 than coye to coye, 2
305	0 0	0 0	0 0	0 0	0 0	always flashing
	_	_				battery volumn less than 80% to 90%,
						charger inserted 🛂
306	0 0	0 0	0 0	0 0	0 0	contant on, no flashing, battery is full.
						battery volumn less than 90% to 100%,
						charger inserted 🛂
						charger inserted 🛂