

DMB PRODTRACK

User Guide

Per-role walkthroughs for the back office and the shop-floor app

Version	1.0
Date	27 September 2026
Application release	Sprint 2-3 batch (branch feature/ sprint-2-3)
Audience	Plant staff - administrators, planners, supervisors, operators, QC inspectors, viewers
Author	Deo Bernal

Practice project by DMB Websolutions. The manufacturing scenario, business rules and data are fictitious, plausible assumptions.

Contents

- About this guide** 3
 - Roles at a glance 3
- Signing in and your password** 4
 - Sign in..... 4
 - Change your password 4
- Back office screens** 6
 - Dashboard 6
 - Sales orders..... 6
 - Work orders 9
 - Products and routings..... 15
 - QC checklists 18
 - Administration (Admin)..... 19
- Shop floor app** 25
 - Open the app and choose your station..... 25
 - Station queue 25
 - Scanning..... 26
 - Run an operation 27
 - QC inspection 29
- Typical workflows by role** 31
 - Planner 31
 - Supervisor 31
 - Operator 31
 - QC inspector 31
 - Administrator..... 31
 - Viewer..... 31
- Troubleshooting** 32

About this guide

DMB ProdTrack tracks production work for a plant that makes safety identification products: pipe markers, valve tags, safety signs and labels. It follows a job from the customer's sales order to a finished, inspected and packed work order.

The application has two parts:

Part	Address (local run)	Used by	Device
Back office	https://localhost:5001/	Admin, Planner, Supervisor, QC, Viewer	Desktop or laptop browser
Shop floor	https://localhost:5001/floor/	Operators, QC inspectors, supervisors	Tablet or phone at a station (installable web app)

All screenshots in this guide were captured from the running application with the automated Playwright tests, using demonstration data. Names of customers and people are fictitious.

Roles at a glance

Role	What the role can do
Admin	Everything, including user administration, stations and reason codes
Planner	Sales orders, work orders (create, edit, release, hold, cancel), artwork upload and approval, products and routings
Supervisor	Everything read-only, plus hold/resume/cancel work orders, print travelers and run operations on the floor
Operator	Run operations on the floor (start, pause, complete, log scrap), upload artwork; read everything else
QC	Run operations and record QC inspections; read everything else
Viewer	Read-only access to dashboards, orders, products and routings

A user can hold several roles. Menu entries that a role cannot use are hidden, and the server rejects the action even if someone tries to call it directly.

Signing in and your password

Sign in

Open the back office address in a browser. You are sent to the sign-in page. Enter the email address and password your administrator gave you and select **Sign in**.

DMB ProdTrack

Shop floor

Sign in

Sign in to DMB ProdTrack

Email or user name name@example.com

Password password

☐ Keep me signed in on this device

Sign in

Accounts are created by an administrator. Forgot your password? Ask your supervisor or admin to reset it.

Sign-in page

After five wrong passwords the account is locked for 15 minutes. An administrator can clear the lock by resetting the password.

Change your password

New accounts, and accounts whose password was reset by an administrator, must choose a new password at the first sign-in. Enter the temporary password once and the new password twice. Passwords need at least 12 characters. You can change your password at any time with **Change password** in the menu.

The screenshot displays the 'Change password' interface in the DMB ProdTrack application. The sidebar on the left contains the following menu items: Dashboard, Sales orders, Work orders, New work order, Products, Routings, QC checklists, Stations, Reason codes, Users, Shop floor, and a 'Change password' option at the bottom. The main content area is titled 'Change password' and includes a message: 'Your account uses a temporary password. Please choose a new one to continue.' Below this message are three input fields: 'Current password' (with placeholder text 'current'), 'New password (at least 12 characters)' (with placeholder text 'new'), and 'Confirm new password' (with placeholder text 'confirm'). A blue 'Update password' button is positioned at the bottom of the form. The top right of the page shows the user's email 'admin@prodtrack.e2e' and a 'Sign out' link.

Forced password change

To sign out, select **Sign out** at the top right. Sessions last up to 12 hours of activity.

First run on a new database. In the local development setup the app creates the administrator `admin@prodtrack.local` with the temporary password `ChangeMe!Dev2026`. Change it at the first sign-in and then create personal accounts for everyone else under **Users**.

Back office screens

Dashboard

The dashboard is the home page. Tiles show how many work orders are in each status (Draft, Released, InProgress, OnHold, Completed), how many are **late** (open and past their due date), and today's output: work orders completed, good units, scrap units and scrap rate. The **WIP by station** table lists, per station, the operations that are ready, in progress, paused and pending.

The dashboard updates **live**: whenever an operator starts, pauses or completes a step, the numbers refresh within a second or two. The green **Live** badge shows the live connection is up; **Refresh** reloads on demand.

The screenshot shows the DMB ProdTrack dashboard. On the left is a dark sidebar with navigation links: Dashboard, Sales orders, Work orders, New work order, Products, Routings, QC checklists, Stations, Reason codes, Users, Shop floor, and Change password. The main content area has a header with the user 'admin@prodtrack.e2e' and a 'Sign out' link. Below the header, the 'Dashboard' title is followed by a green 'Live' badge and a 'Refresh' button. The dashboard features two rows of KPI tiles. The first row shows counts for Draft (3), Released (0), InProgress (1), OnHold (1), Completed (0), and Late (0). The second row shows daily metrics: Completed today (0), Good units today (114), Scrap units today (2), and Scrap rate today (1.7%). Below these is a 'WIP by station' table with columns for Station, Ready, In progress, Paused, and Pending. The table lists eight stations with their respective counts. At the bottom, a note states: 'Updates live as work orders and operations change (SignalR). Last update 10:48:36.'

Station	Ready	In progress	Paused	Pending
DIECUT-01 · Die-cutting / cutting	0	0	0	1
ENGRAVE-01 · Engraving	0	0	0	0
LAM-01 · Laminating	0	0	0	1
PACK-01 · Packing and shipping	1	0	0	1
PREPRESS · Prepress / artwork	1	0	0	0
PRINT-01 · Digital printing	0	0	0	1
QC-01 · Quality control	0	0	0	1

Dashboard with live KPIs and WIP by station

Sales orders

Sales orders lists customer orders with number, customer, customer PO, due date, status and line count. Filter by status or search by customer, PO or number.

DMB ProdTrack

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

admin@prodtrack.e2e

Sign out

Sales orders

New sales order

All statuses ▼

Number	Customer	PO	Due	Status	Lines	Work orders
SO-2026-00001	Petron Bataan Refinery	PO-2026-0917	2026-10-12	Open	2	2

1 sales order(s).

Sales order list

To enter an order (Planner, Admin) select **New sales order**, fill in customer, customer PO and due date, then add one line per product: product, quantity and, where relevant, legend text (for example the pipe content "FUEL GAS"). The product's default specification is copied to the line. Save to get a number such as `SO-2026-00001`.

DMB ProdTrack

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

admin@prodtrack.e2e

Sign out

New sales order

Customer

Customer PO

Due date

Petron Bataan Refinery

PO-2026-0917

10/12/2026

Lines

Product	Qty	Legend (pipe markers)	
PM-VIN-FLAM-2 · Pipe marker, vinyl, flammable, 2in OD	120	FUEL GAS	Remove
VT-BRASS-RND-38 · Valve tag, brass, round 38 mm	40		Remove

Add line

Create sales order

Cancel

New sales order with lines

On the order page, **Create work orders** makes one Draft work order per line. Lines that already have a work order are skipped, so it is safe to press it again after adding a line. Each line then links to its work order. **Edit** changes the header and the lines that do not yet have a work order. **Cancel order** is only possible while no open work orders exist for it.

DMB ProdTrack

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

admin@prodtrack.e2e [Sign out](#)

Created 2 work order(s): WO-2026-000001, WO-2026-000002.

SO-2026-00001 [Open](#)

[Edit](#) [Cancel order](#)

Customer Petron Bataan Refinery

Customer PO PO-2026-0917

Due 2026-10-12

Created 2026-09-28 10:48

Lines

#	Product	Qty	Legend	Work order
10	PM-VIN-FLAM-2 · Pipe marker, vinyl, flammable, 2in OD	120	FUEL GAS	WO-2026-000001 Draft
20	VT-BRASS-RND-38 · Valve tag, brass, round 38 mm	40		WO-2026-000002 Draft

Sales order with generated work orders

Work orders

Work orders lists all jobs, newest first, 25 per page. Filter by status, search by number, SKU or customer, and see late jobs highlighted.

DMB ProdTrack

admin@prodtrack.e2e

Sign out

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

Work orders

Search number, SKU or customer

All statuses

mm/dd/yyyy

☐ Late only

Number	Product	Customer	Status	Qty	Done	Due	Priority
WO-2026-000003	SS-ALU-DANGER-A4 · Safety sign, aluminium, DANGER, A4	San Miguel Brewery	Draft	30	0	2026-10-05	3
WO-2026-000004	VT-BRASS-RND-38 · Valve tag, brass, round 38 mm	Meralco Substation	Released	40	0	2026-10-05	3
WO-2026-000001	PM-VIN-FLAM-2 · Pipe marker, vinyl, flammable, 2in OD	Petron Bataan Refinery	Draft	120	0	2026-10-12	3
WO-2026-000002	VT-BRASS-RND-38 · Valve tag, brass, round 38 mm	Petron Bataan Refinery	Draft	40	0	2026-10-12	3

Previous

Page 1 of 1 (4 work orders)

Next

Work order list

New work order creates a job directly from a product when there is no sales order (for example stock or rework): choose the product, quantity, due date, priority (1 = highest), customer and legend.

Version 1.0 - 27 September 2026

Page 10 of 32

The screenshot shows the 'New work order' page in the DMB ProdTrack application. The left sidebar contains a navigation menu with the following items: Dashboard, Sales orders, Work orders, New work order (highlighted), Products, Routings, QC checklists, Stations, Reason codes, Users, Shop floor, and Change password. The top right of the page shows the user 'admin@prodtrack.e2e' and a 'Sign out' link. The main content area is titled 'New work order' and contains the following form fields:

- Product:** A dropdown menu with the placeholder text '(select a product)'.
- Quantity:** A text input field containing the value '100'.
- Due date:** A date picker showing '10/05/2026'.
- Priority (1 = highest):** A text input field containing the value '3'.
- Customer:** A text input field.

Below the form fields is a blue button labeled 'Create draft'.

New work order

Artwork proofs

Products that need artwork approval (signs, printed pipe markers, custom labels) cannot be released until a proof is approved. On the Draft work order upload a proof (PDF, PNG, JPG or SVG, up to 20 MB). A Planner or Admin then **Approves** it, or **Rejects** it with a reason; a new upload supersedes the previous version.

DMB ProdTrack

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

admin@prodtrack.e2eSign out

WO-2026-000003

Draft

ReleaseDelete draft

Product

Customer

Quantity

Due

Priority

Routing

SS-ALU-DANGER-A4 · Safety sign, aluminium, DANGER, A4 (SafetySign)

San Miguel Brewery

0 / 30 completed

2026-10-05

3

Assigned at release

Operations

Operations are created from the current routing when the work order is released.

Hold / cancel

Cancel reason

Cancel work order

Artwork proofs (approval required before release)

Version	File	Status	Uploaded	Decision
Upload proof (PDF, PNG, JPG, SVG; max 20 MB)		Reject reason		
	Choose FileNo file chosen			

Draft work order waiting for artwork approval

Release

Release copies the current routing of the product type into the work order as numbered operations (10, 20, 30, ...). The first operation becomes **Ready** at its station; the others are **Pending**. From now on the work order appears in the station queues on the shop floor.

DMB ProdTrack

[Dashboard](#)
[Sales orders](#)
[Work orders](#)
[New work order](#)
[Products](#)
[Routings](#)
[QC checklists](#)
[Stations](#)
[Reason codes](#)
[Users](#)
[Shop floor](#)
[Change password](#)

admin@prodtrack.e2e [Sign out](#)

Released. Operations were created from the current routing.

WO-2026-000004

Released

Print traveler

Product

Customer

Quantity

Due

Priority

Routing

VT-BRASS-RND-38 - Valve tag, brass, round 38 mm (ValveTag)

Meralco Substation

0 / 40 completed

2026-10-05

3

v1

Operations

#	Station	Status	Input	Good	Scrap	Started	Completed
10	PREPRESS Prepress / artwork	Ready	40	0	0		
20	ENGRAVE-01 Engraving	Pending	0	0	0		
30	QC-01 Quality control	Pending	0	0	0		
40	PACK-01 Packing and shipping	Pending	0	0	0		

Hold / cancel

Hold reason

Note (optional)

(select)

Put on hold

Cancel reason

Cancel work order

Artwork proofs

Version	File	Status	Uploaded	Decision
Upload proof (PDF, PNG, JPG, SVG; max 20 MB)		Reject reason		
Choose File	No file chosen			

Released work order with operations

Each operation row shows input, good and scrap quantities, who started it and when, and an **Open on floor** link. The page refreshes live while operators work.

Print the traveler

Print traveler opens a printable page with a QR code for the work order and one QR code per operation, the specification and blank columns for operator, good, scrap and date. Select **Print** (or save as PDF from the print dialog). The traveler travels with the job; operators scan its codes at each station.

Print
Back to work order



DMB PRODTRACK · WORK ORDER TRAVELER

WO-2026-000004

VT-BRASS-RND-38 · Valve tag, brass, round 38 mm

Customer	Meralco Substation	Quantity	40
Due date	2026-10-05	Priority	3
Sales order	-	Routing	v1
Spec	Material: Brass · Dia mm: 38.0 · Thk mm: 0.8 · Shape: Round · Hole mm: 4.8		

Operations

Scan	#	Station	Setup / std	Operator	Good	Scrap	Date
	10	PREPRESS Prepress / artwork	10 min + 0.5 min/unit				
	20	ENGRAVE-01 Engraving	10 min + 0.5 min/unit				
	30	QC-01 Quality control	10 min + 0.5 min/unit				
	40	PACK-01 Packing and shipping	10 min + 0.5 min/unit				

Scan the header code to open the work order, or an operation code at its station in the ProdTrack shop-floor app (/floor).
Printed 2026-09-28 10:48 (plant time).

Printable traveler with QR codes

Hold, resume and cancel

Supervisors, Planners and Admins can stop a job:

- **Hold** - choose a hold reason code (for example CUSTOMER-CHANGE) and add a note. The work order shows a yellow banner; floor actions on it are blocked until it is resumed. A failed QC inspection puts the work order on hold automatically with reason QC-FAIL .
- **Resume** - returns the job to the status it had before the hold.
- **Cancel** - requires a reason and is only possible while no operation has been completed.

DMB ProdTrack

admin@prodtrack.e2e [Sign out](#)

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

Work order put on hold.

WO-2026-000005

On hold

Print traveler

Resume

On hold: CUSTOMER-CHANGE: Customer revising legend text

Product

Customer

Legend

Quantity

Due

Priority

Routing

PM-VIN-FLAM-2 · Pipe marker, vinyl, flammable, 2in OD (PipeMarker)

Shell Tabangao

STEAM 150 PSI

0 / 60 completed

2026-10-05

3

v1

Operations

#	Station	Status	Input	Good	Scrap	Started	Completed	
10	PREPRESS Prepress / artwork	Ready	60	0	0			Open on floor
20	PRINT-01 Digital printing	Pending	0	0	0			Open on floor
30	LAM-01 Laminating	Pending	0	0	0			Open on floor
40	DIECUT-01 Die-cutting / cutting	Pending	0	0	0			Open on floor
50	QC-01 Quality control	Pending	0	0	0			Open on floor
60	PACK-01 Packing and shipping	Pending	0	0	0			Open on floor

Artwork proofs

Version	File	Status	Unloaded	Decision
---------	------	--------	----------	----------

Work order on hold with reason

When someone else changed the record

If another user saved the same record after you opened it, ProdTrack does not overwrite their change. You see the message "Someone else changed this ... after you opened it" with a **Reload latest** button. Reload, re-apply your change and save again.

Products and routings

Products lists the catalogue with SKU, name, type and whether artwork approval is required. Planners and Admins can add or edit products and their type-specific specification (material, size, colour scheme, signal word and so on).

DMB ProdTrack

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

admin@prodtrack.e2e

Sign out

Products

Search SKU or name

All types

New product

SKU	Name	Type	Artwork approval	Status
LBL-POLY-50X25	Label, polyester, 50 x 25 mm	Label	Required	Active
PM-VIN-FLAM-2	Pipe marker, vinyl, flammable, 2in OD	PipeMarker	No	Active
SS-ALU-DANGER-A4	Safety sign, aluminium, DANGER, A4	SafetySign	Required	Active
VT-BRASS-RND-38	Valve tag, brass, round 38 mm	ValveTag	No	Active

Product catalogue

Routings shows the current routing (sequence of stations) for each product type, with setup time and standard minutes per unit.

DMB ProdTrack

admin@prodtrack.e2e [Sign out](#)

[Dashboard](#)
[Sales orders](#)
[Work orders](#)
[New work order](#)
[Products](#)
[Routings](#)
[QC checklists](#)
[Stations](#)
[Reason codes](#)
[Users](#)
[Shop floor](#)
[Change password](#)

Routings

Current routing per product type. Editing creates a new version; released work orders keep the version they were released with.

PipeMarker · v1 · Pipe marker (printed) Current

[Edit \(new version\)](#)

#	Station	Setup (min)	Std min/unit	Overlap
10	PREPRESS · Prepress / artwork	10	0.5	No
20	PRINT-01 · Digital printing	10	0.5	No
30	LAM-01 · Laminating	10	0.5	No
40	DIECUT-01 · Die-cutting / cutting	10	0.5	No
50	QC-01 · Quality control	10	0.5	No
60	PACK-01 · Packing and shipping	10	0.5	No

ValveTag · v1 · Valve tag (engraved) Current

[Edit \(new version\)](#)

#	Station	Setup (min)	Std min/unit	Overlap
10	PREPRESS · Prepress / artwork	10	0.5	No
20	ENGRAVE-01 · Engraving	10	0.5	No
30	QC-01 · Quality control	10	0.5	No
40	PACK-01 · Packing and shipping	10	0.5	No

SafetySign · v1 · Safety sign Current

[Edit \(new version\)](#)

#	Station	Setup (min)	Std min/unit	Overlap
10	PREPRESS · Prepress / artwork	10	0.5	No
20	PRINT-01 · Digital printing	10	0.5	No
30	LAM-01 · Laminating	10	0.5	No
40	DIECUT-01 · Die-cutting / cutting	10	0.5	No

Routings per product type

Edit opens the routing editor. Add, remove and reorder steps, choose the station, setup minutes, standard minutes per unit and whether a step may overlap the previous one. Saving creates a **new version**; work orders that are already released keep the operations they were released with.

DMB ProdTrack

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

admin@prodtrack.e2eSign out

Routing editor · ValveTag

Saving creates a new version and makes it current. Work orders already released keep the version they were released with; drafts pick up the new version at release.

Routing name

Valve tag (engraved)Based on current v1.

#	Station	Setup (min)	Std min/unit	Allow overlap
10	PREPRESS · Prepress / artwork (Prepress)	10	0.5	☐
20	ENGRAVE-01 · Engraving (Engraving)	10	0.5	☐
30	QC-01 · Quality control (Inspection)	10	0.5	☐
40	PACK-01 · Packing and shipping (Packing)	10	0.5	☐

Add step

Sequences are renumbered 10, 20, 30... in the order shown. "Allow overlap" lets a step start while the previous step is still running.

Save as new version

Cancel

Routing editor

QC checklists

QC checklists shows the inspection checklist for each product type: pass/fail items and measured items with tolerances (for example engraving depth 0.1-0.3 mm). Inspectors complete these checklists on the shop floor.

Version 1.0 - 27 September 2026

Page 18 of 32

DMB ProdTrack

admin@prodtrack.e2e [Sign out](#)

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

QC checklists

Inspection checklists used at Inspection stations (QC-01). A measured item fails automatically when the value is outside its tolerance; any failed item fails the inspection and puts the work order on hold (reason QC-FAIL).

PipeMarker · Pipe marker inspection

#	Check	Kind	Tolerance
10	Legend text matches the work order (spelling, flow arrows)	PassFail	-
20	Colour scheme matches ASME A13.1 and the spec	PassFail	-
30	Length deviation from spec	Measured	-2 – 2 mm
40	Adhesion and laminate free of bubbles	PassFail	-

ValveTag · Valve tag inspection

#	Check	Kind	Tolerance
10	Engraved text legible and matches the work order	PassFail	-
20	Engraving depth	Measured	0.1 – 0.3 mm
30	Hole size and position correct	PassFail	-
40	Edges deburred	PassFail	-

SafetySign · Safety sign inspection

#	Check	Kind	Tolerance
10	Signal word, header colour and symbol per ANSI Z535	PassFail	-
20	Message text matches the approved proof	PassFail	-
30	Width deviation from spec	Measured	-1 – 1 mm
40	Mounting holes and corners correct	PassFail	-

Label · Label inspection

#	Check	Kind	Tolerance
10	Text and barcode legible, matches the proof	PassFail	-
20	Width deviation from spec	Measured	-0.5 – 0.5 mm
30	Adhesive liner intact, labels peel cleanly	PassFail	-
40	Finish / laminate as specified	PassFail	-

QC checklist templates

Administration (Admin)

Stations

Stations are the work centres on the floor (Prepress, Printing, Laminating, Engraving, Die-cutting, QC, Packing). Admins can add, rename or deactivate stations. Deactivating does not affect work already in progress.

DMB ProdTrack

admin@prodtrack.e2e

Sign out

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

Stations

Code

Name

Type

Work center

Add station

Printing

☐ Show inactive

Code	Name	Type	Work center	Status	
DIECUT-01	Die-cutting / cutting	Cutting		Active	Edit Deactivate
ENGRAVE-01	Engraving	Engraving		Active	Edit Deactivate
LAM-01	Laminating	Laminating		Active	Edit Deactivate
PACK-01	Packing and shipping	Packing		Active	Edit Deactivate
PREPRESS	Prepress / artwork	Prepress		Active	Edit Deactivate
PRINT-01	Digital printing	Printing		Active	Edit Deactivate
QC-01	Quality control	Inspection		Active	Edit Deactivate

Stations

Reason codes

Reason codes explain **scrap** (misprint, colour mismatch, cutting error, material defect), **pauses** (break, waiting for material, end of shift), **downtime** and **holds** (customer change, QC fail). Admins add codes or deactivate old ones; deactivated codes are no longer offered but stay on historical records.

DMB ProdTrack

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

admin@prodtrack.e2e

Sign out

Reason codes

Code

Description

Category

Scrap

Add

Code	Description	Category	Status	
MACHINE-FAULT	Machine fault	Downtime	Active	Deactivate
MAINTENANCE	Planned maintenance	Downtime	Active	Deactivate
NO-OPERATOR	No operator available	Downtime	Active	Deactivate
CUSTOMER-CHANGE	Customer change	Hold	Active	Deactivate
QC-FAIL	Failed QC inspection	Hold	Active	Deactivate
BREAK	Break	Pause	Active	Deactivate
MATERIAL-WAIT	Waiting for material	Pause	Active	Deactivate
SHIFT-END	End of shift	Pause	Active	Deactivate
COLOR-MISMATCH	Colour does not match the approved proof	Scrap	Active	Deactivate
CUT-ERROR	Cutting or die-cut error	Scrap	Active	Deactivate
MATERIAL-DEFECT	Material defect	Scrap	Active	Deactivate
MISPRINT	Misprint	Scrap	Active	Deactivate

Reason codes

Users

Users lists every account with roles and status.

The screenshot displays the 'Users' management interface in DMB ProdTrack. The sidebar on the left contains navigation links: Dashboard, Sales orders, Work orders, New work order, Products, Routings, QC checklists, Stations, Reason codes, Users (highlighted), Shop floor, and Change password. The main content area is titled 'Users' and includes a 'New user' button. Below the title is a table with the following data:

Name	Email	Roles	Badge	Home station	Status
Administrator	admin@prodtrack.e2e	Admin			Active
Maria Santos	maria.santos@dmb.local	Operator	B-0142		Active Must change password

User list

New user creates an account with email (the sign-in name), display name, optional employee number, badge number and home station, one or more roles, and a temporary password. The user must change it at the first sign-in. ProdTrack does not send email - give the temporary password to the person directly.

DMB ProdTrack

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

admin@prodtrack.e2e

Sign out

New user

Email (sign-in name)

Display name

maria.santos@dmb.local

Maria Santos

Employee #

Badge #

Home station

B-0142

(none)

Roles

☐ Admin

☐ Planner

☐ Supervisor

☒ Operator

☐ QC

☐ Viewer

Temporary password (min 12 characters)

The user must change it at first sign-in.

Create user

[Back to users](#)

Create a user

Open a user to edit the profile and roles, **Disable user** (the person can no longer sign in; open sessions end at the next security check), **Enable** again, or **Reset password** to a new temporary password (this also clears a lockout).

DMB ProdTrack

Dashboard

Sales orders

Work orders

New work order

Products

Routings

QC checklists

Stations

Reason codes

Users

Shop floor

Change password

admin@prodtrack.e2eSign out

Maria SantosActive

Email (sign-in name)

Display name

maria.santos@dmb.local

Maria Santos

Employee #

Badge #

Home station

B-0142

(none)

Roles

☐ Admin

☐ Planner

☐ Supervisor

☒ Operator

☐ QC

☐ Viewer

Save changes

Back to users

Access

Disable user

Disabled users cannot sign in; open sessions end at the next security revalidation.

Reset password

New temporary password

Reset

The user must change it at next sign-in. Lockout is cleared.

Edit a user, disable or reset password

Shop floor app

Open the app and choose your station

On the station tablet open `/floor/` (for example `https://localhost:5001/floor/`) and sign in with your own account. In Chrome or Edge you can **Install** the app so it opens full screen from the home screen.

Pick your station. The tablet remembers it.

DMB ProdTrack - Shop floor

Select your station

Signed in as Administrator (Admin)

DIECUT-01

Die-cutting / cutting

ENGRAVE-01

Engraving

LAM-01

Laminating

PACK-01

Packing and shipping

PREPRESS

Prepress / artwork

PRINT-01

Digital printing

QC-01

Quality control

Or scan a traveler

Scan or type WO / operation code

Open

Station picker

Station queue

The queue lists the operations that can be worked at this station - Ready, In progress and Paused - ordered by priority and due date. Work orders on hold stay visible with a yellow **On hold** badge, but cannot be worked until they are resumed. The queue refreshes by itself when work arrives from the previous station. Tap an operation to open it, or scan.

Version 1.0 - 27 September 2026

Page 25 of 32

DMB ProdTrack - Shop floor

PREPRESS

 Prepress / artwork

• Live

Refresh

Change station

Open

WO-2026-000004 Ready

Step 10 · VT-BRASS-RND-38 · Valve tag, brass, round 38 mm

40 pcs
Due 2026-10-05 · Priority 3

WO-2026-000005 Ready On hold CUSTOMER-CHANGE: Customer revising legend text

Step 10 · PM-VIN-FLAM-2 · Pipe marker, vinyl, flammable, 2in OD

60 pcs
Due 2026-10-05 · Priority 3

Station queue

Scanning

The scan box at the top of the floor pages accepts:

- **Camera scanning** - select the camera button and hold the traveler QR code in front of the camera. This uses the browser's built-in barcode detector (Chrome and Edge on Android, ChromeOS and macOS). The browser asks for camera permission the first time; choose **Allow**.
- **Hardware scanners** - USB or Bluetooth scanners that type the code and press Enter work in the scan box.
- **Manual entry** - type the work order number (for example `WO-2026-000004`) or an operation code (`OP:WO-2026-000004:10`) and press Enter.

A work order code opens its current operation; an operation code opens that step. A short tone confirms a good scan. Unknown codes show a clear message:

DMB ProdTrack - Shop floor

ENGRAVE-01 Engraving

• Live

Refresh

Change station

Scan or type WO / operation code

Open

Work order WO-2026-999999 was not found.

WO-2026-000004

Ready

Step 20 · VT-BRASS-RND-38 · Valve tag, brass, round 38 mm

38 pcs

Due 2026-10-05 · Priority 3

Unknown code

Run an operation

The operation page shows the work order, product, station, input quantity, good and scrap so far, and the due date.

DMB ProdTrack - Shop floor

WO-2026-000004 · step 10

PREPRESS queue

Ready

PREPRESS · Prepress / artwork

VT-BRASS-RND-38 · Valve tag, brass, round 38 mm

Input	Good	Scrap	WO qty
40	0	0	40

Due 2026-10-05

Start

Operation ready to start

1. **Start** - clocks the step on and records you as the operator.
2. **Pause** - choose a reason (break, waiting for material, end of shift) and select **Pause**. **Resume** continues.
3. **Log scrap** - enter the quantity and a scrap reason, optionally a note, and select **Log scrap**. Scrap can be logged several times while the step is in progress.
4. **Complete step** - enter the good quantity and select **Complete step**. Good plus scrap cannot exceed the input. The next step becomes Ready at its station with the good quantity as its input. Completing the last step completes the work order.

DMB ProdTrack - Shop floor

WO-2026-000004 · step 10

PREPRESS queue

Scrap logged.

In progress

PREPRESS · Prepress / artwork

VT-BRASS-RND-38 · Valve tag, brass, round 38 mm

Input	Good	Scrap	WO qty
40	0	2	40

Due 2026-10-05 · started 10:48 by admin@prodtrack.e2e

Scrap logged

2 × MISPRINT (Misprint)

Good quantity

40

Complete step

Pause

(reason) ▾

Pause

Log scrap

Qty

MISPRINT · Misprint ▾

Note (optional)

Log scrap

Operation in progress with scrap logged

QC inspection

At an inspection station (QC-01) the operation page shows the checklist for the product type. Mark each pass/fail item and enter measured values; values outside the tolerance fail automatically. Enter the sample size and notes and select **Record inspection** (QC or Admin role).

- **Pass** completes the step and moves the job on to packing.
- **Fail** puts the work order on hold with reason **QC-FAIL**. A supervisor reviews it and resumes it when the problem is fixed.

DMB ProdTrack - Shop floor

WO-2026-000004 · step 30

QC-01 queue

Started.

In progress

QC-01 · Quality control

VT-BRASS-RND-38 · Valve tag, brass, round 38 mm

Input	Good	Scrap	WO qty
38	0	0	40

Due 2026-10-05 · started 10:48 by admin@prodtrack.e2e

QC checklist · Valve tag inspection

10. Engraved text legible and matches the work order

PassFail

20. Engraving depth

0.2

0.1 – 0.3 mm

30. Hole size and position correct

PassFail

40. Edges deburred

PassFail

Sample size

Notes

1

Record inspection

Pass completes this step; fail puts the work order on hold (QC-FAIL).

Pause

(reason)

▼

Pause

Log scrap

Qty

(reason) ▼

Note (optional)

Log scrap

QC checklist on the floor

Typical workflows by role

Planner

1. Enter the customer's **sales order** with its lines.
2. Select **Create work orders** on the sales order.
3. For each work order that needs artwork, upload the proof and approve it (or wait for approval).
4. **Release** the work order and **Print traveler**; hand the traveler to the first station.
5. Watch progress on the **Dashboard** and the work order page.

Supervisor

1. Watch the **Dashboard**: late jobs, WIP by station, today's scrap rate.
2. **Hold** a work order when there is a customer change or quality issue; **Resume** once it is cleared.
3. Review work orders on hold after a failed inspection (QC-FAIL).
4. Help at stations: supervisors can also run operations on the floor.

Operator

1. Open /floor/, pick your station, and work the queue top to bottom.
2. Scan the traveler (or tap the operation), **Start**, log any **scrap** with a reason, then **Complete step** with the good quantity.
3. **Pause** with a reason for breaks or when waiting for material.

QC inspector

1. At the QC station scan the traveler and **Start** the inspection step.
2. Fill in the checklist and **Record inspection**. Fail holds the job for the supervisor.

Administrator

1. Create user accounts and assign roles; reset passwords and disable leavers.
2. Maintain stations and reason codes.
3. Change your own bootstrap password at the first sign-in.

Viewer

Use the dashboard, sales order and work order lists and detail pages for information. Actions are hidden.

Troubleshooting

Problem	What to do
"Invalid sign-in attempt"	Check the email and password (passwords are case-sensitive). After 5 failures the account is locked for 15 minutes; ask an Admin to reset the password.
Asked to change password every time	Complete the change form; the new password must be at least 12 characters and different from the temporary one.
A menu item or button is missing	Your role does not allow that action. Ask an Admin to add the role.
"Someone else changed this ... after you opened it"	Another user saved the record first. Select Reload latest , re-apply your change and save again.
Cannot release a work order	Approve the artwork proof first (products that require artwork), and check the work order is still Draft.
Cannot start or complete an operation	The work order may be on hold or cancelled, or the step is not Ready yet (a previous step is still open). At inspection stations a passed inspection is needed before completion.
Complete is rejected	Good quantity plus scrap cannot exceed the input quantity.
Camera button does not appear or shows no picture	The browser does not support the barcode detector, or camera permission was denied. Allow the camera in the site settings, use a hardware scanner, or type the code. The camera only works on <code>https://</code> or <code>localhost</code> .
"No work order or operation found" after scanning	The traveler may be from another environment or the code was mistyped. Check the number printed under the title.
Dashboard shows no Live badge	The live connection dropped (for example after the laptop slept). It reconnects automatically; select Refresh or reload the page.
"An error has occurred" banner	Reload the page. If it keeps happening, note the time and tell the administrator; the server log (<code>App_Data/Logs</code>) has the details and a trace id.
Shop-floor app shows an old version	Close and reopen the app, or reload with Ctrl+F5 on a desktop browser.