

member switches 8-35

MIB files 4-7 1000BASE-T module, Catalyst 2900 XL 1-12 MIB objects 4-6, 4-7 MIBs files 4-7 Δ objects 4-6 aaa (authentication, authorization, and variables 4-7 accounting) Telnet access 4-4 configuring 6-67 accounting in TACACS+ 6-61 managing 6-61 adding aaa accounting command 6-66 secure addresses 6-58 aaa authorization command 6-65 static addresses 6-59 aaa authorization exec tacacs+ local switches to cluster 5-14 command 6-65 VLAN to database 8-33 aaa new-model command 6-64, 6-67 address abbreviations count, secure 7-15 char, variable field A-3 resolution 6-45 chars, variable field A-3 security violations 7-14 dec, variable field A-3 see also addresses hex, variable field A-3 addresses inet, variable field A-3 dynamic accessing accelerated aging 6-26 CMS 2-35 aging time 6-57 command modes 3-3 default aging 6-26 console port access 4-3 HTTP access 4-5

Numerics

described 6-56	ADSL 1-6
removing 6-58	advertisements, VTP 8-15
MAC	aging, accelerating 6-26
adding secure 6-58	aging time, changing address 6-57
aging time 6-57	alarms group, in RMON 4-6
discovering 6-45, 6-56	allowed-VLAN list 8-40
tables, managing 6-56	American National Standards Institute
secure	see ANSI
adding 6-58	ANSI 1-6
described 6-56, 6-58	Plan 998 7-23
removing 6-59	AppleTalk Remote Access (ARA) 6-65
static	Apply button 2-33
adding 6-59	ARP table
configuring (EtherChannel) 6-61	address resolution 6-45
described 6-56, 6-59	managing 6-45
removing 6-60	asymmetric digital subscriber line
Address Resolution Protocol (ARP)	see ADSL
see ARP table	ATM ports
address table	duplex and speed 7-2
aging time, configuring 6-57	trunks and other features 8-37
dynamic addresses, removing 6-58	VLAN membership 8-7
MAC 6-56	authentication
secure addresses	NTP 6-18
adding 6-58	TACACS+ 6-61
removing 6-59	authorization, TACACS+ 6-61
static addresses	automatic discovery, cluster candidates 5-4
adding 6-59	autonegotiation
removing 6-60	connecting to devices without 7-2
administrative information, displaying 5.19	mismatches 9.3

В	caveats
	password and privilege level 5-9
bandwidth, graphing 2-9, 2-20	CDP 1-3
BPDU message interval 6-40	configuring 6-22
broadcast client mode, configuring 6-18	discovering candidates with 5-4
broadcast messages, configuring for 6-18	CGMP 1-2
broadcast storm control	controlling management packets with 6-46
disabling 7-5	removing router ports 6-48
enabling 7-4	see also Fast Leave
broadcast traffic and protected ports 7-13	chassis system error messages A-5
browser configuration 2-1, 2-35, 4-1, 5-1	Cisco.com xxii
buttons, CMS window 2-33	Cisco 575-LRE CPE 1-6, 7-22
	Cisco Access Analog Trunk Gateway 1-18
	Cisco Access Digital Trunk Gateway 1-18
	Cisco CallManager software 1-16, 1-18
cabling, redundant 5-5	Cisco Discovery Protocol
Cancel button 2-33	see CDP
candidate pop-up menu	Cisco Group Management Protocol
Cluster Builder 2-29	see CGMP
candidates	Cisco IP Phones 1-16
adding 5-15	Cisco LRE 48 POTS Splitter
automatically discovering 5-4	(PS-1M-LRE-48) 1-6, 1-20
changing management VLAN for 8-5	Cisco SoftPhone software 1-16
characteristics 5-3	CiscoWorks 2000 1-8, 4-8
suggested 5-14	Class of service
why not added 9-8	see CoS
cascaded configuration, UplinkFast 6-26	CLI 1-7
Catalyst 3524-PWR XL 7-17	accessing 3-8
cautions xviii	command modes 3-2
	error messages 3-7

IOS Release 12.0 documentation xvi, 3-1	menu bar 2-14
managing cluster members with 5-21	overview 2-2, 2-3
overview 3-1	pop-up menus 2-18, 2-19
saving changes 3-10	port pop-up menu 2-18
using 3-1	toolbar 2-17
client mode, VTP 8-14	toolbar icons 2-17
Cluster Builder	cluster member
candidate pop-up menu 2-29	characteristics 5-3
illustrated 5-16	Cluster Membership Protocol
link pop-up menu 2-30	see CMP system error messages A-5
member pop-up menu 2-29	clusters, switch
menu bar 2-26	see also candidates, command switch, member switches, standby groups
overview 2-2, 2-21	accessing 5-13
polling interval 2-26	adding switches to 5-14
pop-up menus 2-29, 2-30	automatic discovery 5-4
starting 2-17 toolbar 2-27	candidate and cluster member 5-3
toolbar icons 2-27	command switch characteristics 5-2
	configuring 5-13
topology 2-24 device icon colors 2-24	described 5-2
device icon colors 2-24 device icons 2-24	disqualification code 9-8
	Gigabit Ethernet, illustrated 6-27
device labels 2-25	inventory, displaying 5-19
link icons 2-25	LRE profile considerations 5-13, 7-25
Cluster Management Suite 1-7	management VLAN, changing 8-4
see CMS 2-1	managing 5-21 , 5-22
Cluster Manager	overview 5-1
cluster tree 2-6	planning considerations 5-4
device pop-up menu 2-19	
front-panel image 2-5, 2-7	host names 5-10

LRE profiles 5-13	CMS
management VLAN 5-11	accessing 2-35
NAT commands 5-12	device labels 2-25
network port 5-12	features 2-2
passwords 5-8	link icons 2-25
SNMP community strings 5-10	overview
standby command switches 5-5	privilege level 6-16
planning considerations, switch-specific features 5-13	requirements 2-35 saving configuration changes 2-37
redundancy 5-17	topology 2-24
removing switches from 5-14	device icon colors 2-24
requirements 5-2	device icons 2-24
standby command-switch characteristics 5-3	troubleshooting CMS session 9-5
cluster tree 2-6	window components 2-31
icon colors 2-6	buttons 2-33
icons 2-6	host name list 2-32
Cluster View	lists 2-32
device pop-up menu 2-28	online help 2-33
displaying 9-8	tabs 2-32
interface 2-21	command-line error messages 3-7
menu bar 2-26	command-line interface
overview 2-2, 2-21	see CLI
toolbar 2-27	command modes 3-2, 3-3
toolbar icons 2-27	commands
topology 2-24	
device icon colors 2-24	aaa accounting 6-66 aaa authorization 6-65
device icons 2-24	aaa authorization exec tacacs+ local 6-65
device labels 2-25	
link icons 2-25	abbreviating 3-4 copy running-config startup-config 9-10
CMP system error messages A-5	copy running-coning startup-coning 9-10

default 3-5	redundant (standby) 5-17
dir flash 9-9	replacing
getting help (?) 3-5	with another switch 9-19
help 3-5	with cluster member 9-15
list of available 3-4, 3-6	requirements 5-2
name 5-18	standby 5-5, 5-17
no 3-5	see also candidates, member switches
port block 8-38	command variables, listing 3-6
preempt 5-18	community strings
reommand 5-21	configuring 5-10, 6-19
redisplaying 3-5	SNMP 5-10, 5-22
resetting to defaults 3-5	switch clusters 5-10
show cluster members 5-21	compatibility
spanning-tree root guard 6-45	cluster 5-4
stp-list 6-24	feature 9-2
undoing 3-5	config trap 6-19
usage basics 3-2	configuration
command switch	conflicts, managing 9-2, 9-13
and management 4-6	default VLAN 8-28
and managing with SNMP 5-22	file, VMPS database 8-54
characteristics 5-2	files, saving to an external server 9-9
configuration conflicts 9-13	guidelines
defined 5-2	port 7-2
enabling 5-14	VLANs 8-28
privilege levels 5-21	VMPS 8-56
recovery	VTP 8-18
from failure 5-7, 9-14, 9-22	VTP version 8-19
from failure without HSRP 9-22	saving to Flash memory 9-10
from lost member connectivity 9-13	VTP. default 8-20

configuration changes, saving	duplex 7-2, 7-3
CLI 3-10	dynamic ports on VMPS clients 8-50
CMS 2-37	dynamic VLAN membership 8-57
configuration examples, network 1-10	flooding controls 7-4
collapsed backbone and switch cluster 1-16	flow control 7-3
design concepts	hello time 6-40
cost-effective wiring closet 1-12	hops 6-23
high-performance workgroup 1-12	inline power 7-21
network performance 1-10	IP information 6-2
network services 1-11	IP Phone 7-18
redundant Gigabit backbone 1-12	load sharing 8-48
hotel network 1-20	login authentication 6-64
large campus 1-18	management VLAN 8-6
multidwelling configuration 1-23	native VLANs 8-43
small to medium-sized network 1-14	NTP 6-17
configuration files, DHCP 6-10	passwords 6-15
configuring	ports
802.1p class of service 8-44	protected 7-13
AAA 6-67	privilege levels 6-15
aging time 6-57	redundant clusters 5-17
broadcast messages 6-18	RMON groups 4-6
broadcast storm control 7-4	SNMP 6-18
CDP 6-22	speed 7-2, 7-3
clusters 5-13	standby command groups 5-17
community strings 5-10, 6-19	static addresses (EtherChannel) 6-61
Cross-stack UplinkFast 6-31	STP 6-24
date and time 6-17	Cross-stack UplinkFast 6-31
daylight saving time 6-17	port priorities 8-48
DNS 6-8	root guard 6-44, 6-45

UplinkFast 6-26	CSUF 6-31
switches	configuring 6-37
member 5-21	connecting stack ports 6-35
TACACS+ 6-61	fast convergence causes 6-33
trap managers 6-19	limitations 6-35
trunk port 8-38	overview 6-31
trunks 8-37, 8-39	Current Multicast Groups table 6-48
VLANs 8-1, 8-28, 8-32	customer premises equipment
VTP 8-18, 8-20	see CPE
VTP client mode 8-22	
VTP server mode 8-21	<u> </u>
VTP transparent mode 8-10, 8-23	D
conflicts, configuration 9-2, 9-13	database, VTP 8-27, 8-32
consistency checks in VTP version 2 8-16	date, setting 6-17
console port	daylight saving time 6-17
access 4-3	default configuration
connecting to 3-8	VLANs 8-28
default settings 4-3	VMPS 8-57
conventions	VTP 8-20
command xviii	defaults, resetting to 3-5
for examples xviii	default settings, changing 4-9
text xviii	deleting VLAN from database 8-34
copy running-config startup-config	destination-based forwarding 7-11
command 9-10	destination-based port groups 6-61, 7-10
CoS	device pop-up menu 2-19
configuring 8-44	Cluster Manager 2-19
priority 7-19	Cluster View 2-28
CPE 1-6, 1-20, 7-22	VSM 2-19
Cross-stack UplinkFast	
see CSUF	

DHCP 1-3, 6-4	documentation, CD-ROM
Client Request Process 6-5	Catalyst 2900 XL and Catalyst 3500 XL xix
configuring DHCP server 6-6	Cisco xx
configuring domain name and DNS 6-8	documentation, IOS Release 12.0 xvi, 3-1
configuring relay device 6-9	documentation, related xix
configuring TFTP server 6-7	domain name
example configuration 6-12	configuring 6-8
obtaining configuration files 6-10	described 6-8
overview 6-4	specifying 6-8, 8-18
digital telephone networks 1-6	Domain Name System server
dir flash command 9-9	see DNS
disabling	domains for VLAN management 8-13
broadcast storm control 7-5	DTP 8-39
CGMP Fast Leave 6-47	duplex
network port 7-8	configuration guidelines 7-2
port security 7-15	configuring 7-2, 7-3
SNMP 6-18	settings, ATM port 7-2
STP 6-25	duplex mode LED 2-10
Switch Port Analyzer (SPAN) 7-16	dynamic-access ports
trunking on a port 8-40	described 8-7
trunk port 8-40	limit on number of hosts 8-61
VTP 8-23	VLAN membership combinations 8-9
VTP version 2 8-25	dynamic addresses
DISL 8-39	see addresses
disqualification code 9-8	Dynamic Host Configuration Protocol
DNS	see DHCP
configuring 6-8	Dynamic ISL
described 6-8	see DISL
enabling 6-8	dynamic ports, configuring 8-58

dynamic port VLAN membership	port security 7-14, 7-15
configuration example 8-61	SNMP 6-18
configuring 8-58	SPAN 7-16
example 8-61	STP Port Fast 6-42
overview 8-53	UplinkFast 6-30
reconfirming 8-59	VTP pruning 8-25
troubleshooting 8-61	VTP version 2 8-24
VMPS database configuration file 8-54	encapsulation 8-44
Dynamic Trunk Protocol	environment system error messages A-6
see DTP	error messages 3-7
dynamic VLAN membership 8-57	EtherChannel port groups 7-10
	configuring static address for 6-61
	creating 7-12
E	Ethernet link, LRE ports 7-22, 7-25
egress port scheduling 8-45	Ethernet MANs 1-23
eligible switches 5-17	Ethernet VLAN, defaults and ranges 8-29
enable password	ETSI 1-6
see passwords	Plan 997 7-23
enable secret password	European Telecommunication Standards
see passwords	Institute
enabling	see ETSI
broadcast storm control 7-4	events group, in RMON 4-6
CGMP Fast Leave 6-47	examples
command switch 5-14	conventions for xviii
DNS 6-8	network configuration 1-10
Fast Leave 6-47	extended discovery 6-22
network port 7-7	
NTP authentication 6-18	
Port Fast 6-42	

F	port groups 7-10
•	restrictions 7-11
facility codes A-2	resuming 7-7
description A-2	source-based, illustrated 7-11
table A-2	see also broadcast storm control
fan fault indication 2-6	forwarding, static address 6-59
Fast EtherChannel port groups, creating 7-10	front-panel images 2-7
Fast Ethernet trunks 8-36	Cluster Manager 2-5
Fast Leave	VSM 2-4
defined 6-46	FTP, accessing MIB files 4-7
disabling 6-47	
enabling 6-47	
FDDI-Net VLAN defaults and ranges 8-30	G
FDDI VLAN defaults and ranges 8-29	GBICs
features	1000BASE-LX/LH module 1-12
configuration conflicts between 7-1, 8-1	1000BASE-SX module 1-12
conflicting port 9-2	1000BASE-T module 1-12
default settings 4-9	1000BASE-ZX module 1-12
incompatible 9-2	GigaStack 1-12
IOS 1-1	get-next-request operation 4-8
feedback to Cisco Systems, web xxi	get-request operation 4-8
File Transfer Protocol	get-response operation 4-8
see FTP, accessing MIB files	Gigabit Ethernet
Flash memory, files in 9-9, 9-10	clusters, illustrated 6-27
flooded traffic, reducing 7-6	ports, configuring flow control on 7-3
flooding controls, configuring 7-4	port settings 7-2
flow control, configuring 7-3	settings 7-2
forwarding	trunks 8-36
controlling (SNMP) 5-22	
delay 6-38 6-41	

Gigabit Interface Converter	<u> </u>
see GBICs	•
GigaStack system error messages A-7	IEEE 802.1p 7-17
global configuration mode 3-4	IEEE 802.1Q
graphs	configuration considerations 8-37
bandwidth 2-9, 2-20	interaction with other features 8-37
poll result 4-8	native VLAN for untagged traffic 8-43
	overview 8-36
	- IEEE 802.1Q trunks 8-37
н	ingress port scheduling 8-45
hello BPDU interval 6-40	inline power, configuring 7-21
hello time	inline power LED 2-13
changing 6-40	inline power port mode LED 2-10
defined 6-38	Integrated Services Digital Network
help, getting 2-17, 3-5	see ISDN
history group, in RMON 4-6	interface configuration mode 3-4
hold-time, modifying 6-48	interfaces
hops, configuring 6-23	IOS supported 1-7
host name list 2-32	Inter-Switch Link
host names	see ISL
abbreviations appended to 5-18	inventory, displaying 5-19
switch clusters 5-10	IOS command-line interface
to address mappings 6-8	see CLI
hosts, limit on dynamic ports 8-61	IOS Release 12.0 documentation xvi, 3-1
Hot Standby Router Protocol	IP addresses
see HSRP	and admittance to standby groups 5-3
HP OpenView 1-8	candidate 5-3
HSRP 5-5	discovering 6-45
HTTP access 4-5	management VLAN 5-11,8-4

point of access 5-2	L
in redundant clusters 5-5	
removing 6-2	LEDs
switch clusters 5-8	duplex mode 2-10
see also IP information	front-panel images 2-7
IP connectivity to the switch 4-2	LINE PWR mode 2-10
IP information	LRE mode 2-10
assigning 6-2	port 2-9, 2-11, 2-12, 2-13
configuring 6-2	redundant power system 2-8
displaying 5-19	RPS 2-8
removing 6-2	RPS 300 2-9
IP management packets, controlling 6-46	RPS 600 2-8
IP Phone	speed mode 2-10
calls 7-17	STAT mode 2-10
configuring 7-18	System 2-7
sound quality 7-17	legend 2-17
IPX server time-out, and Port Fast 6-42	Cluster Builder and Cluster View 2-27
ISDN 1-6	VSM and Cluster Manager 2-16
ISL 1-4	line configuration mode 3-4
interaction with other features 8-37	LINE PWR mode LED 2-13
overview 8-36	link information, displaying 5-20
	link pop-up menu
	Cluster Builder 2-30
J	link system error messages A-8
Java plug-in configuration 2-1, 2-35, 4-1, 5-1	lists 2-32
	load sharing
	STP, described 8-46
	using STP path cost 8-50
	using STP port priorities 8-47

location of switches, displaying 5-19	lre profile command 7-28
ogin authentication, configuring 6-64	lre profile global command 7-27
Long-Reach Ethernet	lre shutdown command 7-26
see LRE technology	LRE technology 1-6, 7-22
LRE-10 private profile 7-24	
LRE-15 private profile 7-24	BA
LRE-5 private profile 7-24	M
LRE link	MAC addresses
see LRE ports	adding secure 6-58
LRE link system error messages A-8	aging time 6-57
LRE mode LED 2-10	discovering 6-45, 6-56
LRE ports	MAC address tables, managing 6-56
assigning a private profile 7-28	management options 1-7
assigning a public profile 7-27	benefits
assigning the default profile 7-28	clustering 1-8
description 7-22	CMS 1-8
Ethernet link	CLI 3-1
CDP enabled 7-26	CMS 2-1
description 7-22, 7-25	management VLAN
duplex mode 7-25	changes, understanding 8-4
flow control 7-25	changing 5-12, 8-4, 8-5
speed 7-25	configuring 8-6
statistics 7-26	IP address 5-11, 8-4
LRE link	switch clusters 5-11
description 7-22	MANs, Ethernet 1-23
statistics 7-25	map
preventing loss of data 7-25	see topology
profiles 7-22	member pop-up menu
switch clusters 5-13	Cluster Builder 2-29

membership mode, VLAN port 8-7	mismatches, autonegotiation 9-3
member switches	mnemonic code A-3
accessing 8-35	Mode button 2-9
adding	model numbers, displaying 5-19
with Cluster Builder 5-14	modes
assigning host names to 5-10	command 3-3
defined 5-2	VLAN port membership 8-7
displaying inventory of 5-19	VTP
managing 5-21	see VTP modes
passwords, inherited 5-8	Modify button 2-33
recovering from lost connectivity 9-13	modules, displaying 5-19
menu bar	module system error messages A-9
Cluster Builder 2-26	monitoring
Cluster Manager 2-14	ports 7-16
Cluster View 2-26	traffic 7-16
VSM 2-14	VMPS 8-60
messages	VTP 8-26
CLI error 3-7	multicast groups
system error A-1	described 6-46
message severity levels	removing 6-48
description A-3	multicast packets
table A-3	see flooding controls
MIBs, accessing	multicast traffic and protected ports 7-13
files 4-7	Multicast VLAN Registration
objects 4-6	see MVR
variables 4-7	multi-VLAN ports
microfilters, phone 1-20	assigning to VLANs 8-10, 8-12
mini-point-of-presence	described 8-11
see POP	VLAN membership combinations 8-8

MVR 4-13, 6-49	multidwelling configuration 1-23
configuring 6-54	small to medium-sized network 1-14
parameters 6-53	Network Management System
guidelines 6-51	see NMS
limitations 6-52	network ports
overview 6-49	disabling 7-8
	enabling 7-7
N	switch clusters 5-12
IV	and trunks 8-37
name command 5-18	Network Time Protocol
NAT commands	see NTP
cluster considerations 5-12	NMS 4-7
native VLANs 8-43	no commands, using 3-5
NCPs 6-65	no lre profile global command 7-27
Network Address Translation	nonhomologated POTS splitter
see NAT	see Cisco LRE POTS Splitter
network configuration examples 1-10	(PS-1M-LRE-48) NTP
Network Control Protocols (NCPs) 6-65 network examples 1-10	authentication 6-18
collapsed backbone and switch cluster 1-16	broadcast-client mode 6-18
design concepts	client 6-17
cost-effective wiring closet 1-12	configuring 6-17
high-performance workgroup 1-12	described 6-17
network performance 1-10	
network services 1-11	0
redundant Gigabit backbone 1-12	0.11
hotel network 1-20	OK button 2-33
large campus 1-18	online help 2-33
	overheating indication, switch 2-6

Р	standby command switches 5-5
	switch-specific features 5-13
packets 7-6	polling interval
controlling management (CGMP) 6-46	Cluster Builder 2-26
see also traffic	switch image 2-15
parallel links 8-46	poll results, graphing 4-8
passwords	POP 1-23
candidate switch 5-16	pop-up menus
changing 6-15	Cluster Builder link 2-30
community strings 6-19	Cluster Builder member 2-29
recovery of 9-22	Cluster Manager device 2-19
setting 6-15	Cluster Manager port 2-18
switch clusters 5-8	port block command 7-13, 8-38
TACACS+ server 6-61	port-connection information, displaying 5-20
VTP domain 8-18	Port Fast
patch panel 1-20	enabling 6-42
path cost 6-42, 6-43, 8-50	STP parameter 8-56
PBX 1-20	port groups
plain old telephone service	and trunks 8-38
see POTS splitters	configuring static addresses
planning considerations, switch clusters 5-4	(EtherChannel) 6-61
host names 5-10	creating EtherChannel 7-10, 7-12
IP addresses 5-8	destination-based 6-61, 7-10
LRE profiles 5-13	forwarding 7-10
management VLAN 5-11	restrictions on forwarding 7-11
NAT commands 5-12	source-based 6-61, 7-10
network port 5-12	see also ports
passwords 5-8	port membership modes, VLAN 8-7
SNMP community strings 5-10	

port modes 2-9	configuring flow control on 7-3
changing 2-9	settings 7-2
LEDs 2-10	LRE 7-22
port-monitoring conflicts with trunks 8-37	monitoring 8-37
port pop-up menu 2-18	multi-VLAN 8-7, 8-10, 8-11, 8-12
Cluster Manager 2-18	network 8-37
VSM 2-18	priority 6-43, 8-44, 8-47
ports	protected 7-13
ATM	secure 7-15, 8-37
duplex and speed 7-2	security
trunks and other features 8-37	described 7-14
VLAN membership 8-7	disabling 7-15
configuration guidelines 7-2	enabling 7-15
configuring	speed, setting and checking 7-2
protected 7-13	static-access 8-7, 8-8, 8-10, 8-35
trunk 8-38	STP states 6-41
dynamic	trunk
configuring 8-58	configuring 8-38
see also dynamic port VLAN membership	disabling 8-40
dynamic access	trunks 8-7, 8-36
hosts on 8-61	VLAN assignments 8-10, 8-35
mode 8-7	see also port groups
and VLAN combinations 8-9	port scheduling 8-45
dynamic VLAN membership	port security system error messages A-9
reconfirming 8-59	POTS splitters 1-6
features, conflicting 9-2	homologated 1-20
flooded traffic 7-6	nonhomologated 1-20
forwarding, resuming 7-7	power, inline 7-21
Gigabit Ethernet	power detection on the

preempt command 5-18	private 7-23
priority	assigning 7-28
modifying switch 6-39	LRE-10 7-24
overriding 7-19	LRE-15 7-24
port	LRE-5 7-24
described 8-44	public 7-23
modifying 6-42, 6-43	assigning a public profile 7-27
standby group member 5-17	PUBLIC-ANSI 7-24
private branch exchange	PUBLIC-ETSI 7-24
see PBX	properties, displaying switch 5-19
private mode profiles 7-23	protected ports 1-2, 7-13
LRE-10 7-24	pruning
LRE-15 7-24	enabling on a port 8-42
LRE-5 7-24	enabling on the switch 8-25
private VLAN edge ports	overview 8-17
see protected ports	pruning-eligible list 8-42
privileged EXEC mode 3-3	PSTN 1-6, 1-18, 1-20, 7-23
privilege levels	publications, related xix
command switch 5-21	public mode profiles 7-23
inherited 5-8	PUBLIC-ANSI 7-24
mapping on member switches 5-9, 5-21	PUBLIC-ETSI 7-24
setting 6-15	Public Switched Telephone Network
specifying 6-15	see PSTN
profiles, LRE 7-22	
considerations 7-24	Q
default 7-24	u
assigning 7-28	QoS
	egress port scheduling 8-45
	ingress port scheduling 8-45, 8-46

R	RPS LED 2-8
	RPS 300 2-9
rcommand 5-21	RPS 600 2-8
reconfirmation interval, changing 8-59	RTD error messages A-10
recovery procedures 9-13	Runtime Diagnostic
redisplaying commands 3-5	see RTD error messages
redundancy	
cluster 5-17	2
STP 6-25	S
path cost 8-50	Save Configuration window 2-17
port priority 8-47	secure address count 7-15
UplinkFast 6-28	secure addresses
redundant power system 2-8	adding 6-58
relay device, configuring 6-9	described 6-58
releases, switch software 4-2	removing 6-59
remote devices without autonegotiation, connecting to 7-2	secure ports address-security violations 7-14
remote monitoring	disabling 7-15
see RMON	enabling 7-14, 7-15
remove vlan-list parameter 8-40	maximum secure address count 7-15
removing	and trunks 8-37
dynamic address entries 6-58	
IP information 6-2	security
multicast groups 6-48	port 7-14 TACACS+ 6-61
secure addresses 6-59	violations, address 7-14
static addresses 6-59, 6-60	Serial Line Internet Protocol
retry count, changing 8-60	see SLIP
RMON, supported groups 4-6	serial numbers, displaying 5-19
root guard 6-44, 6-45	server, domain name 6-8
router hold-time, modifying 6-48	server, domain name v-v

server mode, VTP 8-14	configuring for
servers, BOOTP 1-3, 6-4	single switches 6-18
set-request operation 4-8	enabling and disabling 6-18
settings	management, using 4-6
default, changing 4-9	managing clusters with 5-22
duplex 7-2, 7-3	network management platforms 4-6
Gigabit Ethernet port 7-2	RMON groups 4-6
speed 7-3	trap managers, configuring 6-19
STP 6-27	trap types 6-19, 6-20
STP default 6-26	SNMP Configuration window 2-17
set-top box, television 1-20	software
severity levels	recovery procedures 9-25
description A-3	requirements for
table A-3	changing management VLAN 5-11
show cluster members command 5-21	joining standby groups 5-3
show controllers ethernet-controller command 7-26	version numbers, displaying 5-19
show controllers lre commands 7-25, 7-27, 7-28	VLAN considerations 8-19
show controllers lre profile mapping 7-28	see also upgrading software releases 4-2
show controllers lre profile mapping command 7-27	Software Upgrade window 2-17
Simple Network Management Protocol	source-based forwarding 7-11
see SNMP	source-based port groups 6-61, 7-10
SLIP 6-65	SPAN 7-16
SNMP	disabling 7-16
accessing MIB variables with 4-7	enabling 7-16
community strings	ports, restrictions 9-2
configuring 6-19	Spanning Tree Protocol
switch clusters 5-10	see STP
	Spanning Tree Protocol window 2-17

spanning-tree rootguard command 6-45	configuring 6-24, 6-26
speed, setting 7-2,7-3	considerations for using STP instances 6-24
speed mode LED 2-10	disabling 6-25
Standby Command Configuration window 5-18	forwarding delay timer 6-41
standby command group	hello BPDU interval 6-40
configuring 5-5, 5-17	implementation type 6-39
priority, configuring 5-17	load sharing
standby command switches	overview 8-46
characteristics 5-3	using path costs 8-50
planning considerations 5-5	using port priorities 8-47
static-access ports	parameters 6-24
assigning to VLAN 8-10, 8-35	path cost
described 8-10	changing 6-43
VLAN membership combinations 8-8	configuring 8-50
static addresses	Port Fast
adding 6-59	enabling 6-42
configuring for EtherChannel port groups 6-61	mode 8-56
described 6-56, 6-59	port grouping parameters 7-11, 8-38
removing 6-60	port priority 6-43, 8-48
see also static address	port states 6-41
static address forwarding 6-59	redundant connectivity 6-25
static address forwarding restrictions 7-11	redundant links with UplinkFast 6-28
statistics, VTP 8-26	root guard 6-44, 6-45
statistics group, in RMON 4-6	settings 6-26, 6-27
STAT mode LED 2-10	STP implementation, changing 6-39
storm control system error messages A-11	supported number of spanning-tree instances 6-24, 8-2
STP	switch priority 6-39
behavior, unpredictable 8-11	UplinkFast 6-28, 6-30
RPDU message interval 6-40	VI AN parameters described 6-38

STP port states 6-41	switch software releases 4-2
SunNet Manager 1-8	switch-specific features in switch clusters 5-13
switch clusters	switch upgrades, troubleshooting 9-10
candidate and cluster member characteristics 5-3	system date and time 6-17 system error messages A-1
command switch characteristics 5-2 displaying inventory 5-19 displaying link information 5-20 overview 5-1 planning considerations 5-4 host names 5-10 IP addresses 5-8 LRE profiles 5-13 management VLAN 5-11 NAT commands 5-12 network port 5-12 passwords 5-8 SNMP community strings 5-10 standby command switches 5-5 switch-specific features 5-13 standby command switch characteristics 5-3 troubleshooting 9-8	chassis A-5 CMP A-5 environment A-6 GigaStack A-7 how to read A-2 link A-8 list of A-5 LRE link A-8 module A-9 port security A-9 recovery procedures A-5 RTD A-10 storm control A-11 traceback reports A-4 System LED 2-7
verifying 5-19 switch images 2-7 LEDs 2-7 polling interval 2-15 Switch Port Analyzer see SPAN switchport command 8-39	tables message severity levels A-3 variable fields A-3 tabs 2-32

TACACS+	Cluster View 2-27
AAA accounting commands 6-66	VSM 2-17
AAA authorization commands 6-65	topology, CMS 2-24
configuring 6-61	traceback reports A-4
initializing 6-64	traffic
server, creating 6-62	blocking flooded 7-6
starting accounting 6-66	forwarding, and protected ports 7-13
tacacs-server host command 6-62, 6-63	monitoring 7-16
tacacs-server retransmit command 6-63, 6-67	reducing flooded 7-4, 7-7
tacacs-server timeout command 6-63	transmit queue 8-45
Telnet	transparent mode, VTP 8-14, 8-23
access 4-4	trap managers
accessing management interfaces 3-8	adding 6-19
accessing the CLI 1-7	configuring 6-19
from a browser 3-9	traps 4-8, 6-19
TFTP server, configuring 6-7	TrBRF VLAN defaults and ranges 8-30
time	TrCRF VLAN defaults and ranges 8-31
daylight saving 6-17	troubleshooting 9-1
setting 6-17	CMS sessions 9-5
zones 6-17	switch clusters 9-8
TLV support 8-16	switch upgrades 9-10
Token Ring VLANs	with CiscoWorks2000 4-8
overview 8-27	trunk ports
TrBRF 8-16, 8-30	configuring 8-38
TrCRF 8-16, 8-31	disabling 8-40
toolbar	trunks
Cluster Builder 2-27	allowed-VLAN list 8-40
Cluster Manager 2-17	ATM 8-37
	blocking unknown packets on 8-38

configuration conflicts 8-37	upgrading software 4-1
configuring 8-39	VLAN considerations 8-19
disabling 8-40	UplinkFast
Gigabit Ethernet 8-36	configuring 6-26
IEEE 802.1Q 8-36, 8-37	enabling 6-30
interacting with other features 8-37	redundant links 6-28
ISL 8-36	URLs, Cisco xx
load sharing using	user EXEC mode 3-3
STP path costs 8-50	User Settings window 2-17
STP port priorities 8-47	
native VLAN for untagged traffic 8-43	V
overview 8-36	V
parallel 8-50	variable fields
pruning-eligible list 8-42	definition A-3
VLAN, overview 8-36	table A-3
VLAN membership combinations 8-9	version-dependent transparent mode 8-16
TTY traps 6-19	virtual IP address
	HSRP 5-5
U	standby group member 5-18
o	see also IP addresses
UDLD 7-9	Visual Switch Manager
unicast and multicast packets, unknown	see VSM
see flooding controls	VLAN
unicast traffic and protected ports 7-13	adding to database 8-33
UniDirectional Link Detection	modifying 8-34
see UDLD	port membership modes 8-7
Unrecognized Type-Length-Value	trunks, overview 8-36
see TLV support 8-16	VLAN database mode 3-3
	VLAN ID. discovering 6-45, 6-56

VLAN Management Policy Server	native, configuring 8-43
see VMPS	number supported 8-3
VLAN membership	overlapping 8-11
ATM port 8-7	overview 8-2
combinations 8-8	static-access ports 8-10, 8-34, 8-35
confirming 8-59	STP parameters, changing 6-38
modes 8-7	supported VLANs 8-3
port group parameters 7-11	Token Ring 8-27
traps 6-19	trunking 8-3
see also dynamic VLAN membership	trunks configured with other features 8-37
VLAN Membership window 2-17	see also trunks
VLAN Query Protocol	VTP database and 8-27
see VQP	VTP modes 8-14
VLANs	see also management VLAN
802.1Q considerations 8-37	VMPS
adding to database 8-33	administering 8-60
aging dynamic addresses 6-26	configuration guidelines 8-56
allowed on trunk 8-40	database configuration file example 8-54
changing 8-34	default configuration 8-57
configuration guidelines 8-28	dynamic port membership
configuring 8-1, 8-32	configuring 8-58
default configuration 8-28	example 8-61
deleting from database 8-34	overview 8-53
described 8-2	reconfirming 8-59
illustrated 8-2	troubleshooting 8-61
ISL 8-36	mapping MAC addresses to VLANs 8-52
MAC addresses 6-56	monitoring 8-60
modifying 8-34	overview 8-52
multi-VLAN ports 8-10, 8-12	reconfirmation interval, changing 8-59

reconfirming membership 8-59	described 8-12
retry count, changing 8-60	disabling 8-23
server address, entering on client 8-57	domain names 8-18
Voice over IP	domains 8-13
configuring 7-17	modes
port configuration 7-18	client 8-14
voice ports	configurations affecting mode
configuring VVID 7-20	changes 8-15
voice ports, configuring 7-17	configuring 8-22
voice traffic 7-21	server 8-14, 8-21
voice VLAN	transitions 8-14
see VVID	transparent 8-10, 8-14, 8-23
VQP 8-52	monitoring 8-26
VSM	pruning
device pop-up menu 2-19	enabling 8-25
front-panel image 2-4, 2-7	overview 8-17
home page 2-4	pruning-eligible list, changing 8-42
menu bar 2-14	statistics 8-26
overview 2-2, 2-3	Token Ring support 8-16
port pop-up menu 2-18	transparent mode, configuring 8-23
privilege level 6-16	traps 6-19
toolbar 2-17	using 8-12
toolbar icons 2-17	version, determining 8-19
VTP	version 1 8-16
advertisements 8-15	version 2
configuration guidelines 8-18	configuration guidelines 8-19
configuring 8-20	disabling 8-25
consistency checks 8-16	enabling 8-24
database 8-27, 8-32	overview 8-16
default configuration 8-20	VLAN parameters 8-27

Index

```
VVID 1-5, 7-18 configuring 7-20
```

W

```
warnings xviii
window components, CMS 2-31
buttons 2-33
host name list 2-32
lists 2-32
online help 2-33
tabs 2-32
```



Xmodem protocol 9-25