

Start FADC CODA

2 December 2010

Start CODA

FADC CODA is running on ‘hamoller’ computer under ‘moller’ account. To start CODA one can type command: `start_coda_brad` — that fires up the usual set of windows for ET, ER, EB, etc. For FADC DAQ ‘fadc_moller’ configuration is used.

FADC parameters. There is configuration file with settable parameters for FADC. File is located in directory: `~moller/crl/FADC/fadc_params.cnf` Parameters from file are loaded to FADC in ‘Prestart’ state of CODA. There is self explained list of FADC parameters from configuration file (Wed Apr 21 16:22:20 EDT 2010):

FADC settable parameters

Parameter	Value	Comment
FA_SUM_THRESH_CR	8500	Threshold on calorimeter sums (define triggers and SW scaler logic)
FA_SUM_THRESH_CL	8500	
FA_CHN_THRESH_SR	500	Threshold on individual channels. Define SW scaler logic for Scintillators only. Controls digitized data output for all channels (ie. ‘zero-suppression’)
FA_CHN_THRESH_SL	500	
FA_CHN_THRESH_CR	500	
FA_CHN_THRESH_CL	500	
FADC_PRESCALE_CL	1000	Prescale range: 1–2047
FADC_PRESCALE_CR	1000	
FADC_PRESCALE_CRL	200	
FADC_EVENTS_PER_BLOCK	20	These many DATA trigger are grouped into each DATA interrupt
FADC_PULSE_WIDTH	3	PULSE_WIDTH range is from 3–255 (3 is default)
FADC_COIN_WINDOW	2	COIN_WINDOW range is from 1–255 (2 is default)
FADC_DELAY_CL	0	Delays range: 1–255
FADC_DELAY_CR	0	
FADC_DELAY_SL_0	1	
FADC_DELAY_SL_1	1	
FADC_DELAY_SL_2	1	
FADC_DELAY_SL_3	1	
FADC_DELAY_SR_0	1	
FADC_DELAY_SR_1	1	
FADC_DELAY_SR_2	1	
FADC_DELAY_SR_3	1	
FADC_DELAY_SRL	25	This delay is for the _delay counts (random background measure)

Data stored on ‘hamoller’ computer to directory: `/data1/raw/`