

Wired remote for the **D7500's MC-DC2 terminal** (left side, under the rubber flap). 2× AAA.
Does the one thing the ML-L3 and the in-camera interval timer **cannot**: Bulb exposures longer than 30 s, repeated automatically.

NEEWER TC-2 · MC-DC2 timer remote

1 · CONNECT & DISCONNECT (ORDER MATTERS)

PLUGGING IN	UNPLUGGING
1. Camera OFF	1. Check TIMER ACTIVE + RELEASE are not showing
2. Check TIMER ACTIVE + RELEASE are not showing	2. Camera OFF
3. Open terminal cap, push plug in firmly	3. Unplug
4. Camera ON	4. Replace the cap

2 · THE FOUR TIMER VALUES

SET (SET flashes) → ←/→ pick field → ↑/↓ change value → SET confirm → **TIMER START/STOP** to run.

TAB	MEANING	RANGE
DELAY	Wait before shot 1	0 s - 99:59:59
LONG	Exposure length (camera on Bulb)	1 s - 99:59:59
INTVL	Start-to-start gap	1 s - 99:59:59
N	Number of shots	1-399, or --- = unlimited

Unlimited: at 1 press ↓, or at 399 press ↑.
Interval 00:00:00 auto-becomes 00:00:01 on SET.
TIMER ACTIVE flashes while running · press START/STOP again to abort.

3 · TWO WAYS TO SHOOT

A · Remote controls the exposure
Astro stacking, star trails, anything past 30 s.

Mode	M
Shutter	Bulb
Interval timer	OFF (it will fight the remote)
Focus	MF (or AF-C)
Release mode	S · single frame

Exposure length is set on the **remote** (LONG).

B · Camera controls the exposure
Timelapse, daylight sequences.

Mode	M or S
Shutter	Any normal speed
Interval timer	OFF
Release mode	S · single frame

On the remote: **LONG = 1 s**, **INTVL longer than the camera's shutter speed**.

4 · INTERVAL RULES — GET THESE WRONG AND IT DROPS FRAMES

- INTVL ≥ exposure + a few seconds.** Always.
- Using autofocus?** Set a **DELAY** (not 0) and leave extra INTVL headroom. AF fires ~2 s before the shutter opens — indicator goes **GREEN**, then **RED** when the shutter is open.
- Long Exposure NR ON → INTVL ≥ 2 × exposure.** The dark frame doubles capture time. For stacking: turn Long Exp NR **OFF** and shoot your own darks.

5 · MANUAL SHUTTER BUTTON (NO TIMER)

- Half-press** = focus (**GREEN**) · **full press** = fire (**RED**).
- Slide to HOLD** = shutter held down. This is your manual Bulb. Slide back to release.
- Works **with no batteries** in the remote — display and beep just won't function.
- Works **while the timer is running** too; shutter stays open until both releases finish.

6 · OTHER CONTROLS & POWER

- Backlight / Lock:** tap = backlight (~6 s; any arrow press extends it). **Hold** = lock everything except shutter + backlight. Hold again to unlock.
- Beep:** 5th tab in the SET cycle. Off for wildlife — but genuinely useful audible confirmation in the dark.
- No power button.** To save batteries, make sure **TIMER ACTIVE** / **SET** / **RELEASE** are all quiet when stowed.
- Low-battery icon flashing?** Replace *before* the session. The timer keeps running even if the camera has stopped shooting (flat EN-EL15a, full card) — you'd never know.

7 · STARTER RECIPES

JOB	DELAY	LONG	INTVL	N
Deep-sky stack 200P, MF	5 s	30 s-2 m	exp + 5 s	---
Star trails 18 mm f/3.5, ISO 800	5 s	30 s	32 s	---
Single ultra-long waterfall + ND	2 s	your call	—	1
Timelapse camera-controlled, 1/250	5 s	1 s	4 s	300

8 · TWO THINGS TO CHECK ON YOUR CAMERA

- 1 · Back-button focus (a6 = AF-ON only) means half-pressing the remote won't focus.** For astro that's irrelevant — you're on MF anyway. But an *autofocusing* interval sequence will fire every frame on whatever focus was last set. Either temporarily revert **a6** to enable half-press AF, or lock focus manually and leave it. Know this *before* you're standing in a field wondering why nothing's sharp.
- 2 · Don't combine this with Mirror-up (Mup) / EFCS.** Mup needs a *second* press to fire; the remote's timer only sends one. Your Mup + EFCS + ML-L3 anti-vibration routine is for *short* tripod exposures. At 30 s+, mirror slap is a rounding error — use **single-frame release** and don't overthink it.