

TechNova Router Support Manual

Customer Support Guide

Version 2.3 | April 2026

1. Product Overview

TechNova X1000 is a high-speed Wi-Fi 6 router designed for home and small offices. It supports up to 150 connected devices with speeds up to 9.6 Gbps.

2. Common Troubleshooting Steps

Q1. How do I reset my router?

1. Locate the Reset button at the back of the router.
2. Press and hold the button for 10 seconds using a paperclip.
3. All lights will flash. The router will restart automatically.
4. Reconfigure using the default SSID: TechNova_X1000.

Q2. Wi-Fi is not working / No internet

- Restart your router and modem.
- Check if the WAN light is solid blue.
- Try connecting via Ethernet cable.
- Update firmware from the app.

Q3. Forgot Wi-Fi Password

1. Reset the router (see Q1).
2. Default password is printed on the sticker at the bottom of the router.
3. Recommended: Change password via the TechNova mobile app.

Q4. Slow Internet Speed

- Move closer to the router.
- Reduce number of connected devices.
- Check for interference from microwaves or cordless phones.
- Run speed test in the app.

3. Warranty & Returns

Standard Warranty: 2 years from date of purchase.

Covered: Manufacturing defects, hardware failure.

Not covered: Physical damage, water damage, unauthorized repairs.

Refund: Full refund within 30 days if unopened.

4. Firmware Update

Open TechNova App → Settings → Firmware Update. Download and install the latest version. Do not unplug the router during update.

5. Contact Support

Email: support@technova.com

Phone: +91-1800-123-4567 (9 AM – 7 PM IST)

Live Chat: www.technova.com/support

WhatsApp: +91-98765-43210

Important Note

For refund, cancellation, or account-related requests, please speak directly with a human agent.