

# Nokia5110 graphical display interfacing with PIC18F4550

#### Overview of Nokia5110

Nokia5110 is a graphical display that can display text, images, and various patterns.

It has a resolution of 48x84 and comes with a backlight.


It uses SPI communication to communicate with a microcontroller.

Data and commands can be sent through a microcontroller to the display to control the display output.

It has 8 pins.

For more information about the Nokia5110 display and how to use it, refer to the topic Nokia5110 Graphical Display (http://electronicwings.com/sensors-modules/nokia5110-graphical-display) in the sensors and modules section.


For information on SPI in PIC18F4550, refer to the topic on SPI in PIC18F4550 (http://electronicwings.com/pic/pic18f4550-spi) in the PIC inside section.



Nokia 5110 LCD Module

## Connection Diagram for Nokia 5110 Display with PIC18F4550

 The following circuit diagram shows the complete interfacing of PIC18F4550 to the Nokia5110 display.



Nokia 5110 LCD Interfacing with PIC18F4550

ElectronicWings.com

### Interconnection Detail

Nokia5110 Pins	PIC18F4550 Pins	PIC18F4550 Ports/Function
RST	20	RD1
CE	7	SS
DC	19	RD0
Din	26	SDO
CLK	34	SCK
BL and VCC	11/32	VCC
GND	12/31	GND

## **Programming of Nokia5110 Display**

- In the coding first step is to include and initialize the SPI\_Header\_File.h header files.
- In the SPI\_Header\_File.h file contains all definitions of SPI.

#### Initialization of Nokia5110

- The first step is to reset the display by sending low to high pulse to the reset pin. The pulse width of a low signal should not be < 100 ms.
- Send command 0x21 to set the display in extended command mode (H=1).
- Set the voltage bias system using a 0x13 command, it is recommended for n=4 and 1:48 mux rate.
- Set the temp. coefficient. E.g. Set temperature coefficient 3 by sending 0x07H.
- Then set VOP = 5 V by sending command 0xC0H.
- Send the command 0x20 to configure the display for basic command mode (H=0)
- And then send 0x0C to operate the display in normal mode.



+ Project (/publish/project)



```
Platforms
(/explore)
```

```
Projects /*apply 100 in tests (low to high) pulse */
(/projects) RES = 0; (/pontable) eset */

MSdelay(100);

RES = 1; /* disable reset */

Nokia_SendCommand(0x21); /* use extended instruction set */

Nokia_SendCommand(0x13); /* select Bias voltage */

Nokia_SendCommand(0x07); /* set temperature coefficient */

Nokia_SendCommand(0xC0); /* set LCD Vop for contrast */

Nokia_SendCommand(0x20); /* use basic instruction set */

Nokia_SendCommand(0x0C); /* set normal mode */

}
```

#### Command write the function:

- Make DC pin low for command operation.
- Enable the slave select pin.
- · Send/write the command to the SPI data(SSPBUF) register.
- Disable the slave select pin.

```
void Nokia_SendCommand(char cmd)
{
    DC = 0;    /* Data/Command pin, D/C=1 - Data, D/C = 0 - Command*/
    CS = 0;    /* enable chip */
    SPI_Write (cmd);    /* write command to the Nokia 5110 */
    CS = 1;    /* disable chip */
}
```

#### Data write the function:

- For data, the operation makes DC pin high for data operation.
- · Enable the slave select pin.
- Send/write the data to the SPI data(SSPBUF) register.
- Disable the slave select pin after sending the data.

```
void Nokia_SendData(char dat)
{
    char i;
    DC = 1;    /* Data/Command pin, D/C=1 - Data, D/C = 0 - Command*/
    CS = 0;    /* enable chip */
    for(i=0;i<5;i++)
        SPI_Write(font[(dat) - (0x20)][i]);    /* write data to the Nokia 511
    CS = 1;    /* disable chip */
}</pre>
```

### Nokia 5110 Display Code for PIC18F4550

Display "ElectronicWings" on Nokia5110 display using PIC18F4550

(/explore)





+ Project (/publish/project)



```
* Nokia 5110 display interface with PIC18F4550
Projects Contests http://www.electronicwings.com
(/projects)
                     (/contests)
       */
      #include <pic18f4550.h>
      #include "Configuration_Header_File.h"
      #include "SPI_Header_File.h"
      #include "Nokia_Font.h"
      void Nokia_Init();
      void Nokia_SendCommand(char);
      void Nokia_SendData(char);
      void Nokia_SendString(char *);
      void MSdelay(unsigned int);
      void Nokia_Clear();
      void Nokia_PositionXY(char, char);
      #define DC LATD0
      #dofine DEC I ATD1 /* connected to recet */
```

## Image Display Function for Nokia5110

```
void Nokia_DisplayImage (const unsigned char *image)
{
    int i;
    CS = 0;
    DC = 1;
    for(i=0;i<504;i++)
    {
        SPI_Write(image[i]);
    }
    CS = 1;
}</pre>
```

## Video of Nokia5110 Display using PIC18F4550



Q

+ Project (/publish/project)



Platforms (/explore) Projects (/projects)

Contests (/contests)



## MOUSER ELECTRONICS (https://www.

mouser.in?
utm\_source=el
ectronicswing
s&utm\_mediu
m=display&ut
m\_campaign=
mousercomponentsli
sting&utm\_co
ntent=0x0)

## **Components Used**

#### Nokia5110 Graphical Display

Nokia5110 is 48x84 dot LCD display with Serial ...

X 1

(https://www.mouser.i n/ProductDetail/Olime x-Ltd/MOD-LCD3310? qs=%2Fha2pyFaduiM2 FizGGE3eTLrshD%2Fq HV%2F3UdKes06wlNlf ol%252BJ2g6%2Fw%3 D%3D&utm\_source=el ectronicswings&utm\_medium=display&utm\_campaign=mouser-componentslisting&ut m\_content=0x0)

■ Datasheet (/componen ts/nokia511 0-graphicaldisplay/1/da tasheet)







mouser.in?

(https://www.



Contests (/contests)

**Components Used** 

utm\_source=el ectronicswing s&utm\_mediu Powered By m=display&ut m\_campaign= mousercomponentsli sting&utm\_co ntent=0x0)

PIC18f4550 X 1 PIC18f4550

(https://www.mouser.i n/ProductDetail/Micro chip-Technology/PIC18F45 50-I-P? qs=oKK8NaWdAJs8nL DXBGwMXw%3D%3D& utm\_source=electronic swings&utm\_medium= display&utm\_campaig n=mousercomponentslisting&ut m\_content=0x0)

■ Datasheet (/componen ts/pic18f45 50/1/datash eet)

(https://www.mouser.i

**PICKit 4 MPLAB** X 1 PICKit 4 MPLAB

n/ProductDetail/Micro Technology/PG164140 qs=r5DSvlrkXmLKDuY NJImLWw%3D%3D&ut m\_source=electronics wings&utm\_medium=d isplay&utm\_campaign =mousercomponentslisting&ut m\_content=0x0)

■ Datasheet (/componen ts/pickit-4mplab/1/dat asheet)



+ Project (/publish/project)

:




Platforms (/explore)

Proje		Contests (/contests) PIC18F4550 Nokia5110 Text Project File	Dow (/api/download/platf nloa orm-attachment/114) d
	>_	PIC18F4550 Nokia5110 Image Project File	Dow (/api/download/platf nloa orm-attachment/115) d
	4	Datasheets	Dow (/api/download/platf nloa orm-attachment/116) d

### **Comments**



#### Comment



(/users/lokeshc/profile)
2018-06-14 20:58:47

Hi green3ggsandham
what do you want to do iwth push buttons?
Reply Like

green3ggsandham (/users/green3ggsandham/profile) 2018-06-15 17:19:36

I managed to get it all figured out! Thanks for the reply though Reply Like

green3ggsandham (/users/green3ggsandham/profile) 2018-06-16 16:55:22

Just a question about the send string function... how would I go about passing a variable to the string?

Reply Like

fernandoliozzi

(/users/fernandoliozzi/profile) 2018-09-30 22:54:29

sprintf(buffer,"Cont=%d",25);
Nokia\_SendString(buffer);



you need: #include <stdio.h>

+ Project (/publish/project)

:

:

:

:



**Platforms** (/explore)

char buffer[20]; **Projects** Reply Contests (/projects) (/contests) blarblublublar

(/users/blarblublublar/profile) 2019-05-21 23:25:04

SPI\_Write(font[(data) - (0x20)][i]);

why u subract 0x20? Reply Like 1₺

lokeshc

(/users/lokeshc/profile) 2019-06-03 17:06:21

This is to generate proper ASCII value for the requested character. You can see font.h file where array is given to generate particular font.

Reply Like 116

pkarday123

(/users/pkarday123/profile) 2019-06-03 12:07:07

PIC4550

Getting error: section '.idata\_spi.o' can not fit the section. Section '.idata\_spi.o'

length=0x000001e0

Reply Like

ChristianYonpang

(/users/ChristianYonpang/profile) 2020-07-24 18:24:51

thanks for all its realy awesome

but please how do i make the message on the screen to scroll??

Reply Like

BinitaKar :

(/users/BinitaKar/profile) 2021-10-11 10:35:51

What will be the coding of Nokia 5110 LCD Display using PIC12F675 mirocontroller?

Reply Like

About Us (/about)

**Business Offering (/business-**

services)

Host Platform (/launch-

platform)

Contact Us (/contactus)

Connect On:

Facebook(https://www.facebook.com/electronicwings)

LinkedIn(https://www.linkedin.com/company/electronicwin

Youtube(https://www.youtube.com/channel/UCNdqkukBtk4

(https://www.instagram.com/electronicwings\_collnstagram

igshid=1cip10jijttko)

Terms of Service (/terms-of-

service)

Cookies Policy (/cookie-policy)

Privacy Policy (/privacy-policy)

ElectronicWings

© 2023