## **Connection of KJ-750 TEL**



## KJ-750 Tel { Side View}

- ✓ Connect to KJ Headset with RJ-9 jack.

  Or
- ✓ Connect KJ Headset with 2.5mm jack

## KJ-750 Tel { Back View}

- √'TEL' Port Connect to Direct Line or Analog Extension
- √'EXT' Port can parallel to Single Line Telephone
- ✓ Ringer Volume Control HI/LO/ OFF (Auto Answer Mode)
- √FLASH {1(100ms)/2(300MS)/3(600MS)}

## KJ-750 Tel { Side View}

√ Headset Volume Control