

Ford F-150 2023 - Owner & Service Manual Excerpt

1. Vehicle Identification

Brand: Ford

Model: F-150

Year: 2023

Engine: 3.5L EcoBoost V6 / 5.0L Ti-VCT V8 (available)

Transmission: 10-speed Automatic

2. Pro Trailer Backup Assist

When can Pro Trailer Backup Assist be used?

This feature helps steer a trailer while reversing and requires:

- A compatible trailer with the trailer reverse steering knob calibrated to the specific trailer.
- Vehicle speed kept below approximately 5 mph (8 km/h) while the system is engaged.
- The system will disengage automatically if the driver brakes hard, exceeds the speed threshold, or shifts out of Reverse.

3. Anti-Theft Alarm System

The perimeter anti-theft alarm is triggered when, after the vehicle is locked:

- A door, hood, or tailgate is opened without unlocking via the key fob or keypad.
- The ignition is switched on with a key or fob not recognized by the SecuriLock immobilizer.
- Vehicles equipped with the interior motion sensor detect movement inside the cabin.

To disarm, unlock a door with the key fob or enter the correct code on the door keypad.

4. Towing and Payload - When Not to Tow

Do not tow a trailer exceeding the vehicle's rated maximum towing capacity for its specific configuration (engine, cab, bed length, and axle ratio).

Avoid towing when:

- The trailer brake controller has not been properly installed and calibrated for trailers requiring electric brakes.
- Total combined weight (vehicle + trailer + cargo + passengers) would exceed the Gross Combined Weight Rating (GCWR) listed on the door jamb placard.
- Tires are worn, underinflated, or rated below the load requirement for towing.

5. Climate Control Air Recirculation

Automatic air recirculation is switched off when:

- The windshield defrost setting is selected to remove interior fog or frost.
- The climate control system detects rising humidity levels that could fog the windshield.
- The driver manually presses the recirculation button to select fresh outside air.

6. Seat Heating and Cooling Precautions

Do not activate heated or cooled seats when:

- The seat cushion is wet or damp, which can cause an electrical malfunction.
- Aftermarket seat covers or thick blankets block normal airflow/heat transfer through the seat surface.
- The occupant is unable to sense excessive heat or cold due to a medical condition, without medical guidance.