

Toyota Camry 2023 - Owner & Service Manual Excerpt

1. Vehicle Identification

Brand: Toyota

Model: Camry

Year: 2023

Engine: 2.5L Dynamic Force 4-Cylinder

Transmission: 8-speed Direct Shift Automatic

2. Toyota Safety Sense - Pre-Collision System

When does the Pre-Collision System (PCS) intervene?

The Pre-Collision System uses a millimeter-wave radar and camera to detect vehicles or pedestrians ahead.

PCS will sound an alert and apply automatic braking when:

- The system determines a forward collision is imminent and the driver has not braked.
- A pedestrian is detected in the vehicle's path during daylight or well-lit night conditions.

PCS may not activate or may be delayed if the sensor is blocked by dirt, snow, or heavy rain, or if the road curves sharply.

To keep the system reliable, keep the front grille radar sensor and windshield camera area clean and undamaged.

3. Hybrid Battery & Warning Indicators (Camry Hybrid)

If the hybrid system warning light illuminates:

1. Safely stop the vehicle in a location away from traffic as soon as possible.
2. Move the Power switch to OFF, then back to ON to see if the warning clears.
3. If the warning persists, do not continue driving. Contact a Toyota dealer or roadside assistance.
4. Do not attempt to open or service the hybrid battery pack yourself; it operates at high voltage.

4. Climate Control - When Air Recirculation Switches Off

The automatic climate control system will switch out of recirculation mode automatically when:

- The defogger/defrost setting is selected to clear the windshield.
- The system detects the cabin air quality sensor (on equipped grades) reading elevated CO2 levels for an extended period.
- The engine is started from cold in low ambient temperatures, to avoid window fogging during warm-up.

5. Tire Pressure Monitoring System (TPMS)

When will the low tire pressure warning light turn on?

The TPMS warning light illuminates when one or more tires is significantly underinflated relative to the placard pressure.

Steps to resolve:

1. Check all four tires (and spare, if equipped) with a calibrated gauge when tires are cold.
2. Inflate to the pressure listed on the driver's door jamb placard, not the number on the tire sidewall.
3. After adjusting, the light may take several minutes of driving to reset automatically.
4. If the light flashes for 60-90 seconds then stays on solid, the TPMS itself may need service.

6. Seat Heating and Ventilation Precautions

When should seat heating not be used?

- Avoid using seat heating on wet or damp seats to prevent electrical short circuits.
- Do not place blankets, cushions, or infant seats over the heated seating surface while active.

Toyota Camry 2023 - Owner & Service Manual Excerpt

- Individuals with reduced sensitivity to heat or pain (due to medication, disability, or medical condition) should not use seat heating unattended.