

Hydraulic System Maintenance SOP

Overview

Maintenance guidelines for central hydraulic systems (HS-001).

Routine Checks

Check oil level daily. Normal pressure is 150-200 bar.

Seal Replacement Procedure

When pressure drops below 140 bar or oil leakage is observed, seal replacement is required. Step 1: Depressurize the system. Step 2: Disconnect the affected cylinder. Step 3: Remove the gland nut. Step 4: Replace the polyurethane seals (Part# SEAL-HYD-04). Step 5: Reassemble and bleed air from the system.

Oil Change

Hydraulic oil (ISO VG 46) must be replaced every 4000 operating hours. Take oil samples every 500 hours for contamination analysis.