FibreLink ONT-200 installation sheet

The ONT-200 connects customers to an XGS-PON line. Install it near the fiber wall outlet and a power socket.

Power supply

Use only the supplied 12 V DC power adapter. The power light is green when the ONT has power.

PON light

PON light	Meaning
Blinking green	Ranging: the ONT is searching for the OLT
Solid green	Registered at the OLT
Off	No optical signal