

WidowX AI

Base

Parts List


Parts:

- (1) WidowX AI Follower Robot Arm
- (1) WidowX AI Controller Box
- (1) Aviator to XT30(2+2) Cable
- (1) 24V 25A Power Supply
- (1) M12 X-Code 8-Pin Male to RJ45 Male Cable 1m
- (1) Base Cable Lock
- (1) WX AI Finger Pair with Silicone Fingertips
- (1) M2 Hex Key
- (1) M2.5 Hex Key
- (1) M3 Hex Key
- (1) 2mL Loctite Tube
- (1) Base Clamp Plate
- (6) M3x8mm Socket Head Bolt
- (2) M3x6mm Button Head Bolt
- (4) M5x8mm Button Head Bolt

1) Attach Arm to Base Clamp Plate

Parts:



- (1) WidowX AI Follower Robot Arm
- (1) Base Clamp Plate
- (4) M5x8mm Button Head Bolts
- (1) M3 Hex Key
- (1) 2mL Loctite Tube



2) Attach Fingers to Arm

Parts:

- (1) WidowX AI Follower Robot Arm
- (1) WX AI Finger Pair with Silicone Fingertips
- (6) M3x8mm Socket Head Bolt
- (1) M2.5 Hex Key
- (1) 2mL Loctite Tube



3) Connect Cables to Controller Box

Parts:


- (1) WidowX AI Controller Box
- (1) Aviator to XT30(2+2) Cable
- (1) 24V 25A Power Supply
- (1) M12 X-Code 8-Pin Male to RJ45 Male Cable 1m



4) Connect Cable to Arm

Parts:

- (1) WidowX AI Follower Robot Arm
- (1) Aviator to XT30(2+2) Cable
- (1) Base Cable Lock
- (2) 3x6mm Button Head Bolt
- (1) M2 Hex Key
- (1) 2mL Loctite Tube



5) Power on Controller Box

Parts:

- WidowX AI Follower Robot Arm
- WidowX AI Controller Box

With Cables attached, turn on controller and wait for the light to turn green. You are now ready to use your WidowX AI Robot Arm.

