

Yamaha SEQTRAK — Cheat Sheet

Portable groovebox with AWM2 + FM synthesis, 11-track sequencer, sampling, and Wi-Fi/Bluetooth. Rechargeable battery, built-in speaker and mic.

Top Panel Layout

Section	Controls
Drum	7 track knobs (KICK, SNARE, CLAP, HAT 1, HAT 2, PERC 1, PERC 2), 16 Drum keys (step sequencer grid)
Synth	4 track knobs (SYNTH 1, SYNTH 2, DX, SAMPLER), 7 Synth keys (chromatic scale)
Sound Design & FX	4 Sound Design knobs, Sound Design Page button, FX knob, MASTER/SINGLE switch, 3 touch sliders (FX LEVEL / HIGH PASS / REPEATER), CLEAR FX button, UNDO/REDO button
Transport & Mode	P/PLAY button, Record key, SOLO button, MUTE button, PAGE button, PROJECT button, BAR LENGTH, OCTAVE, SCALE, KEY, REC SAMPLE button
Global	[ALL] knob, VOL+/VOL- buttons, Global Meter (LED ring), Index display
Top jacks	PHONES (stereo mini), AUDIO IN (stereo mini), USB-C (power, audio, MIDI), MIDI IN/OUT (breakout cable)

Project / Track / Pattern Structure

Concept	Details
Projects	8 per device (managed via app for backup)
Tracks	11 total — 7 Drum, 3 Synth (SYNTH 1 AWM2, SYNTH 2 AWM2, DX FM), 1 SAMPLER
Patterns	Up to 6 per track
Steps	Up to 128 per pattern
Song/Scene	Chain patterns across tracks into song arrangements (via app)

Drum Tracks

Track Knob	Default Sound
KICK	Kick drum
SNARE	Snare drum
CLAP	Clap / snap
HAT 1	Closed hi-hat
HAT 2	Open hi-hat
PERC 1	Percussion 1
PERC 2	Percussion 2

Track types (OS v2.0): Press & hold a Drum track knob, then hold a Drum key 5 sec to change:

- **Drum** (key 9) — default, single sound per track, step input
- **DrumKit** (key 10) — assign 7 drum sounds to Synth keys, play chromatically
- **Synth** (key 11) — turn drum track into AWM2 synth sound, play via Synth keys

Synth Tracks

Track Knob	Engine	Polyphony
SYNTH 1	AWM2 (sample-based)	128
SYNTH 2	AWM2 (sample-based)	128
DX	FM (4 operators)	8

- Mono/Poly/Chord modes via Sound Design knob 2 on Page 1
- CHORD mode: hold [ALL] + Synth key to edit chord voicing (up to 4 notes)
- **Keyboard Input mode**: hold [ALL] + [KEY] — Drum keys become a piano keyboard

Sampling Workflow

1. Press [SAMPLER] knob to select SAMPLER track.
2. Press a **Synth key** to assign the sample slot (1–7). Selected key flashes red.
3. Press **[REC SAMPLE]** to start recording (built-in mic by default; up to 16 sec).
4. Press **[REC SAMPLE]** again to stop. Sample auto-normalizes.
5. Press the Synth key to audition.

Change source: Hold [REC SAMPLE] 2 sec + press lit Drum key to cycle: built-in mic / AUDIO IN / USB audio / resample.

Resample: Set source to resample, play patterns, press [REC SAMPLE] to capture the mix.

Cancel sampling: Hold [DELETE] + [REC SAMPLE].

Monitoring mode: Hold [REC SAMPLE] + [VOL+] to check input level on Global Meter.

Sound Design Pages

Press a **Track knob** to select a track, then use **Sound Design knobs 1–4** and **Page button** to adjust parameters.

Drum Track (Type: Drum)

Page	Knob 1	Knob 2	Knob 3	Knob 4
1	SOUND SELECT	ATTACK	DECAY	PITCH
2	PAN	VOLUME	FILTER CUTOFF	FILTER RESONANCE
3	REVERB SEND	DELAY SEND	EQ HIGH	EQ LOW

Synth Track (SYNTH 1 / 2)

Page	Knob 1	Knob 2	Knob 3	Knob 4
1	SOUND SELECT	MONO/POLY/CHORD	PAN	VOLUME
2	ATTACK	DECAY/RELEASE	FILTER CUTOFF	FILTER RESONANCE
3	REVERB SEND	DELAY SEND	EQ HIGH	EQ LOW

DX Track (FM)

Page	Knob 1	Knob 2	Knob 3	Knob 4
1	SOUND SELECT	MONO/POLY/CHORD	PAN	VOLUME
2	ALGORITHM	MOD AMOUNT	MOD FREQ	MOD FEEDBACK
3	REVERB SEND	DELAY SEND	EQ HIGH	EQ LOW

SAMPLER Track

Page	Knob 1	Knob 2	Knob 3	Knob 4
1	SOUND SELECT	START POINT	END POINT	LOOP ON/OFF
2	LOOP LENGTH	ATTACK	DECAY/RELEASE	PITCH
3	PAN	VOLUME	FILTER CUTOFF	FILTER RESONANCE

Effects Architecture

Three effect layers applied in order:

1. **Track effects** — per-track, changes with sound selection
2. **Send effects** — shared across all tracks (REVERB × 12 types, DELAY × 9 types)
3. **Master effects** — applied to final mix (85 types including FILTER, REVERB, DELAY, COMPRESSOR, DISTORTION, MODULATION, DUCKER, OTHER)

Controlling Effects

Control	Function
MASTER/SINGLE switch	MASTER = effect on all tracks, SINGLE = effect on selected track only
[FX] knob	Scroll through effect presets (85 MASTER / 85 SINGLE types in 8 categories)
[FX LEVEL] slider	Effect send level / wet-dry mix
[HIGH PASS] slider	High-pass filter cutoff (always global)
[REPEATER] slider	Beat repeat / stutter (always global)
[CLEAR FX] button	Minimize current effect level
FX Page button	Switch slider parameter pages
Mixer mode	Per-track volume, pan, reverb/delay send levels

Sequencer Operations

Action	How
Select track	Press a Track knob
Step input (Drums)	Press Drum keys to toggle steps on/off
Step input (Synth/Sampler)	Hold [PAGE] + press Synth/SAMPLER knob to enter Step mode
Real-time record	Press Record key, play Synth keys, press Record again to stop
Pattern length	Hold [PAGE] + turn Drum Track knob (1–128 steps)

Copy pattern	Hold Track knob or [ALL] + press Drum key 2 sec
Paste pattern	Hold Track knob + [PAGE] + press Drum key
Copy steps	Hold a Drum key 2 sec (Synth/Sampler tracks must be in Step mode)
Paste steps	Hold [PAGE] + press Drum key
Parameter Lock	Hold a lit Drum key + turn Sound Design knob — step lights purple
ALL knob	Turn to change all 11 track patterns simultaneously
Swing	Adjust via app or hold [ALL] + turn while in appropriate mode (OS v2.0)
BAR LENGTH	Change pattern length for Synth / SAMPLER tracks (also Drum in OS v2.0)

Key Shortcuts

Action	Result
[ALL] + [KEY]	Keyboard Input mode (Drum keys become piano)
[ALL] + [REC SAMPLE]	Toggle count-in on/off for sampling
Hold [ALL] + Synth key	Edit chord voicing (in CHORD mode)
Hold [DELETE] + [REC SAMPLE]	Cancel sampling in progress
Hold [REC SAMPLE] + [VOL+]	Monitoring mode (check input level)
Hold [MUTE] + Synth key	Mute/unmute sample on SAMPLER track
Hold [PAGE] + Track knob	Enter Step Input mode (Synth/SAMPLER)
[CLEAR FX]	Reset effect to minimum
[UNDO/REDO]	Undo/redo sound and effect parameter changes
Hold [PROJECT] + Drum key	Load project (1–8)
[SOLO]	Solo selected track

Connectivity

- **USB-C** — power (PD), audio interface (44.1 kHz / 24-bit), MIDI to host/device
- **PHONES** — stereo mini jack (mutes built-in speaker)
- **AUDIO IN** — stereo mini jack for sampling external audio
- **MIDI IN/OUT** — via included breakout cable (TRS to 5-pin DIN)
- **Bluetooth** — MIDI to/from SEQTRAK app
- **Wi-Fi** — wireless WAV sample transfer with SEQTRAK app
- **Built-in mic** — MEMS microphone
- **Built-in speaker** — 2.3 cm, 1 W

Specs at a Glance

Spec	Value
Sound engines	AWM2 (128 voices) + FM 4-op (8 voices)
Preset waveforms	800 MB (16-bit equiv), 2032 sounds

User waveform memory	500 MB
Sampler slots	7 (up to 16 sec each)
Preset sampler sounds	392
Tracks	11 (7 Drum + 3 Synth + 1 Sampler)
Patterns per track	6
Max steps per pattern	128
Projects	8
Effects	85 Master × 85 Single + 12 Reverb + 9 Delay
Sampling rate	44.1 kHz / 24-bit
Battery	Li-ion 2100 mAh, ~3–4 hrs, charge 3–5 hrs
Power	USB-C PD (5V / 1.5A+), 6W
Dimensions	343 × 97 × 38 mm
Weight	0.5 kg
App	SEQTRAK app (Mac, PC, iOS, Android)

Quick Tips

- Press a **Track knob** while stopped to audition the sound without playing a pattern.
- Turn **Sound Design knobs** while pressing them for larger/sweeping parameter changes.
- **Parameter Lock** (hold lit Drum key + turn a Sound Design knob) lets you automate filter, pitch, FX, etc. per step.
- **ALL knob** changes patterns for all 11 tracks at once — great for live remixing.
- In **Mixer mode** you can adjust per-track volume, pan, reverb/delay sends.
- **Song/Scene mode** (via app) lets you chain patterns into full arrangements.
- Use the **SEQTRAK app** for deep sound editing, visualizer, sample management, and firmware updates.
- DX track excels for FM basses, metallic percussion, and glassy pads — tweak the algorithm and modulator parameters on Page 2.
- **Chord mode**: set a Synth track to CHORD on Page 1, then hold [ALL] + a Synth key to customize which notes form the chord.
- **Keyboard Input mode** ([ALL] + [KEY]) turns the 16 Drum keys into a piano layout for melodic input.

Source: Yamaha SEQTRAK User Guide v1.20 / Quick Operation Guide, yamahasynth.com