XSR v1.5.2

Porting Guide

JUN-2007, Version 5.2





Copyright notice

Copyright © Samsung Electronics Co., Ltd

All rights reserved.

Trademarks

XSR is a trademark of Samsung Electronics Co., Ltd in Korea and other countries.

Restrictions on Use and Transfer

All software and documents of XSR are commercial. Therefore, you must install, use, redistribute, modify and purchase only in accordance with the terms of the license agreement you entered into with Samsung Electronics Co., Ltd.

All advertising materials mentioning features or use of this software must display the following acknowledgement: Technical Writing Team.

"This product includes XSR written by Samsung Electronics Co., Ltd."

Contact Information

Flash Software Group Memory Division Samsung Electronics Co., Ltd

Address: BanWol-Dong, Hwasung-City Gyeonggi-Do, Korea, 445-701

http://www.samsung.com/global/business/semiconductor/footer/Footer ContactUs.html



Preface

SEC XSR POG-001

This Document is a Porting Guide for XSR (eXtended Sector Remapper) developed by Samsung Electronics.

Purpose

This document is XSR Porting Guide. This document explains the definition, architecture, system requirement, and porting tutorial of XSR. This document also provides the features and API of each module - OAM, PAM, LLD - that a user should know well to port XSR.

Scope

This document is for Project Manager, Project Leader, Application Programmers, etc.

Definitions and Acronyms

FTL (Flash Translation	A software module which maps between logical addresses and
Layer)	physical addresses when accessing to flash memory
XSR	eXtended Sector Remapper
STL	Sector Translation Layer
BML	Block Management Layer
LLD	Low Level Device Driver
Initial bad block	Invalid blocks upon arrival from the manufacturers
Run-time bad block	Additional invalid blocks may occur during the life of NAND
	flash usage
Sector	The file system performs read/write operations in a 512-byte
	unit called sector.
Page	NAND flash memory is partitioned into fixed-sized pages. A
	page is (512+16) bytes or (2048 + 64) bytes.
Block	NAND flash memory is partitioned into fixed-sized blocks. A
	block is 16K bytes or 128K bytes.
Wear-Leveling	Wear-leveling algorithm is an algorithm for increasing lifetime
algorithm	of NAND flash memory
NAND flash device	NAND flash device is a device that contains NAND flash
	memory or NAND flash controller.
NAND flash memory	NAND-type flash memory
Deferred Check	The method that can increase time and device operation
Operation	performance. Every operation function of LLD defers the
	check routine to the next operation.
OneNAND	Samsung NAND flash device that includes NAND flash

Related Documents

- SEC, XSR v1.5.2 Part 1. Sector Translation Layer Programmer's Guide, Samsung Electronics, Co., LTD, JUN-2006

memory and NAND flash controller.

- SEC, XSR v1.5.2 Part 2. Block Management Layer Programmer's Guide, Samsung Electronics, Co., LTD, JUN-2006

History

١.					
	Version	Date	Comment	Author	Approval



0.1	JULY-05-2004	Initial version	Seungeun Lee	
0.2	JULY-09-2004	Updated version - Delete FIL; Some of FIL functionalities is shifted to BML or LLD Add a synchronous feature - Add chapater 7.5. "Byte Alignment Restriction" - Add MRead/MWrite function - Modify the figure of XSR system architecture. XSR consists of XSR Core (STL and BML), OAM, PAM, and LLD. In the previous verion, XSR has only STL and BML	Seungeun Lee	
1.0	JULY-09-2004	Released version	Seungeun Lee	Kwangyoon Lee
1.1	OCT-18-2004	Updated version - Add MErase/ EraseVerify function - Add ECC Policy	Min Young Kim Se Wook Na Seungeun Lee	
2.0	OCT-19-2004	Released version	Seungeun Lee	Kwangyoon Lee
2.1	NOV-26-2004	Updated version - Add PAM interrupt functions - Modify OAM interrupt functions and timer functions - Modify Interrupt and Timer	Min Young Kim Se Wook Na Seungeun Lee	
3.0	DEC-09-2004	XSR v1.3.1 Release	Seungeun Lee	Kwangyoon Lee
3.1	JAN-14-2005	Modify ECC Policy	Min Young Kim Se Wook Na Seungeun Lee	
4.0	JUN-24-2005	Updated version for XSR v1.4.0 - Add PAM_Memcpy - Modify ECC policy - Modify interrupt and timer	Min Young Kim Se Wook Na	Song Ho Yoon
5.0 RC5	FEB-20-2006	XSR v1.5.0 RC5 Release	Byoung Young Ahn	
5.1	APR-07-2006	XSR v1.5.1 Release	Byoung Young Ahn	
5.2	JUN-2007	XSR v1.5.2 Release	Byoung Young Ahn	



Contents

<u>1.</u>	Introduction	9
	1.1. XSR Overview	9
	1.2. XSR System Architecture	10
	1.3. XSR Features	11
<u>2.</u>	Development Environment	12
	2.1. System Requirement	12
	2.2. Directory Structure	12
<u>3.</u>	Porting Tutorial	14
	3.1. Prerequisite	14
	3.1.1. Porting Outline	14
	3.1.2. Condition Check	15
	3.2. Porting Example	16
	3.2.1. Extract XSR File	16
	3.2.2. OAM Porting	16
	3.2.3. LLD Porting	21
	3.2.4. PAM Porting	33
	3.2.5. Application Creating	37
<u>4.</u>	OAM (OS Adaptation Module)	43
	4.1. Description & Architecture	43
	4.2. API	44
	OAM_Malloc	46
	OAM_Free	47
	OAM_Memcpy	48
	OAM_Memset	50
	OAM_Memcmp	51
	OAM_Debug	53
	OAM_CreateSM	54
	OAM_DestroySM	56
	OAM_AcquireSM	58
	OAM_ReleaseSM	60
	OAM_InitInt	62
	OAM_BindInt	64
	OAM_EnableInt	66
	OAM_DisableInt	68
	OAM_ClearInt	70
	OAM_ResetTimer	72
	OAM_GetTime	74
	OAM_WaitNMSec	76
	OAM_Pa2Va	77
	OAM_Idle OAM_GetROLockFlag	79 80
5	•	
<u>5.</u>		81
	5.1. Description & Architecture 5.2. API	81
	XXX_Init	83 84
	XXX_Open	86 86
	XXX_Close	89
	XXX_GetDevInfo	91
		71



XXX_Read	96
XXX_Write	101
XXX_Erase	105
XXX_MRead	108
XXX_MWrite	116
XXX_MErase	123
XXX_EraseVerify	129
XXX_CopyBack	132
XXX_ChkInitBadBlk	140
XXX_SetRWArea	142
XXX_IOCtl	144
XXX_GetPrevOpData	150
XXX_FlushOp	153
6. PAM (Platform Adaptation Module)	155
6.1. Description & Architecture	155
6.2. API	157
PAM_Init	158
PAM_GetPAParm	159
PAM_RegLFT	162
PAM_InitInt	166
PAM_BindInt	168
PAM_EnableInt	170
PAM_DisableInt	172
PAM_ClearInt	174
PAM_Memcpy	
17111_111chicpy	176



Figures

Figure 1-1. XSR System Architecture	10
Figure 2-1. XSR and Platform Directory Structure	12
Figure 3-1. XSR Porting Flowchart	14
Figure 3-2. XSR and Platform Directory	15
Figure 3-3. XSR and Platform Directory	16
Figure 3-4. OAM Function Classification	17
Figure 3-5. Simple NAND Emulator Design	22
Figure 3-6. LLD Function Classification	23
Figure 3-7. PAM Function Classification	34
Figure 3-8. XSRHello Project Structure	40
Figure 3-9. XSRHello Project Working Screen	41
Figure 4-1. OAM in XSR System Architecture	43
Figure 5-1. LLD in XSR System Architecture	82
Figure 6-1. PAM in XSR System Architecture	156
Figure 6-2. Register LLD Address to BML	162
Figure 6-3. Define Volume and Device of BML	164



Tables

Table 2-1. System Requirement	12
Table 2-2. Component of XSR and Platform Directory	12
Table 4-1. OAM API	45
Table 5-1. LLD API	83
Table 5-2. LLDSpec in LLD.h	92
Table 5-3. LLDMEArg data structure in LLD.h	124
Table 5-4. LLDMEList data structure in LLD.h	124
Table 5-5. RndInArg data structure in XsrTypes.h	133
Table 5-6. CpBkArg data structure in XsrTypes.h	133
Table 6-1. PAM API	157



Introduction

This document is a Porting Guide of XSR (eXtended Sector Remapper). This chapter first introduces the definition, system architecture, and features of XSR.

1.1. XSR Overview

☐ Flash Memory

Flash memory is an electronically programmable nonvolatile memory. It is used in laptop computer, PDA, or cell phone as storage. It is divided into two types, NOR and NAND, according to its cell composition at manufacturing. NAND flash memory has higher capacity and is cheaper than NOR flash memory. It has many benefits and widely used as storage of portable device.

☐ NAND Flash Memory

Unlike a hard disk, a user cannot rewrite data on NAND flash memory. It means user cannot overwrite existing data on it without first executing an erase operation. A user needs to erase the current data to write new data. Additionally, erase operation is performed by a block, which is larger than other operation unit; read and write operation is performed by a page on NAND flash memory. This prolongs working time, because unrelated data must also be erased and then rewritten to complete updating.

NAND flash memory is also limited in the number of times it can be written to and then erased (erase cycles). Flash device writes data sporadically, not in its address order. Specific sector can be written more frequently and the entire flash device becomes unusable eventually. Lastly, NAND flash memory can have an initial bad block when it is manufactured and a run time bad block or bit-flipping² when it is used.

☐ XSR development background

As the above reason, a user cannot manage data on NAND flash memory like block devices³. Therefore, data management of NAND flash memory is very important issue. To cover that, Samsung Electronics develops the flash management software XSR (eXtended Sector Remapper) to use NAND flash memory as a regular block device. XSR has same functionalities with well-known FTL (Flash Translation Layer). Basically, it is a software layer or device driver, that resides between the OS file system and the NAND flash memory. XSR can be used separately and is independent of Operating system as a common component itself. It provides the OS with full block-device functionality so that NAND flash memory appears to the OS as a regular hard disk drive, while it transparently manages the flash data.

¹ Bad block is a block on which data cannot be read, written, or erased. There are two types of bad blocks: Initial bad block and Run-time bad block. Initial bad block occurs from manufacturer and runtime bad block occurs during using of NAND flash memory.

2 Bad block is a block.

Bad block is a block on which data cannot be read, written, or erased. When 1 bit error happens, XSR corrects the error itself, called bit-flipping.

Block devices include all disk drives and other mass-storage devices on the computer.



1.2. XSR System Architecture

As mentioned in chapter 1.1. XSR Overview, XSR exists between the file system and NAND flash memory. It works in conjunction with an existing Operating system or in some embedded applications.

File System **Block Device Interface** Logical Flash Address XSR Core OS Adaptation Module Sector Translation Layer Virtual Flash Address Platform Adaptation Block Management Layer Module Physical Flash Address Low Level Device Driver NAND Flash Memory

Figure 1-1 shows the system architecture of XSR.

Figure 1-1. XSR System Architecture

There is a file system at the top of the figure. Block device interface exists between the file system and XSR. Block device interface is a kind of driver layer, which provides a file system with block device services. Block device interface code is ported for each OS.

There is XSR at the middle of the figure and it consists of four parts: XSR core, OAM (OS Adaptation Module, PAM (platform adaptation module), and LLD (Low Level Device Driver). The following briefly explains each of them.

□ XSR core: XSR core is composed of two layers: STL (Sector Translation Layer) and BML (Block Management Layer). STL is a top layer of XSR. BML is below the STL. The layers specifically have different features with each other, but all they are to perform the basic functionalities of XSR as block device emulation and flash memory management. The main features of each layer are as follows.



- STL (Sector Translation Layer): translates a logical address from the file system into the virtual flash address. It internally has wear-leveling 4 during the address translation.
- BML (Block Management Layer): translates the virtual address from the upper layer into the physical address. At this time, BML does the address translation in consideration of bad block and the number of NAND device in use. BML accesses LLD⁵, which actually performs read, write, or erase operation, with the physical address.

Note

Each layer of XSR can be operated separately as a module. Thus, STL can be used with other layer, which has same functionalities with BML.

□ OAM: OAM is at the right of the figure. OAM connects XSR with the OS. OAM needs to be configured according to your OS environment to use NAND flash memory. □ PAM: PAM is below OAM. PAM connects XSR with the platform. PAM also needs to be configured according to your platform to use NAND flash memory. □ LLD: There is a low level device driver between BML and NAND flash memory. It reads, writes, or erases data on the physical sector address received from XSR and is controlled by BML.

1.3. XSR Features

The following describes the main benefits and features of XSR implementation.

☐ It emulates a block device and manages data on NAND flash memory efficiently.
☐ It extends the life span of NAND flash memory by enhancing Wear-leveling.
☐ It can be embedded in any kind of OS using NAND flash memory.
☐ It enhances data integrity by managing a bad block and performing error detection or
correction.
☐ It reduces data loss in case of sudden power failure with the advanced algorithms, and
guarantees data stability.

In the next chapter, XSR build and installation procedures are covered in detail.

⁴ Wear-leveling is an internal operation to use every block of NAND flash memory evenly through the algorithm. It extends NAND flash memory life span.

LLD is an abbreviation of Low Level Device Driver. It performs actual read/write/erase operation to NAND flash memory as a device driver.



Development Environment

This chapter describes the system requirement and the directory structure.

2.1. System Requirement

Table 2-1 shows the system requirement to install XSR and use it.

Table 2-1. System Requirement

System Requirement	
Host OS	Windows 2K/XP
Target CPU	50 mips
Source Disk Space	About 8 MB
NAND Flash Chip	Samsung NAND Chip Emulator using RAM
Target Disk Space	Minimum 50 MB

2.2. Directory Structure

Figure 2-1 shows the XSR and Platform Directory Structure. Depending on type of released package, detail structure of directories can be different from Figure 2-1.




Figure 2-1. XSR and Platform Directory Structure

Table 2-2 describes the components of XSR and Platform directory structure in Figure 2-1. The following table only refers to porting related components of XSR and Platform directory.

Table 2-2. Component of XSR and Platform Directory

Director	·y	Description
XSR		This folder is a base directory when XSR is installed.
	Core	This folder has XSR source code. (STL and BML)
	Inc	This folder has XSR header files.
	Lib	This folder has XSR libraries (STL and BML).



	LLD	This folder has LLD source code.
	MAO	This folder has OAM source code.
Platfo	rm	This folder is a base directory for platform dependent code.
	PAM	This folder has platform source code.



Porting Tutorial

This chapter describes a porting example of XSR. First of all, you should read the prerequisite and check points. Then, follow the steps of the porting example.

3.1. Prerequisite

3.1.1. Porting Outline

The procedure of the porting example is as follows.




Figure 3-1. XSR Porting Flowchart



This document shows you the process to port XSR on a PC. So, you port OAM(OS Adaptation Module) to Win32. You implement ANSI functions, and Message print functions. You do not implement the semaphore functions, because you use the single process. Also, you do not implement both interrupt functions and timer functions, because you do not use real NAND flash memory.

In porting LLD, you do not use a real device or NAND flash memory. This document shows you the process to make a simple NAND emulator including small block NAND flash memory functionality. You do not implement functions related to Deferred Check Operation.

In porting PAM, you use the simple NAND emulator that is made in implementing LLD. You implement the device and driver configuration functions

After implementing OAM, LLD and PAM, you create the application in Visual Studio and check that XSR is normally operated. Therefore, XSR porting example will be completed.

3.1.2. Condition Check

Before you start the porting example, you should check the files to use in porting. The following figure shows XSR and Platform directory structure to check.




Figure 3-2. XSR and Platform Directory

The following description only refers to porting related files in XSR and Platform directory.

```
☐ In PAM folder, there is a template file in Template folder: MyPAM.cpp
☐ In Inc folder, there are XSR library files: BML.h, LLD.h, OAM.h, PAM.h, STL.h,
XSR.h, and XsrTypes.h.
☐ In Lib folder, there is a XSR library file in Generic\VS60\Retail folder: XsrEmul.lib.
☐ In LLD folder, there are template files in Template folder: MyLLD.h and MyLLD.cpp.
☐ In OAM folder, there is a template file in Template folder: MyOAM.cpp.
```

Now, you fulfill all prerequisite for the porting example.



3.2. Porting Example

Follow the next porting example step by step.

3.2.1. Extract XSR File

At first, extract the provided XSR file.

- 1) Create a folder named as **XSR** in any location to port.
- 2) Extract **XSR_1.5.2_xxx.zip** in a newly created folder **XSR**. Then, you can see the directory structure as follows.




Figure 3-3. XSR and Platform Directory

3.2.2. OAM Porting

Among three modules (OAM, LLD, and PAM), you port OAM at first.

OAM, an OS-dependent module, links XSR to OS. In this porting example, you exercise OAM porting to Win32 because you port XSR on a PC.

In \XSR\OAM folder, there is a template file MyOAM.cpp in Template folder. This template file contains 21 functions that are classified into 6 categories as follows.






Figure 3-4. OAM Function Classification

The following explains the classification of OAM functions.

□ ANSI functions

ANSI functions are the mandatory functions that XSR library uses. You must implement these functions at all times.

> OAM_Malloc() OAM_Free() OAM_Memcpy() OAM Memset() OAM Memcmp()

☐ Message print function

Message print function is the functions to print all XSR messages, including an error or debug message. If you do not implement this function, you cannot see XSR debug messages.

OAM_Debug()

☐ Semaphore functions

The semaphore functions are the functions to protect codes or devices using XSR in multi-task or multi-process environment. For more information about the semaphore functions, refer to Chapter 오류! 참조 원본을 찾을 수 없습니다. 오류! 참조 원본을 찾을 수 없습니다..

> OAM CreateSM() OAM DestroySM() OAM AcquireSM() OAM ReleaseSM()

□ Interrupt functions

The interrupt functions are the functions for Asynchronous functionality of XSR. For more information about the interrupt, refer to Chapter 오류! 참조 원본을 찾을 수 없습니다.. 오류! 참조 원본을 찾을 수 없습니다..

OAM_InitInt() OAM_BindInt()



```
OAM EnableInt()
OAM_DisableInt()
OAM_ClearInt()
```

□ Timer functions

Timer functions are the functions to check the time flow for Asynchronous functionality of XSR or handle the time-related errors. For more information about timer, refer to Chapter 오류! 참조 원본을 찾을 수 없습니다. Timer and 오류! 참조 원본을 찾을 수 없습니다. Power-Off Recovery

```
OAM_ResetTimer()
OAM_GetTime()
OAM_WaitNMSec()
```

□ Other functions

These functions does not correspond to any category above.

```
OAM_Pa2Va()
OAM Idle()
OAM GetROLockFlag()
```

Now, port OAM to Win32.

1) Make a duplicate of the existing **Template** folder in \XSR\OAM, and name the new folder as MyOAM.

Check there is a file **MyOAM.cpp** in the newly named folder **MyOAM**.

- 2) Open the existing file MyOAM.cpp in an editor.
- 3) Add the followings to include the header files.

```
#include <windows.h>
#include <stdio.h>
#include <stdarg.h>
#include <string.h>
```

4) Add the following code in bold to implement ANSI functions.

```
VOID *
OAM Malloc(UINT32 nSize)
   return malloc(nSize);
}
VOID
OAM_Free(VOID *pMem)
   free(pMem);
}
VOID
OAM_Memcpy(VOID *pDst, VOID *pSrc, UINT32 nLen)
```



```
memcpy((void *) pDst,(void *) pSrc, nLen);
}
VOID
OAM_Memset(VOID *pDst, UINT8 nData, UINT32 nLen)
   memset((void *) pDst, (int) nData, nLen);
}
INT32
OAM_Memcmp(VOID *pCmp1, VOID *pCmp2, UINT32 nLen)
   return memcmp((void *) pCmp1, (void *) pCmp2, nLen);
```

ANSI functions are implemented to map one-to-one with the standard ANSI function. Each six functions execute the general memory operation: memory allocation, memory release, memory copy, memory set, and memory comparison. You must implement these mandatory functions.

5) Add the following code in bold to implement Message print function.

```
VOID
OAM_Debug(VOID *pFmt, ...)
   static char aStr[4096];
   va_list
                 ap;
   va_start(ap, pFmt);
   vsprintf(aStr, (char *) pFmt, ap);
   printf(aStr);
   va_end(ap);
```

Message print function prints messages on XSR. If you want to see an error or debug message of XSR, you should implement this function.

Do not modify the semaphore functions because you use a single process, not a multi-process. The current template always returns TRUE32.

```
BOOL32
OAM_CreateSM(SM32 *pHandle)
   *pHandle = 1;
   return TRUE32;
}
BOOL32
OAM_DestroySM(SM32 nHandle)
   return TRUE32;
BOOL32
```



```
OAM_AcquireSM(SM32 nHandle)
   return TRUE32;
BOOL32
OAM ReleaseSM(SM32 nHandle)
   return TRUE32;
```

For detailed information about the semaphore functions, refer to Chapter 4.2. OAM APIs. For detailed information about the semaphore functionality, refer to Chapter 오류! 참조 원본을 찾을 수 없습니다.. 오류! 참조 원본을 찾을 수 없습니다..

7) Do not modify the interrupt functions because you do not use real NAND flash memory.

```
VOID
OAM_InitInt(UINT32 nLogIntId)
VOID
OAM_BindInt(UINT32 nLogIntId, UINT32 nPhyIntId)
VOID
OAM_EnableInt(UINT32 nLogIntId, UINT32 nPhyIntId)
VOID
OAM_DisableInt(UINT32 nLogIntId, UINT32 nPhyIntId)
VOID
OAM_ClearInt(UINT32 nLogIntId, UINT32 nPhyIntId)
```

For detailed information about the interrupt functions, refer to Chapter 4.2. OAM APIs.

8) Do not modify timer functions because you do not real NAND flash memory.

```
VOID
OAM_ResetTimer(VOID)
UINT32
OAM_GetTime(VOID)
   return 0;
```



```
VOID
OAM_WaitNMSec(UINT32 nNMSec)
```

For detailed information about timer functions, refer to Chapter 4.2. OAM APIs. For detailed information about timer functionality, refer to Chapter 오류! 참조 원본을 찾을 수 없습니다. Timer and 오류! 참조 원본을 찾을 수 없습니다. Power-Off Recovery.

9) The function OAM_Pa2Va is used for the address translation: from Physical address to Virtual address. Do not modify this function, because you do not use real NAND flash memory.

```
UINT32
OAM_Pa2Va(UINT32 nPAddr)
   return nPAddr;
```

If it is needed to the address translation for accessing to hardware, you should implement this function.

10) The function OAM Idle is called when XSR is at idle time. For example, if XSR is polling on the device status, this function is called. Do not modify this function for now.

```
VOID
OAM Idle(VOID)
```

At idle, other operations can be done by implementing this function.

11) The function OAM_GetROLockFlag is called when XSR determines whether certain block is in Read-Only partition or not. If XSR finds it is in range of RO partition, this function is called. If it is necessary to regard blocks in RO partition as RW under certain condition, implement this function. Do not modify this function unless you deeply understand internal implementation of XSR. Default implementation of this function just returns TRUE.

```
BOOL32
OAM_GetROLockFlag(VOID)
{
   return TRUE32;
```

After editing MyOAM.cpp, save the file and close it.

By far, you implement an OAM file, MyOAM.cpp, operating on Win32. Next, you implement LLD files.



3.2.3. LLD Porting

XSR sends a request to a device driver LLD, and then LLD accesses to the real device. This porting example shows you the process to make a simple NAND emulator as RAM, because you do not use real NAND flash memory.

Suppose that the simple NAND emulator is as follows;

- □ pNANDArray, a general pointer variable, points to the start address of the simple NAND emulator.
- \square Supposing that using large block, so 1 page = 4 sector.
- \square 1 page = (512 * 4) bytes main array + (16 * 4) bytes spare array.
- \square 1 block = 64 pages.
- \square The total number of blocks = 1024.
- ☐ The total memory of the simple NAND emulator
 - = the number of total blocks * (the number of pages in a block * the size of a page)
 - = 1024 * (64 * (512 * 4 + 16 * 4)) bytes.




Figure 3-5. Simple NAND Emulator Design

In \XSR\LLD folder, there are two template files in Template folder: MyLLD.h and MyLLD.cpp. A template file MyLLD.cpp contains 17 functions that are classified into 6 categories.






Figure 3-6. LLD Function Classification

Now, make a simple NAND emulator and port LLD to that simple NAND emulator.

1) Make a duplicate of the existing **Template** folder in \XSR\LLD, and name the new folder as MyLLD.

Check there are two files MyLLD.cpp and MyLLD.h in the newly named folder MyLLD.

2) Open the existing file MyLLD.h in an editor and check it. Do not modify MyLLD.h and use it as it is.

```
#ifndef MY LLD H
#define __MY_LLD_H__
#ifdef __cplusplus
extern "C" {
#endif /* __cplusplus */
INT32 MyLLD_Init (VOID *pParm);
INT32 MyLLD Open (UINT32 nDev);
INT32 MyLLD_Close (UINT32 nDev);
INT32 MyLLD_ChkInitBadBlk (UINT32 nDev, UINT32 nPbn);
INT32 MyLLD_Read (UINT32 nDev, UINT32 nPsn, UINT32 nNumOfScts,
                UINT8 *pMBuf, UINT8 *pSBuf, UINT32 nFlag);
INT32 MyLLD_Write (UINT32 nDev, UINT32 nPsn, UINT32 nNumOfScts,
                 UINT8 *pMBuf, UINT8 *pSBuf, UINT32 nFlag);
INT32 MyLLD_Erase (UINT32 nDev, UINT32 nPbn, UINT32 nFlag);
INT32 MyLLD_CopyBack (UINT32 nDev, CpBkArg *pstCpArg,
                      UINT32 nFlag);
INT32 MyLLD_GetDevInfo (UINT32 nDev, LLDSpec* pstLLDDev);
INT32 MyLLD_GetPrevOpData (UINT32 nDev, UINT8 *pMBuf,
                           UINT8 *pSBuf);
INT32 MyLLD_FlushOp (UINT32 nDev);
INT32 MyLLD_SetRWArea (UINT32 nDev, UINT32 n1stUB,
                       UINT32 nNumOfUBs);
```



```
INT32 MyLLD_IOCtl (UINT32 nDev, UINT32 nCode, UINT8 *pBufI,
                 UINT32 nLenI, UINT8 *pBuf0, UINT32 nLenO,
                 UINT32 *pByteRet);
INT32 MyLLD_MWrite (UINT32 nDev, UINT32 nPsn, UINT32 nNumOfScts,
                 SGL *pstSGL, UINT8 *pSBuf,
                                          UINT32 nFlag,
                 UINT32 *pErrPsn);
INT32 MyLLD MErase (UINT32 nDev, LLDMEArg *pstMEArg,
                  UINT32 nFlaq);
INT32 MyLLD_EraseVerify (UINT32 nDev, LLDMEArg *pstMEArg,
                      UINT32 nFlag);
#ifdef __cplusplus
#endif /* __cplusplus */
#endif /* __MY_LLD_H__ */
```

If necessary, you can rename the prefix (MyLLD_) of LLD function suitable for the device. If you change the function name, save the file MyLLD.h and close it.

- Open the existing file MyLLD.cpp in an editor.
- 4) Add the following code to make a simple NAND emulator. First, define the number of blocks and the size of total blocks to use. Then, define a general pointer variable pointing to the start address of the buffer for the simple NAND emulator.

```
1024
#define NUM_BLK
#define PGS_PER_BLK
                       64
#define SCTS_PER_PG
#define SCTS_PER_BLK
                     (64 * 4)
                       (512 * 4 + 16 * 4)
#define PG_SIZE
                       (64 * PG_SIZE)
#define BLK_SIZE
UINT8 *pNANDArray;
```

NUM BLK is the number of the total blocks. It is defined as 1024.

BLK_SIZE is the size of a block. The formula to decide the size of a block is the number of pages in a block * the size of a page = 64 * (512 * 4 + 16 * 4).

pNANDArray is a general pointer variable pointing to the start address of the simple NAND emulator.

5) Add the following code in bold to implement Device initialization related functions: Init, Open and Close.

```
INT32
MyLLD_Init(VOID *pParm)
   XsrVolParm *pstParm = (XsrVolParm*)pParm;
```



```
pNANDArray = (UINT8 *)OAM Malloc(NUM BLK * BLK SIZE);
   if (pNANDArray == NULL)
      LLD_RTL_PRINT((TEXT("Memory Allocation Error!!\n")));
      return LLD INIT FAILURE;
   OAM_Memset(pNANDArray, 0xff, NUM_BLK * BLK_SIZE);
   return LLD SUCCESS;
}
INT32
MyLLD_Open(UINT32 nDev)
   return LLD_SUCCESS;
}
INT32
MyLLD_Close(UINT32 nDev)
   return LLD_SUCCESS;
```

Init initializes data structure required to the device operating. Init called first and once when the driver is loaded.

This example allocates a buffer for the simple NAND emulator calling a function OAM_Malloc, and initializes the buffer as 0xff. In general, you can implement this function suitable for real NAND device.

Open initializes the device to be used.

Do not modify the template. In general, you can implement this function that makes the real device be ready to use.

Close, in opposite to Open, unlinks XSR and the device.

Do not modify the template. In general, you can implement this function that makes the real device be released.

6) Add the following code in bold to implement Device information query function GetDevInfo.

```
INT32
MyLLD GetDevInfo(UINT32 nDev, LLDSpec* pstDevInfo)
                                 = 0xEC;
   pstDevInfo->nMCode
   pstDevInfo->nDCode
                                 = 0x11;
   pstDevInfo->nNumOfBlks
                                 = NUM_BLK;
   pstDevInfo->nPgsPerBlk
                                 = 64;
   pstDevInfo->nSctsPerPg
                                 = 4;
                                 = 20;
   pstDevInfo->nBlksInRsv
   pstDevInfo->nNumOfPlane
                                 = 1;
                                 = 0;
   pstDevInfo->nBadPos
   pstDevInfo->nLsnPos
                                 = 2;
   pstDevInfo->nEccPos
                                 = 8;
   pstDevInfo->nMEFlag
                                 = LLD_ME_NO;
```



```
pstDevInfo->nBWidth
                               = 0;
                               = 0;
pstDevInfo->aUID[ 0]
pstDevInfo->aUID[ 1]
                               = 0;
pstDevInfo->aUID[ 2]
                               = 0;
pstDevInfo->aUID[ 3]
                               = 0;
pstDevInfo->aUID[ 4]
                               = 0;
pstDevInfo->aUID[ 5]
                               = 0;
pstDevInfo->aUID[ 6]
                               = 0;
pstDevInfo->aUID[ 7]
                               = 0;
pstDevInfo->aUID[ 8]
                               = 0;
pstDevInfo->aUID[ 9]
                               = 0;
pstDevInfo->aUID[10]
                               = 0;
pstDevInfo->aUID[11]
                               = 0;
pstDevInfo->aUID[12]
                               = 0;
pstDevInfo->aUID[13]
                               = 0;
pstDevInfo->aUID[14]
                               = 0;
pstDevInfo->aUID[15]
                               = 0;
                              = 500000;
pstDevInfo->nTrTime
                              = 3500000;
pstDevInfo->nTwTime
pstDevInfo->nTeTime
                              = 20000000;
pstDevInfo->nTfTime
                              = 50;
return LLD_SUCCESS;
```

GetDevInfo returns the device information to BML.

☐ nMCode and nDCode are Device IDs. This example gives random code as 0xEC and 0x11 because you do not use a real device. □ nNumOfBlks is the number of blocks, nPgsPerBlk is the number of pages in a block, □ nSctsPerPg is the number of sectors in a page, and nBlksInRsv is the number of the reserved blocks. □ nMEFlag is a flag which indicates whether multi-block erase is supported or not. ☐ **aUID** is Unique ID of a device.

□ nTrTime is the time for page reading, nTwTime is the time for page writing, nTeTime is the time for block erasing, **nTfTime** is the time for data transmitting (512 bytes). These values are referred as XSR mapping.

This example gives random code as 0 because you do not use a real device.

These time values are the standard to calculate the performance cost for the internal algorithm. The time values should be suitable for the real operation time approximately, although it is not exactly same. The unit of the operation time is ns.

For more information about the device information to BML, refer to LLD API, XXX_GetDevInfo.

7) Add the following code in bold to implement Flash operation functions: Read, Write, Erase, MRead, MWrite, MErase and EraseVerify.



```
INT32
MyLLD_Read(UINT32 nDev, UINT32 nPsn, UINT32 nNumOfScts,
           UINT8 *pMBuf, UINT8 *pSBuf, UINT32 nFlag)
   UINT32 nBlkOff;
   UINT32 nPgOff;
   UINT32 nSctOff;
   UINT32 nPos;
   nBlkOff = nPsn / SCTS_PER_BLK;
   nPgOff = (nPsn - nBlkOff * SCTS PER BLK) / SCTS PER PG;
   nSctOff = nPsn - (nBlkOff * SCTS PER BLK + nPgOff * SCTS PER PG);
   nPos = nBlkOff * BLK_SIZE + nPgOff * PG_SIZE;
   if (pMBuf != NULL)
      PAM_Memcpy(pMBuf, pNANDArray + nPos + 512 * nSctOff,
                  512 * nNumOfScts);
   }
   if (pSBuf != NULL)
       PAM_Memcpy(pSBuf, pNANDArray + nPos + 512 * 4 + 16 * nSctOff,
                  16 * nNumOfScts);
   }
   return LLD SUCCESS;
```

Read is to read data as a unit of a sector from NAND flash memory.

The parameters nPsn and nNumOfScts read data as a unit of a sector. The number of sectors does not exceed the sector-included page because you can read/write as a unit of a page. That is, this function reads data as a unit of a page; else the argument of the function is received as a unit of a sector. So, the number of sectors is limited by the number of a page.

This example calculates the start address of memory using pNANDArray, and copies data to the using buffer. This function handles the main array and spare array separately when reading data of NAND flash memory page.

```
INT32
MyLLD_Write(UINT32 nDev, UINT32 nPsn, UINT32 nNumOfScts,
            UINT8 *pMBuf, UINT8 *pSBuf, UINT32 nFlag)
   UINT32 nIdx;
   UINT32 nSctIdx;
   UINT32 nBlkOff;
   UINT32 nPgOff;
   UINT32 nSctOff;
   UINT32 nPos;
   nBlkOff = nPsn / SCTS_PER_BLK;
   nPgOff = (nPsn - nBlkOff * SCTS_PER_BLK) / SCTS_PER_PG;
   nSctOff = nPsn - (nBlkOff * SCTS_PER_BLK + nPgOff * SCTS_PER_PG);
```



```
nPos = nBlkOff * BLK SIZE + nPgOff * PG SIZE;
if (pMBuf != NULL)
   for (nSctIdx = 0; nSctIdx < nNumOfScts ; nSctIdx++)</pre>
       for (nIdx = 0; nIdx < 512; nIdx++)
          pNANDArray[nPos + 512 * (nSctOff + nSctIdx) + nIdx]
                     &= pMBuf[512 * nSctIdx + nIdx];
       }
   }
}
if (pSBuf != NULL)
   for (nSctIdx = 0; nSctIdx < nNumOfScts ; nSctIdx++)</pre>
       for (nIdx = 0; nIdx < 16; nIdx++)
          pNANDArray[nPos + 512 * 4 + 16 * (nSctOff + nSctIdx)
                     + nIdx] &= pSBuf[16 * nSctIdx + nIdx];
       }
   }
}
return LLD_SUCCESS;
```

Write is to write data as a unit of a page or sector to NAND flash memory.

The parameters nPsn and nNumOfScts read data as a unit of a sector. The number of sectors does not exceed the sector-included page because you can read/write as a unit of a page. That is, this function writes data as a unit of a page, else the argument of the function is received as a unit of a sector. So, the number of sectors is limited by the number of a

This example calculates the start address of memory using pNANDArray, and writes data. This function always handles main array and spare array separately when it reads data of NAND flash memory page. You use an AND operator to emulate the real writing to NAND flash memory in this function.

```
INT32
MyLLD Erase(UINT32 nDev, UINT32 nPbn, UINT32 nFlag)
   OAM_Memset(pNANDArray + nPbn * BLK_SIZE, 0xff, BLK_SIZE);
   return LLD_SUCCESS;
```

Erase is to erase a block of NAND flash memory.

This example calculates the start address of memory using pNANDArray, and erases data. This example handles as a unit of a block. You fill memory buffer with 0xff. In general, you can implement this function that accesses to the real NAND device.

```
INT32
MyLLD_MRead(UINT32 nDev, UINT32 nPsn, UINT32 nNumOfScts,
```



```
SGL *pstSGL, UINT8 *pSBuf, UINT32 nFlag)
UINT32 nBlkOff;
UINT32 nPgOff;
UINT32 nSctOff;
UINT32 nPos;
UINT32 nCnt;
UINT32 nReadScts;
UINT32 nSctIdx;
UINT32 nCurPos;
nBlkOff = nPsn / SCTS_PER_BLK;
nPgOff = (nPsn - nBlkOff * SCTS_PER_BLK) / SCTS_PER_PG;
nSctOff = nPsn - (nBlkOff * SCTS_PER_BLK + nPgOff * SCTS_PER_PG);
nPos = nBlkOff * BLK_SIZE + nPgOff * PG_SIZE;
nCurPos = nPos;
nSctIdx = nSctOff;
if (pstSGL != NULL)
   for (nCnt = 0;nCnt < pstSGL->nElements;nCnt++)
   {
       nReadScts = 0;
       while (nReadScts < pstSGL->stSGLEntry[nCnt].nSectors)
       {
          PAM_Memcpy(
             pstSGL->stSGLEntry[nCnt].pBuf + 512*nReadScts,
             pNANDArray + nCurPos + 512 * nSctIdx, 512);
          nReadScts++;
          nSctIdx++;
          if (nSctIdx == 4)
              nCurPos += PG_SIZE;
              nSctIdx = 0;
       }
   }
}
if (pSBuf != NULL)
   PAM_Memcpy(pSBuf, pNANDArray + nPos + 512 * 4 + 16 * nSctOff,
              16 * nNumOfScts);
}
return LLD_SUCCESS;
```

MRead reads pages and sectors within a block boundary, while Read reads data within a page. This function can be optimized by not reading sectors one by one. But, for simplicity, the above scheme shows how to handle SGL argument.

```
TNT32
MyLLD_MWrite(UINT32 nDev, UINT32 nPsn, UINT32 nNumOfScts,
```



```
SGL *pstSGL, UINT8 *pSBuf, UINT32 nFlag,
          UINT32 *pErrPsn)
UINT32 nIdx;
UINT32 nBlkOff;
UINT32 nPgOff;
UINT32 nSctOff;
UINT32 nPos;
UINT32 nCnt;
UINT32 nWriteScts;
UINT32 nSctIdx;
UINT32 nCurPos;
UINT8 *pSrcBuf;
nBlkOff = nPsn / SCTS_PER_BLK;
nPgOff = (nPsn - nBlkOff * SCTS_PER_BLK) / SCTS_PER PG;
nSctOff = nPsn - (nBlkOff * SCTS_PER_BLK + nPgOff * SCTS_PER_PG);
nPos = nBlkOff * BLK_SIZE + nPgOff * PG_SIZE;
nCurPos = nPos;
nSctIdx = nSctOff;
if (pstSGL != NULL)
   for (nCnt = 0;nCnt < pstSGL->nElements;nCnt++)
      nWriteScts = 0;
      pSrcBuf = pstSGL->stSGLEntry[nCnt].pBuf;
      while(nWriteScts<pstSGL->stSGLEntry[nCnt].nSectors)
          for (nIdx = 0; nIdx < 512; nIdx++)
           pNANDArray[nCurPos + 512*nSctIdx + nIdx]
                      &= pSrcBuf[512*nWriteScts + nIdx];
          nWriteScts++;
          nSctIdx++;
          if (nSctIdx == 4)
             nCurPos += PG_SIZE;
             nSctIdx = 0;
          }
      }
   }
}
if (pSBuf != NULL)
   for (nSctIdx = 0; nSctIdx < nNumOfScts ; nSctIdx++)</pre>
       for (nIdx = 0; nIdx < 16; nIdx++)
         pNANDArray[nPos+512*4+16*(nSctOff+nSctIdx)+nIdx]
                 &= pSBuf[16 * nSctIdx + nIdx];
       }
   }
```



```
return LLD_SUCCESS;
```

MWrite writes pages and sectors within a block boundary, while Write writes data within a page. This function can be optimized by not writing sectors one by one. But, for simplicity, the above scheme shows how to handle SGL argument.

```
INT32
MyLLD_MErase(UINT32 nDev, LLDMEArg *pstMEArg, UINT32 nFlag)
   return LLD_SUCCESS;
```

MErase erases multiple blocks of NAND flash memory simultaneously, while Erase erases only one block of NAND flash memory. In this example, we assume that NAND emulator does not support an erase operation for multiple blocks, thus MErase is not provided.

```
INT32
MyLLD_EraseVerify(UINT32 nDev, LLDMEArg *pstMEArg, UINT32 nFlag)
{
   return LLD_SUCCESS;
```

EraseVerify verifies an erase operation whether it checks blocks are properly erased. Do not modify the template. In this example, we assume that NAND emulator does not support an erase operation for multiple blocks, thus EraseVerify is not provided.

Add the following code in bold to implement CopyBack function. CopyBack function supports a page copy functionality using the internal buffer in a NAND device.

```
INT32
MyLLD_CopyBack(UINT32 nDev, CpBkArg *pstCpArg, UINT32 nFlag)
   UINT8 aBuf[2112];
   UINT32 nIdx;
   UINT32 nBlkOff;
   UINT32 nPgOff;
   UINT32 nSctNum;
   UINT32 nOffset;
   UINT32 nPos;
   nBlkOff = pstCpArg->nSrcSn / SCTS_PER_BLK;
   nPgOff = (pstCpArg->nSrcSn - nBlkOff * SCTS_PER_BLK)
             / SCTS_PER_PG;
   nPos = nBlkOff * BLK_SIZE + nPgOff * PG_SIZE;
   PAM_Memcpy(aBuf, pNANDArray + nPos, 2112);
   for (nIdx = 0; nIdx < pstCpArg->nRndInCnt; nIdx++)
```



```
nSctNum = pstCpArg->pstRndInArg[nIdx].nOffset / 1024;
   nOffset = pstCpArg->pstRndInArg[nIdx].nOffset % 1024;
   if (nOffset < 512)
      PAM_Memcpy(aBuf + 512 * nSctNum + nOffset,
               pstCpArg->pstRndInArg[nIdx].pBuf,
               pstCpArg->pstRndInArg[nIdx].nNumOfBytes);
   }
   else
      PAM_Memcpy(aBuf + 512 * 4 + 16 * nSctNum + nOffset,
               pstCpArg->pstRndInArg[nIdx].pBuf,
               pstCpArg->pstRndInArg[nIdx].nNumOfBytes);
   }
}
nBlkOff = pstCpArg->nDstSn / SCTS_PER_BLK;
nPgOff = (pstCpArg->nDstSn - nBlkOff * SCTS_PER_BLK)
         / SCTS_PER_PG;
nPos = nBlkOff * BLK_SIZE + nPgOff * PG_SIZE;
for (nIdx = 0; nIdx < 2112; nIdx++)
{
   pNANDArray[nPos + nIdx] &= aBuf[nIdx];
}
return LLD_SUCCESS;
```

Reference

CopyBack means the operation method to copy pages using the internal buffer in a NAND device.

This copyback method improves the performance by cutting the transfer time and operation procedure, because this method does not use the external memory. When copying a page using the copyback method, a part of data can be brought the outside device; this is called Random-in.

To implement CopyBack function, you must understand a CpBkArq structure. For more information about CpBkArg, refer to LLD function XXX_CopyBack.

Do not modify ChkInitBadBlk, SetRWArea, and IOCtl functions, because you use the simple NAND emulator.

```
INT32
MyLLD ChkInitBadBlk(UINT32 nDev, UINT32 nPbn)
{
   return LLD_INIT_GOODBLOCK;
}
TNT32
MyLLD_SetRWArea(UINT32 nDev, UINT32 n1stUB, UINT32 nNumOfUBs)
   return LLD_SUCCESS;
```



```
INT32
MyLLD_IOCtl(UINT32 nDev, UINT32 nCode, UINT8 *pBufl,
            UINT32 nLenI, UINT8 *pBufO, UINT32 nLenO,
           UINT32 *pByteRet)
   return LLD SUCCESS;
```

ChkInitBadBlk is to check whether a block is an initial bad block or not.

If the value of the bad mark position in the first or second page of a block is not 0xff(a normal statement), the block is the initial bad block.

This function is implemented to read the first or second page of a block and check it bad or not. In general, you implement this function using Read function in real NAND device.

SetRWArea is used when NAND device supports the hardware write protection.

10) Do not modify Deferred Check Operation functions. The current template always returns LLD_SUCCESS.

```
INT32
MyLLD_GetPrevOpData(UINT32 nDev, UINT8 *pMBuf, UINT8 *pSBuf)
{
   return LLD SUCCESS;
}
INT32
MyLLD_FlushOp(UINT32 nDev)
   return LLD_SUCCESS;
```

For detailed information about the function related to Deferred Check Operation, refer to Chapter 5.2. LLD APIs. For detailed information about the functionality of Deferred Check Operation, refer to Chapter 오류! 참조 원본을 찾을 수 없습니다.. 오류! 참조 원본을 찾을 수 없습니다..

After editing MyLLD.cpp, save the file and close it.

By far, you make a simple NAND emulator and port the device driver file MyLLD.cpp operating to the simple NAND emulator. Next, you implement a PAM file.

3.2.4. PAM Porting

PAM, a platform-dependent module, links XSR to the platform. This document shows you the process to port OAM to Win32 and port LLD by making a simple NAND emulator. You implement PAM based on that porting environment.

In \Platform\PAM directory, there is a template file MyPAM.cpp in Template folder. This template file contains 9 functions as follows.






Figure 3-7. PAM Function Classification

Now, port PAM to the simple NAND emulator made by LLD.

1) Make a duplicate of the existing **Template** folder in \Platform\PAM, and name the new folder as MyPAM.

Check that there is a file MyPAM.cpp in the newly named folder MyPAM.

- 2) Open the existing file MyPAM.cpp in an editor.
- 3) Update the path of a LLD header file as follows.

```
□ Before Modification
#include "../../XSR/LLD/Template/MyLLD.h"
☐ After Modification
```

```
#include "../../XSR/LLD/MyLLD/MyLLD.h"
```

Depending on the type of the released package, the proper path of LLD header files can be different from above.

4) Do not modify initialization functions because you do not real NAND flash memory.

```
VOID
PAM_Init(VOID)
```

5) Add the following code in bold to implement a function ReqLFT, which registers LLD to XSR.

```
VOID
PAM_RegLFT(VOID *pstFunc)
   LowFuncTbl *pstLFT;
   pstLFT
                               = (LowFuncTbl*)pstFunc;
```



```
pstLFT[0].Init
                               = MyLLD Init;
                              = MyLLD_Open;
pstLFT[0].Open
                              = MyLLD_Close;
pstLFT[0].Close
                               = MyLLD_Read;
pstLFT[0].Read
                               = MyLLD_Write;
pstLFT[0].Write
                              = MyLLD_CopyBack;
pstLFT[0].CopyBack
                               = MyLLD_Erase;
pstLFT[0].Erase
pstLFT[0].GetDevInfo = MyLLD_GetDevInfo;
pstLFT[0].ChkInitBadBlk = MyLLD_ChkInitBadBlk;
pstLFT[0].FlushOp = MyLLD_FlushOp;
pstLFT[0].SetRWArea = MyLLD_SetRWArea;
pstLFT[0].GetPrevOpData = MyLLD_GetPrevOpData;
pstLFT[0].IOCtl
                               = MyLLD IOCtl;
                              = MyLLD_MRead;
pstLFT[0].MRead
                      _ MRead;
= MyLLD_MWrite;
- --
pstLFT[0].MWrite
                              = MyLLD_MErase;
pstLFT[0].MErase
pstlfT[0].EraseVerify = MyLLD_EraseVerify;
```

RegLFT registers LLD to BML.

If you change LLD function name in MyLLD.cpp and MyLLD h, you must rename LLD function name in this function.

6) Add the following code in bold to implement a function GetPAParm, which configures the platform and device.

```
#define
            VOL0
#define
            VOL1
#define
           DEV0
#define
          DEV1
                    1
#define DEV2
                    2
#define DEV3
VOID*
PAM_GetPAParm(VOID)
    gstParm[VOL0].nBaseAddr[DEV0] = 0x20000000;
    gstParm[VOL0].nBaseAddr[DEV1] = NOT_MAPPED;
    gstParm[VOL0].nBaseAddr[DEV2] = NOT_MAPPED;
    gstParm[VOL0].nBaseAddr[DEV3] = NOT_MAPPED;
   gstParm[VOL0].nLectro1 = SW_ECC;
gstParm[VOL0].nLSchemePol = SW_LOCK_SCHEME;
gstParm[VOL0].bByteAlign = FALSE32;
gstParm[VOL0].nDevsInVol = 1;
    gstParm[VOL0].pExInfo
                                         = NULL;
    return (VOID *) gstParm;
```

GetPAParm returns the information to XSR and LLD.

This example only implements [VOL0] and [DEV0] because this example uses only one device. The value NOT MAPPED means that the device is not used for that device slot. In



this example, only [DEV0] is used.

[VOL0] has the following functionalities: it uses software ECC, it uses the software lock scheme, and it does not use byte aligning. In general, you must implement the total setting about nBaseAddr[] as many as the device number per a volume.

7) Do not modify the interrupt functions because you do not use real NAND flash memory.

```
VOID
PAM_InitInt(UINT32 nLogIntId)
VOID
PAM_BindInt(UINT32 nLogIntId)
VOID
PAM EnableInt(UINT32 nLogIntId)
}
VOID
PAM_DisableInt(UINT32 nLogIntId)
VOID
PAM_ClearInt(UINT32 nLogIntId)
```

For detailed information about the interrupt functionality, refer to Chapter 오류! 참조 원본을 찾을 수 없습니다.. 오류! 참조 원본을 찾을 수 없습니다..

8) Do not modify the memory copy function because you do not use real NAND flash memory.

```
VOID
PAM_Memcpy(VOID *pDst, VOID *pSrc, UINT32 nLen)
   OAM_Memcpy(pDst, pSrc, nLen);
```

PAM_Memopy copies data from source to destination using system supported function. In this porting example, PAM_Memcpy just calls OAM_Memcpy because you do not use real platform.

After editing MyPAM.cpp, save the file and close it.

By far, you implement MyPAM.cpp. You implement all required porting files, so create the application to execute XSR.



3.2.5. Application Creating

Now, create the application using the implemented files and test that XSR operates well.

1) To make a main file of the project, add the following code in an editor and name it as XSRHello.cpp in XSR folder.

```
#include <XSR.h>
#include <stdio.h>
#define NUM OF VOLS 2
#define VOL0
#define VOL1
                   1
UINT8 aRWBuf[512];
INT32
SeqWrite(UINT32 nTotalLogScts)
   UINT32
               nIdx;
               nIdx2;
   UINT32
   INT32
               nErr;
   printf(" ");
   for (nIdx = 0; nIdx < nTotalLogScts; nIdx++)</pre>
      for (nIdx2 = 0; nIdx2 < 512; nIdx2++)
      {
         aRWBuf[nIdx2] = (UINT8)(nIdx + nIdx2);
      nErr = STL_Write(VOL0 , PARTITION_ID_FILESYSTEM,
                      nIdx, 1, aRWBuf);
      if (nErr != STL_SUCCESS) break;
   printf("\b\b\b\b\b\b\b\b");
   return nErr;
}
INT32
SeqVerify(UINT32 nTotalLogScts)
              nIdx;
   UTNT32
   UINT32
              nIdx2;
   INT32
              nErr;
   for (nIdx = 0; nIdx < nTotalLogScts; nIdx++)</pre>
      nErr = STL_Read(VOL0 , PARTITION_ID_FILESYSTEM,
                     nIdx, 1, aRWBuf);
      if (nErr != STL_SUCCESS) break;
      for (nIdx2 = 0; nIdx2 < 512; nIdx2++)
         if (aRWBuf[nIdx2] != (UINT8)(nIdx + nIdx2)) break;
```



```
if (nIdx2 < 512)
          nErr = 1;
          break;
   return nErr;
}
VOID
main(VOID)
   STLInfo stSTLinfo;
   STLConfig
               stSTLconfig;
   XSRPartI stPart[NUM_OF_VOLS];
           nErr;
   INT32
           nTotalLogScts;
   UINT32
   UINT32 nIdx;
   printf("### Hello XSR ###\r\n");
   do
   {
      STL_Init();
      OAM_Memcpy(&stPart[VOL0].aSig, "XSRPARTI",
                   BML MAX PART SIG);
      stPart[VOL0].nVer
                                           = 0 \times 00010000;
      stPart[VOL0].nNumOfPartEntry
                                           = 1;
      stPart[VOL0].stPEntry[0].nID
                                 PARTITION_ID_FILESYSTEM;
                                         = BML_PI_ATTR_RW;
      stPart[VOL0].stPEntry[0].nAttr
      stPart[VOL0].stPEntry[0].n1stVbn
                                          = 0;
      stPart[VOL0].stPEntry[0].nNumOfBlks = 100;
      nErr = BML_Format(VOL0, &stPart[VOL0],
                        BML_INIT_FORMAT);
      if (nErr != BML_SUCCESS)
         printf("[:ERR] BML_Format() returns ERROR : %x\r\n",
                                                     nErr);
         break;
      }
                                   = 100;
      stSTLconfig.nFillFactor
      stSTLconfig.nNumOfRsvUnits
                                   = 2;
                                   = 1;
      stSTLconfig.nBlksPerUnit
      stSTLconfig.nSnapshots
                                    = 4;
      nErr = STL_Format(VOL0, PARTITION_ID_FILESYSTEM,
                        &stSTLconfig , 0);
      if (nErr != STL_SUCCESS)
         printf("[:ERR] STL_Format() returns ERROR : %x\r\n",
```



```
nErr);
      break;
   stSTLinfo.nSamBufFactor = 100;
   stSTLinfo.bASyncMode
                                 = FALSE32;
   nErr = STL_Open(VOL0, PARTITION_ID_FILESYSTEM,
                   &stSTLinfo);
   if (nErr != STL_SUCCESS)
      printf("[:ERR] STL_Open() returns ERROR : %x\r\n",
             nErr);
      break;
   }
   nTotalLogScts = stSTLinfo.nTotalLogScts;
   printf("* Simple Test()\r\n");
   for (nIdx = 0; nIdx < 10; nIdx++)
      printf("\t(%2d) Write : ", nIdx + 1);
      if (SeqWrite(nTotalLogScts) == STL_SUCCESS)
          printf("OK\r\n");
      }
      else
       {
          printf("ERROR\r\n");
          break;
      }
      printf("\t
                    Verify: ", nIdx + 1);
      if (SeqVerify(nTotalLogScts) == STL_SUCCESS)
          printf("OK\r\n");
      }
      else
          printf("ERROR\r\n");
          break;
} while (0);
STL_Close(VOL0, PARTITION_ID_FILESYSTEM);
printf("### Bye XSR ###\r\n");
```

- Execute Visual Studio, and create a new Win32 Console project. This is an example to name the new project as **XSRHello.**
- 3) Include the following files in the new project **XSRHello**. Then, you can see the project structure as the following figure.



```
☐ XSR\XSRHello.cpp
☐ XSR\OAM\MyOAM\MyOAM.cpp
☐ XSR\LLD\MyLLD\MyLLD.cpp
                MyLLD.h
☐ XSR\Inc\BML.h
          LLD.h
          OAM.h
          PAM.h
          STL.h
          XSR.h
          XsrTypes.h
☐ XSR\lib\Generic\VS60\Retail\XSREmul.lib
☐ Platform\PAM\MyPAM\MyPAM.cpp
```




Figure 3-8. XSRHello Project Structure

- On **Project** menu, click **Setting**, and then **Project Setting** pop-up window is opened. On **Project Setting** pop-up window, set as follows.
 - ☐ On C/C++ tap, click General in Category list. Add ", OAM_RTLMSG_ENABLE" in Preprocessor definitions text box.

Reference

```
If you declare OAM_RTLMSG_ENABLE, XSR_RTL_PRINT() function is linked to
OAM_Debug() function.
If you declare OAM_DBGMSG_ENABLE, XSR_DBG_PRINT() function is linked to
OAM_Debug() function.
```



☐ On C/C++ tap, click **Preprocessor** in **Category** list. Add "../../inc" in **Additional include directories** text box.

Now, all preparation for executing XSRHello project is done.

5) Click **Execute XSRHello.cpp** on Build menu, or press **Ctrl** + **F5** key, or click button on menu toolbar. Then, the project is executed.

The project is compiled and built if there is no error, and the project is performed. The command window is opened, so you can XSRHello project is working.

```
### Hello XSR ###
* Simple Test()
       ( 1) Write : OK
           Verify: OK
       ( 2) Write : OK
           Verify : OK
       ( 3) Write : OK
           Verify: OK
       ( 4) Write : OK
           Verify : OK
       ( 5) Write : OK
           Verify : OK
       ( 6) Write : OK
           Verify : OK
       ( 7) Write : OK
           Verify : OK
       ( 8) Write : OK
           Verify : OK
       ( 9) Write : OK
           Verify : OK
       (10) Write : OK
           Verify : OK
### Bye XSR ###
Press any key to continue
```

Figure 3-9. XSRHello Project Working Screen

XSRHello project working process is as follows;

- 1. First, call STL_Init,
- 2. Format BML
- 3. Format STL
- 4. Open STL,
- **5.** Then, repeat Sequential Write and Sequential Verify 10 times.

Remark

The preceding API calling sequence is for the NAND device that is called for the first time. BML_Format() should be called just one time to initialize NAND device. And STL_Format() should be called for each RW partitions. If BML_Format() and STL_Format() are called for the NAND device before, STL_Init() and



STL_Open() are enough to next opening the NAND device.

Reference

Sequential Write means writing data from the sector 0 to the last as many as defined

Sequential Verify means verifying the written data from the sector 0 to the last as many as defined sequentially.

Once all working is finished, it shows "### Bye XSR ###". Press any key to close XSRHello command window.

You follow XSR porting example and execute it. Now, you can port XSR in various environments by implementing OAM, LLD and PAM.



OAM (OS Adaptation Module)

This chapter describes the definition, system architecture, features, and APIs of OAM.

4.1. Description & Architecture

OAM is an abbreviation of OS Adaptation Module. OAM is to receive the services that OS provides. OAM is responsible for OS-dependent part of XSR layers (STL and BML). If OS is changed, a user only changes OAM.

For example, a layer of XSR wants to write memory. The memory request service is dependent on OS. Each layer calls an adaptation module OAM to use OS functionalities. Therefore a user must implement OAM suitable for the OS when a user ports XSR.

File System **Block Device Interface** Logical Flash Address **XSR** Core OS Adaptation Module Sector Translation Layer Virtual Flash Address Platform Adaptation Block Management Layer Module Physical Flash Address Low Level Device Driver NAND Flash Memory

Figure 4-1 shows OAM in XSR system architecture.

Figure 4-1. OAM in XSR System Architecture

OAM has 21 functions that are classified into 6 categories as follows.

□ ANSI functions: memory allocation, memory free, memory copy, memory setting, and memory comparison

☐ Message print function : message print



☐ Semaphore functions: semaphore creation, semaphore destroy, semaphore acquire, and semaphore release
☐ Interrupt functions: interrupt initialization, interrupt bind, interrupt enable, interrupt disable, and interrupt clear
\square Timer functions : timer setting, timer return, and time waiting
\square Other functions: address translation, idle operation, RO partition check
In the next chapter, OAM APIs are covered in detail.

4.2. API

This chapter describes OAM APIs. .

Reference

All the OAM function has a prefix "OAM_" on each function name.



Table 4-1 shows the lists of OAM APIs.

The right row in table shows that the function is M and atory or Optional or R ecommended. Optional functions should be existed, but contents of the functions does not need to be implemented.

Table 4-1. OAM API

Function	Description	
OAM_Malloc	This function allocates memory for XSR.	M
OAM_Free	This function frees memory that XSR allocates.	M
OAM_Memcpy	This function copies from the source data to the	M
	destination data.	
OAM_Memset	This function sets data of a specific buffer.	M
OAM_Memcmp	This function compares data of two buffers.	M
OAM_Debug	This function is called when XSR prints message.	R
OAM_CreateSM	This function creates the semaphore.	O
OAM_DestroySM	This function destroys the semaphore.	0
OAM_AcquireSM	This function acquires the semaphore.	О
OAM_ReleaseSM	This function releases the semaphore.	О
OAM_InitInt	This function initializes the specified logical interrupt	О
	for NAND device.	
OAM_BindInt	This function binds the specified interrupt for NAND	O
	device.	
OAM_EnableInt	This function enables the specified interrupt for NAND	O
	device.	
OAM_DisableInt	This function disables the specified interrupt for	O
	NAND device.	
OAM_ClearInt	This function clears the specified interrupt for NAND	O
	device.	
OAM_ResetTimer	This function resets timer.	O
OAM_GetTime	This function returns the current time value.	O
OAM_WaitNMSec	This function is called for delaying as a unit of	R
	milliseconds.	
OAM_Pa2Va	This function is called for the address translation to	R
	access to the hardware from the system using virtual	
	memory.	
OAM_Idle	This function is called at idle time.	0
OAM_GetROLockFlag	This function is called when XSR determines whether	0
	Partition is RO or not.	



OAM Malloc

DESCRIPTION

This function allocates memory for XSR.

SYNTAX

```
VOID *
OAM_MallocC(UINT32 nSize)
```

PARAMETERS

Parameter	Type	In/Out	Description
nSize	UINT32	In	Size to be allocated

RETURN VALUE

Return Value	Description
VOID	allocated memory buffer pointer
	If this function fails, the return value is NULL.

REMARKS

This function is a mandatory ANSI function. ANSI function is implemented to map one-to-one with the standard ANSI function.

This function is called by the function that wants to use memory.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   UINT8 *MainBuf = (UINT8 *)OAM_Malloc(512);
   OAM_Free(MainBuf);
```

(2) Example to implement the function in Symbian

```
void *
OAM_Malloc(UINT32 nSize)
   return Kern::Alloc(nSize);
```

SEE ALSO

OAM_Free



OAM Free

DESCRIPTION

This function frees memory that XSR allocates.

SYNTAX

```
VOID
OAM_Free(VOID *pMem)
```

PARAMETERS

Parameter	Type	In/Out	Description
pMem	VOID *	In	Pointer to be free

RETURN VALUE

None

REMARKS

This function is a mandatory ANSI function. ANSI function is implemented to map one-to-one with the standard ANSI function.

This function is called by the function that wants to free memory.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   UINT8 *MainBuf = (UINT8 *)OAM_Malloc(512);
   OAM_Free(MainBuf);
```

(2) Example to implement the function in Symbian

```
VOID
OAM_Free(VOID *pMem)
   Kern::Free(pMem);
   return ;
```

SEE ALSO

OAM_Malloc



OAM Memcpy

DESCRIPTION

This function copies from the source data to the destination data.

SYNTAX

```
VOID
OAM_Memcpy(VOID *pDst, VOID *pSrc, UINT32 nLen)
```

PARAMETERS

Parameter	Type	In/Out	Description
pDst	VOID *	Out	Array Pointer of destination data to be copied
pSrc	VOID *	In	Array Pointer of source data to be copied
nLen	UINT32	In	Length to be copied

RETURN VALUE

None

REMARKS

This function is a mandatory ANSI function. ANSI function is implemented to map one-to-one with the standard ANSI function.

This function is called by the function that wants to copy data in the source buffer to data in the destination buffer.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   UINT8 *SrcBuf = (UINT8 *)OAM_Malloc(512);
   UINT8 *DstBuf = (UINT8 *)OAM_Malloc(512);
   OAM_Memcpy(DstBuf, SrcBuf, (512));
```

(2) Example to implement the function in Symbian

```
OAM_Memcpy(VOID *pDst, VOID *pSrc, UINT32 nLen)
   memcpy((TAny*)(pDst), (const TAny*)(pSrc),
          (unsigned int)nLen);
```

SEE ALSO

OAM_Memset, OAM_Memcmp





OAM Memset

DESCRIPTION

This function sets data of a specific buffer.

SYNTAX

```
VOID
OAM_Memset(VOID *pDst, UINT8 nV, UINT32 nLen)
```

PARAMETERS

Parameter	Type	In/Out	Description
pDst	VOID *	Out	Array Pointer of destination data to be copied
nV	UINT8	In	Value to be set
nLen	UINT32	In	Length to be set

RETURN VALUE

None

REMARKS

This function is a mandatory ANSI function. ANSI function is implemented to map one-to-one with the standard ANSI function.

This function is called by the function that wants to set the source buffer's own data.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   UINT8 *pBuf = (UINT8 *)OAM_Malloc(512);
   OAM_Memset(pBuf, 0xFF, (512));
```

(2) Example to implement the function in Symbian

```
VOID
OAM_Memset(VOID *pSrc, UINT8 nV, UINT32 nLen)
   memset((TAny*)(pSrc),(TInt)(nV), (unsigned int)(nLen));
```

SEE ALSO

OAM_Memcpy, OAM_Memcmp



OAM Memcmp

DESCRIPTION

This function compares data of two buffers.

SYNTAX

```
INT32
OAM_Memcmp(VOID *pBuf1, VOID *pBuf2, UINT32 nLen)
```

PARAMETERS

Parameter	Type	In/Out	Description
pBuf1	VOID *	In	Pointer of Buffer1
pBuf2	VOID *	In	Pointer of Buffer2
nLen	UINT32	In	Length to be compared

RETURN VALUE

Return Value	Description
Negative number	When pBuf1 is smaller than pBuf2.
0	When pBuf1 is the same as pBuf2.
Positive number	When pBuf1 is bigger than pBuf2.

REMARKS

This function is a mandatory ANSI function. ANSI function is implemented to map one-to-one with the standard ANSI function.

This function is called by the function that wants to compare data of two buffers.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   UINT8 Re;
   UINT8 *pBuf1 = (UINT8 *)OAM_Malloc(512);
   UINT8 *pBuf2 = (UINT8 *)OAM_Malloc(512);
   Re = OAM_Memcmp(pBuf1, pBuf2);
   if (Re != 0)
      printf(" Compare fail(%x)\n", Re);
```

(2) Example to implement the function in Symbian

```
INT32
```



```
OAM_Memcmp(VOID *pSrc, VOID *pDst, UINT32 nLen)
   INT8 *pS1 = (UINT8 *)pSrc;
   INT8 *pD1 = (UINT8 *)pDst;
   while (nLen--)
      if (*pS1 != *pD1)
         return (*pS1 - *pD1);
      pS1++;
      pD1++;
   return 0;
```

SEE ALSO

OAM_Memcpy, OAM_Memset



OAM Debug

DESCRIPTION

This function is called when XSR prints messages such as error or debug or etc.

SYNTAX

```
VOID
OAM_Debug(VOID *pFmt, ...)
```

PARAMETERS

Parameter	Type	In/Out	Description
pFmt	VOID *	In	Data to be printed

RETURN VALUE

None

REMARKS

This function is recommended.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   OAM_Debug("Print debug message");
```

(2) Example to implement the fuinction in Win32

```
VOID
OAM_Debug(VOID *pFmt, ...)
   static char aStr[4096];
   va_list ap;
   va_start(ap, pFmt);
   vsprintf(aStr, (char *) pFmt, ap);
   printf(aStr);
   va_end(ap);
```

SEE ALSO



OAM CreateSM

DESCRIPTION

This function creates the semaphore.

SYNTAX

```
BOOL32
OAM_CreateSM(SM32 *pHandle)
```

PARAMETERS

Parameter	Type	In/Out	Description
pHandle	SM32 *	Out	Handle of the semaphore to be created

RETURN VALUE

Return Value	Description
TRUE32	If this function creates the semaphore successfully, it
	returns TRUE 32.
FALSE32	Else it returns FALSE32.

REMARKS

This function is an optional semaphore function.

This function is called by the function that wants to create the semaphore.

XSR regards the number of the semaphore token as 0 after calling OAM_CreateSM(). Thus, when a user implements OAM_CreateSM(), a user should set the initial value of the semaphore token as 0.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   SM32
              nSm;
   if (OAM_CreateSM (&(nSm)) == FALSE32)
      FVM_DBG_PRINT((TEXT("OAM_CreateSM Error\r\n")));
```

(2) Example to implement the function in pSOS

```
BOOL32
OAM_CreateSM(SM32 *pHandle)
   BOOL32 bRet = TRUE32;
```



```
if (sm_create("XSRS",
                  SM_LOCAL | SM_FIFO | SM_UNBOUNDED,
(ULONG *)pHandle) != 0)
    bRet = FALSE32;
return bRet;
```

SEE ALSO

OAM_DestroySM, OAM_AcquireSM, OAM_ReleaseSM



OAM DestroySM

DESCRIPTION

This function destroys the semaphore.

SYNTAX

```
BOOL32
OAM_DestroySM(SM32 nHandle)
```

PARAMETERS

Parameter	Type	In/Out	Description
nHandle	SM32	In	Handle of the semaphore to be destroyed

RETURN VALUE

Return Value	Description
TRUE32	If this function destroys the semaphore successfully, it
	returns TRUE32.
FALSE32	Else it returns FALSE32.

REMARKS

This function is an optional semaphore function.

This function is called by the function that wants to destroy the semaphore.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   SM32
              nSm;
   if (OAM\_CreateSM (&(nSm)) == FALSE32)
      FVM_DBG_PRINT((TEXT("OAM_CreateSM Error\r\n")));
   OAM_DestroySM(nSm);
```

(2) Example to implement the function in pSOS

```
BOOL32
OAM_DestroySM(SM32 nHandle)
   BOOL32 bRet = TRUE32;
   if (sm_delete(nHandle) != 0)
```



```
bRet = FALSE32;
return bRet;
```

SEE ALSO

OAM_CreateSM, OAM_AcquireSM, OAM_ReleaseSM



OAM_AcquireSM

DESCRIPTION

This function acquires the semaphore.

SYNTAX

```
BOOL32
OAM_AcquireSM(SM32 nHandle)
```

PARAMETERS

Parameter	Type	In/Out	Description
nHandle	SM32	In	Handle of the semaphore to be acquired

RETURN VALUE

Return Value	Description
TRUE32	If this function acquires the semaphore successfully, it
	returns TRUE 32.
FALSE3	Else it returns FALSE32.

REMARKS

This function is an optional semaphore function.

This function is called by the function that wants to acquire the semaphore.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   SM32
             nSm;
   if (OAM_CreateSM (&nSm) == FALSE32)
      FVM_DBG_PRINT((TEXT("OAM_CreateSM Error\r\n")));
   OAM_ReleaseSM(nSm);
   OAM_AcquireSM(nSm);
   OAM_ReleaseSM(nSm);
```

(2) Example to implement the function in pSOS

```
BOOL32
OAM_AcquireSM(SM32 nHandle)
   BOOL32 bRet = TRUE32;
```



```
if (sm_p(nHandle, SM_WAIT, 0) != 0)
   bRet = FALSE32;
return bRet;
```

SEE ALSO

OAM_CreateSM, OAM_DestroySM, OAM_ReleaseSM



OAM ReleaseSM

DESCRIPTION

This function releases the semaphore.

SYNTAX

```
BOOL32
OAM_ReleaseSM(SM32 nHandle)
```

PARAMETERS

Parameter	Type	In/Out	Description
nHandle	SM32	In	Handle of the semaphore to be released

RETURN VALUE

Return Value	Description
TRUE32	If this function releases the semaphore successfully, it
	returns TRUE32.
FALSE32	Else it returns FALSE32.

REMARKS

This function is an optional semaphore function.

This function is called by the function that wants to release the semaphore.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   SM32
             nSm;
   if (OAM\_CreateSM (&(nSm)) == FALSE32)
      FVM_DBG_PRINT((TEXT("OAM_CreateSM Error\r\n")));
   OAM_ReleaseSM(nSm);
   OAM_AcquireSM(nSm);
   OAM_ReleaseSM(nSm);
```

(2) Example to implement the function in pSOS

```
BOOL32
OAM_ReleaseSM(SM32 nHandle)
   BOOL32 bRet = TRUE32;
```



```
if (sm_v(nHandle) != 0)
   bRet = FALSE32;
return bRet;
```

SEE ALSO

OAM_CreateSM, OAM_DestroySM, OAM_AcquireSM



OAM InitInt

DESCRIPTION

This function initializes the specified logical interrupt for NAND device.

SYNTAX

```
VOID
OAM_InitInt(UINT32 nLogIntId)
```

PARAMETERS

Parameter	Type	In/Out	Description
nLogIntId	UINT32	In	Logical interrupt ID number

RETURN VALUE

None

REMARKS

This function is an optional interrupt function. Currently, this function is used for asynchronous operation.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
        INT_ID_NAND_0 (0) /* Interrupt ID : 1st NAND */
#define
VOID
Example(VOID)
   OAM_InitInt(INT_ID_NAND_0);
```

(2) Example to implement the function in Symbian

```
VOID
OAM_InitInt(UINT32 nLogIntId)
   switch (nLogIntId)
      case XSR_INT_ID_NAND_0:
          iNANDInt = new TNandInterrupt;
          break;
      default:
          break;
```

SEE ALSO



OAM_BindInt, OAM_EnableInt, OAM_DisableInt, OAM_ClearInt



OAM BindInt

DESCRIPTION

This function binds the specified interrupt for NAND device.

SYNTAX

```
VOID
OAM_BindInt(UINT32 nLogIntId, UINT32 nPhyIntId)
```

PARAMETERS

Parameter	Type	In/Out	Description
nLogIntId	UINT32	In	Logical interrupt ID number
nPhyIntId	UINT32	In	Physical interrupt ID number

RETURN VALUE

None

REMARKS

This function is an optional interrupt function. Currently, this function is used for asynchronous operation.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
#define INT_ID_NAND_0 (0) /* Interrupt ID : 1st NAND */
enum TPlatformInterruptId
{
           EIrqTick, // IRQ 8
EIrqWatchdog, // IRQ 9
EIrqTimer0, // IRQ 10
EIrqTimer1, // IRQ 11
EIrqTimer2, // IRQ 12
};
VOID
Example(VOID)
   OAM_BindInt(INT_ID_NAND_0, EIrqExt4_7);
```



(2) Example to implement the function in Symbian

```
OAM_BindInt(UINT32 nLogIntId, UINT32 nPhyIntId)
   switch (nLogIntId)
      case XSR_INT_ID_NAND_0:
          iNANDInt->Bind((TInt)nPhyIntId, NandIsr, iNANDInt);
          break;
      default:
          break;
```

SEE ALSO

OAM_InitInt, OAM_EnableInt, OAM_DisableInt, OAM_ClearInt



OAM EnableInt

DESCRIPTION

This function enables the specified interrupt for NAND device.

SYNTAX

```
VOID
OAM_EnableInt(UINT32 nLogIntId, UINT32 nPhyIntId)
```

PARAMETERS

Parameter	Type	In/Out	Description
nLogIntId	UINT32	In	Logical interrupt ID number
nPhyIntId	UINT32	In	Physical interrupt ID number

RETURN VALUE

None

REMARKS

This function is an optional interrupt function. Currently, this function is used for asynchronous operation.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
#define INT_ID_NAND_0 (0) /* Interrupt ID : 1st NAND */
enum TPlatformInterruptId
{
           EIrqTick, // IRQ 8
EIrqWatchdog, // IRQ 9
EIrqTimer0, // IRQ 10
EIrqTimer1, // IRQ 11
EIrqTimer2, // IRQ 12
};
VOID
Example(VOID)
   OAM_EnableInt(INT_ID_NAND_0, EIrqExt4_7);
```



(2) Example to implement the function in Symbian

```
OAM_EnableInt(UINT32 nLogIntId, UINT32 nPhyIntId)
   switch (nLogIntId)
      case XSR_INT_ID_NAND_0:
          iNANDInt->Enable((TInt)nPhyIntId);
          break;
      default:
          break;
```

SEE ALSO

OAM_InitInt, OAM_BindInt, OAM_DisableInt, OAM_ClearInt



OAM DisableInt

DESCRIPTION

This function disables the specified interrupt for NAND device.

SYNTAX

```
VOID
OAM_DisableInt(UINT32 nLogIntId, UINT32 nPhyIntId)
```

PARAMETERS

Parameter	Type	In/Out	Description
nLogIntId	UINT32	In	Logical interrupt ID number
nPhyIntId	UINT32	In	Physical interrupt ID number

RETURN VALUE

None

REMARKS

This function is an optional interrupt function. Currently, this function is used for asynchronous operation.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
#define INT_ID_NAND_0 (0) /* Interrupt ID : 1st NAND */
enum TPlatformInterruptId
           EIrqTick, // IRQ 8
EIrqWatchdog, // IRQ 9
EIrqTimer0, // IRQ 10
EIrqTimer1, // IRQ 11
EIrqTimer2, // IRQ 12
};
VOID
Example(VOID)
   OAM_DisableInt(INT_ID_NAND_0, EIrqExt4_7);
```



(2) Example to implement the function in Symbian

```
OAM_DisableInt(UINT32 nLogIntId, UINT32 nPhyIntId)
   switch (nLogIntId)
      case XSR_INT_ID_NAND_0:
          iNANDInt->Disable((TInt)nPhyIntId);
          break;
      default:
          break;
```

SEE ALSO

OAM_InitInt, OAM_BindInt, OAM_EnableInt, OAM_ClearInt



OAM ClearInt

DESCRIPTION

This function clears the specified interrupt for NAND device.

SYNTAX

```
VOID
OAM_ClearInt(UINT32 nLogIntId, UINT32 nPhyIntId)
```

PARAMETERS

Parameter	Type	In/Out	Description
nLogIntId	UINT32	In	Logical interrupt ID number
nPhyIntId	UINT32	In	Physical interrupt ID number

RETURN VALUE

None

REMARKS

This function is an optional interrupt function. Currently, this function is used for asynchronous operation.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
#define INT_ID_NAND_0 (0) /* Interrupt ID : 1st NAND */
enum TPlatformInterruptId
          {
           EIrqBatteryFault, // IRQ 7
           EIrqTick, // IRQ 8
EIrqWatchdog, // IRQ 9
EIrqTimer0, // IRQ 10
EIrqTimer1, // IRQ 11
EIrqTimer2, // IRQ 12
};
VOID
Example(VOID)
   OAM_ClearInt(INT_ID_NAND_0, EIrqExt4_7);
```



(2) Example to implement the function in Symbian

```
OAM_ClearInt(UINT32 nLogIntId, UINT32 nPhyIntId)
   switch (nLogIntId)
      case XSR_INT_ID_NAND_0:
          iNANDInt->Clear((TInt)nPhyIntId);
          break;
      default:
         break;
```

SEE ALSO

OAM_InitInt, OAM_BindInt, OAM_EnableInt, OAM_DisableInt



OAM ResetTimer

DESCRIPTION

This function resets the timer.

SYNTAX

```
VOID
OAM_ResetTimer(VOID)
```

PARAMETERS

None

RETURN VALUE

None

REMARKS

This function is a recommended timer function.

Currently, this function is used for asynchronous operation.

In current implementation, this function does not use a timer of operating system but uses global counter variables. However, if user wants to implement the asynchronous feature based on execution time of operation, this function should be changed to use the real OS timer instead of the counter.

For more information about timer functions for asynchronous feature, refer to 오류! 참조 원본을 찾을 수 없습니다. Timer.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
{
   OAM_ResetTimer();
```

(2) Example to implement the function in Symbian

```
static UINT32 nTimerCounter = 0;
static UINT16 nTimerPrevCnt = 0;
OAM_ResetTimer(VOID)
   nTimerPrevCnt = 0;
   nTimerCounter = 0;
```



OAM_GetTime, OAM_WaitNMSec



OAM GetTime

DESCRIPTION

This function returns the current time value.

SYNTAX

```
UINT32
OAM_GetTime(VOID)
```

PARAMETERS

None

RETURN TYPE

Return Type	Description
UINT32	Current time value

REMARKS

This function is a recommended timer function.

Currently, this function is used for asynchronous operation.

In current implementation, this function does not use a timer of operating system but uses global counter variables. However, if user wants to implement the asynchronous feature based on execution time of operation, this function should be changed to use the real OS timer instead of the counter.

For more information about timer functions for asynchronous feature, refer to 오류! 참조 원본을 찾을 수 없습니다. Timer.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   UINT32
          nStartTime;
   nStartTime = OAM_GetTime();
```

(2) Example to implement the function in Symbian

```
UINT32
OAM_GetTime(VOID)
   return nTimerCounter++;
```



OAM_ResetTimer, OAM_WaitNMSec



OAM_WaitNMSec

DESCRIPTION

This function is called for waiting as a unit of milliseconds.

SYNTAX

```
VOID
OAM_WaitNMSec(UINT32 nNMSec)
```

PARAMETERS

Parameter	Type	In/Out	Description
nNMSec	UINT32	In	µsec time for waiting

RETURN TYPE

None

REMARKS

This function is a recommended timer function.

Currently, this function is used to wait the time in handling Power-off error.

For more information about timer functions for power-off recovery, refer to 오류! 참조 원본을 찾을 수 없습니다. Power-Off Recovery.

EXAMPLE

(1) Example to implement the function in Win32

```
VOID
OAM_WaitNMSec(UINT32 nNMSec)
   Sleep(nNMSec);
```

SEE ALSO

OAM_ResetTimer, OAM_GetTime



OAM Pa2Va

DESCRIPTION

This function is called for the address translation to access to the hardware from the system using virtual memory.

SYNTAX

```
UINT32
OAM_Pa2Va(UINT32 nPAddr)
```

PARAMETERS

Parameter	Type	In/Out	Description
nPAddr	UINT32	In	Physical address of NAND device

RETURN TYPE

Return Type	Description
UINT32	Virtual address of NAND device that Symbian OS uses

REMARKS

This function is recommended.

EXAMPLE

(1) Example to call the function

```
#include <OAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   INT32 nBaseAddr = 0x30000000;
   UINT32 nVirtualAddr;
   nVirtualAddr = OAM_Pa2Va(nBaseAddr));
```

(2) Example to implement the function in Symbian

```
UINT32
OAM_Pa2Va(UINT32 nPAddr)
   DPlatChunkHw *NandChunk;
   TLinAddr NandVirtAddr;
   XSR_DBG_PRINT((TEXT(">Nand::Open -> OneNandPhyAddr = 0x%x"),
                 nPAddr));
   TInt r=DPlatChunkHw::New(NandChunk,nPAddr,0x80000,
                 EMapAttrSupRw | EMapAttrFullyBlocking);
   if (r != KErrNone)
```



```
XSR_DBG_PRINT((TEXT(">Nand::Open -> NandChunk->
                          DoCreateL failed = 0x%x"), r));
   return r;
NandVirtAddr = NandChunk->LinearAddress();
XSR_DBG_PRINT((TEXT(">Nand::Open -> OneNandVirtAddr
                          = 0x%x"), NandVirtAddr));
return (UINT32)NandVirtAddr;
```



OAM_Idle

DESCRIPTION

This function is called when XSR is at idle time.

SYNTAX

```
VOID
OAM_Idle(VOID)
```

PARAMETERS

None

RETURN TYPE

None

REMARKS

This function is optional.

If XSR is polling on the device status, this function is called.

XSR usually keep polling on device status register to perform next operation. This polling takes little time, so ,usually, this function is not needed.to implement. But, under certain condition, it is better to yield CPU to other task instead of just waiting. XSR performance will be decreased, but other task can be performed with XSR simultaneously.

Caution: Do not perform any flash memory operation (XSR operation) in this function.

EXAMPLE

(1) Example to implement the function in Symbian

```
OAM_Idle(VOID)
   /* Default : Do nothing */
```



OAM_GetROLockFlag

DESCRIPTION

This function is called when XSR determines Read Only attribute.

SYNTAX

```
BOOL32
OAM_GetROLockFlag(VOID)
```

PARAMETERS

None

RETURN TYPE

Return Type	Description
BOOL32	TRUE32 with RO partition.

REMARKS

This function is optional.

The function OAM_GetROLockFlag is called when XSR determines whether certain block is in Read-Only partition or not. If XSR finds it is in range of RO partition, this function is called. If it is necessary to regard blocks in RO partition as RW under certain condition, implement this function to return FALSE. Do not modify this function unless you deeply understand internal implementation of XSR. Default implementation of this function just returns TRUE.

When the RO partition should be regarded as RW, this function should return FALSE.

EXAMPLE

(1) Example to implement the function in Symbian

```
BOOL32
OAM_GetROLockFlag(VOID)
   return TRUE32;
```



LLD (Low Level Driver)

This chapter describes the definition, system architecture, features, and APIs of LLD.

5.1. Description & Architecture

LLD is an abbreviation of Low Level Device Driver. LLD is adaptation module of XSR. LLD accesses the real device.

XSR cannot send a command directly to the device. When XSR sends a command to the device, it is needed a kind of translator, converting XSR command to the device-understandable message. The translator is a device driver LLD. LLD directly access to the device.

Reference

Generally, a device is a machine or hardware designed for a purpose. For example, it can include keyboards, mouse, display monitors, hard disk drives, CD-ROM players, printers, audio speakers, and etc. In this document, a device means NAND flash memory.

Generally, a device driver is a program that controls a particular type of a device. That is, a device driver converts the general input/output instruction of the Operation system to messages that the device type can understand.

For example, if XSR orders "read" command to the device, the device cannot receive "read" command of XSR itself. LLD translates "read" command for the device. Thus, the device receives "read" command not by XSR but by LLD, and executes it. Therefore, a user must implement LLD suitable for the device when a user ports XSR.

Figure 5-1 shows LLD in XSR system architecture.






Figure 5-1. LLD in XSR System Architecture

LLD has 17 functions that are classified into 6 categories as follows.

- ☐ Initialization functions : initialization, open, and close
- ☐ **Device information query function** : device information return
- ☐ Flash operation function : read, write, and erase
- ☐ Copyback function : copyback
- ☐ Other functions: initial bad block check, writable area setting
- ☐ Deferred Check Operation functions

In the next chapter, LLD APIs are covered in detail.



5.2. API

This chapter describes LLD APIs.

Note

In Table 5-1, a user can rename XXX in the function name. It is recommended to name XXX with the device name and three or four capital letters.

Table 5-1 shows the lists of LLD APIs.

The right row in table shows that the function is Mandatory or Optional or Recommended. Optional functions should be existed, but contents of the functions does not need to be implemented.

Table 5-1. LLD API

Function	Description	
XXX_Init	This function initializes the device driver.	M
XXX_Open	This function opens the device and makes it be ready.	M
XXX_Close	This function closes the device and closes linking.	M
XXX_GetDevInfo	This function reports the device information to upper layer.	M
XXX_Read	This function reads data from a page of NAND flash memory within page boundry.	M
XXX_Write	This function writes data into a page of NAND flash memory page boundry.	M
XXX_Erase	This function erases a block of NAND flash memory.	M
XXX_MRead	This function reads data from a page of NAND flash memory within block boundary.	M
XXX_MWrite	This function writes data into a page of NAND flash memory within block boundary.	M
XXX_MErase	This function erases multiple blocks of NAND flash memory	M
XXX_EraseVerify	This function verifies an erase operation whether success or not	M
XXX_CopyBack	This function copies data by using internal buffer in the device.	M
XXX_ChkInitBadBlk	This function checks whether a block is an initial bad block or not.	M
XXX_SetRWArea	This function is called when NAND device provides write/erase protection functionality in hardware.	О
XXX_IOCtl	This function is called to extend LLD functionality.	0
XXX_GetPrevOpData	This function copies data of previous write operation to the given buffer.	0
XXX_FlushOp	This function completes the current working operation.	О



XXX Init

DESCRIPTION

This function initializes XXX device driver.

SYNTAX

```
INT32
XXX_Init(VOID *pParm)
```

PARAMETERS

Parameter	Type	In/Out	Description
pParm	VOID *	In	Pointer to XsrVolParm data structure

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Initialize Success
LLD_INIT_FAILURE	Initialize Failure

REMARKS

This function is a mandatory initialization function.

For more information about XsrVolParm data structure, refer to the API page of PAM_GetPAParm.

EXAMPLE

(1) Example to call the function

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
           nErr;
   UINT32 nVol = 0;
   UINT32 nBaseAddr = 0x20000000;
   LowFuncTbl stLFT[MAX_VOL];
   PAM_RegLFT((VOID *)stLFT);
   nErr = stLFT[nVol].Init((VOID *) PAM_GetPAParm());
   if (nErr != LLD_SUCCESS)
      printf("XXX_Init(%d) fail. ErrCode = %x\n", nDev, nErr);
      return(FALSE32);
   return(TRUE32);
```



(2) Example to implement the function in OneNAND

```
INT32
ONLD_Init(VOID *pParm)
   UINT32
                nCnt;
   UINT32
                nIdx;
   UINT32
                nVol;
   static BOOL32 nInitFlg = FALSE32;
   XsrVolParm *pstParm = (XsrVolParm*)pParm;
   ONLD_DBG_PRINT((TEXT("[ONLD : IN] ++ONLD_Init()\r\n")));
   if (nInitFlg == TRUE32)
   {
       return(ONLD_SUCCESS);
   for (nCnt = 0; nCnt < MAX_SUPPORT_DEVS; nCnt++)</pre>
      pstPrevOpInfo[nCnt]
                                  = (PrevOpInfo *) NULL;
      astONLDDev[nCnt].bOpen = FALSE32;
astONLDDev[nCnt] = FALSE32:
      astONLDDev[nCnt].pstDevSpec = NULL;
   }
   for (nVol = 0; nVol < XSR_MAX_VOL; nVol++)</pre>
       for (nIdx = 0; nIdx < (XSR_MAX_DEV / XSR_MAX_VOL); nIdx++)</pre>
          nCnt = nVol * (XSR_MAX_DEV / XSR_MAX_VOL) + nIdx;
          if (pstParm[nVol].nBaseAddr[nIdx] != NOT MAPPED)
              astONLDDev[nCnt].BaseAddr
                  = OAM Pa2Va(pstParm[nVol].nBaseAddr[nIdx]);
              astONLDDev[nCnt].BaseAddr = NOT_MAPPED;
       }
   }
   nInitFlg = TRUE32;
   ONLD_DBG_PRINT((TEXT("[ONLD : OUT] --ONLD_Init()\r\n")));
   return(ONLD_SUCCESS);
```

SEE ALSO

XXX_Open, XXX_Close



XXX_Open

DESCRIPTION

This function opens the device and makes it be ready.

SYNTAX

```
INT32
XXX_Open(UINT32 nDev)
```

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)

RETURN VALUE

Return Value	Description	
LLD_SUCCESS	Open Success	
LLD_OPEN_FAILURE	Open Failure	

REMARKS

This function is a mandatory initialization function.

EXAMPLE

(1) Example to call the function

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
           nErr;
   UINT32 nDev = 0;
   UINT32 nVol = 0;
   LowFuncTbl stLFT[MAX_VOL];
   PAM_RegLFT((VOID *)stLFT);
   nErr = stLFT[nVol].Open(nDev);
   if (nErr != LLD_SUCCESS)
      printf("XXX_Open(%d) fail. ErrCode = %x\n", nDev, nErr);
      return (FALSE32);
   return (TRUE32);
```

(2) Example to implement the function in OneNAND



```
INT32
ONLD_Open(UINT32 nDev)
   INT32
          nCnt;
   UINT16 nMID, nDID, nVID;
   UINT32
             nBAddr;
   LLDMEArg *pstMEArg;
   SET PWR FLAG(nDev);
   _GetDevID(nDev, &nMID, &nDID, &nVID);
   for (nCnt = 0; astNandSpec[nCnt].nMID != 0; nCnt++)
      if (nDID == astNandSpec[nCnt].nDID)
          if ((nVID >> 8) == astNandSpec[nCnt].nGEN)
             astONLDDev[nDev].bOpen
                                       = TRUE32;
             astONLDDev[nDev].pstDevSpec = &astNandSpec[nCnt];
             break;
          }
          else
             continue;
      }
   _InitDevInfo(nDev, &nDID, &nVID);
   if (astONLDDev[nDev].bOpen != TRUE32)
      CLEAR PWR FLAG(nDev);
      return (ONLD OPEN FAILURE);
   if (pstPrevOpInfo[nDev] == (PrevOpInfo*)NULL)
      pstPrevOpInfo[nDev]
                  = (PrevOpInfo*)MALLOC(sizeof(PrevOpInfo));
      if (pstPrevOpInfo[nDev] == (PrevOpInfo*)NULL)
          return (ONLD_OPEN_FAILURE);
   }
   pstPrevOpInfo[nDev]->ePreOp
                                  = NONE;
   pstPrevOpInfo[nDev]->nCmd
                                   = 0;
   pstPrevOpInfo[nDev]->nPsn
                                   = 0;
   pstPrevOpInfo[nDev]->nScts
                                   = 0;
                                   = 0;
   pstPrevOpInfo[nDev]->nFlag
   pstPrevOpInfo[nDev]->pstPreMEArg
                      = (LLDMEArg*)MALLOC(sizeof(LLDMEArg));
   pstMEArg = pstPrevOpInfo[nDev]->pstPreMEArg;
   if (pstMEArg == NULL)
```



```
return (ONLD OPEN FAILURE);
   MEMSET(pstMEArg, 0x00, sizeof(LLDMEArg));
   pstMEArg->pstMEList
    = (LLDMEList*)MALLOC(sizeof(LLDMEList) * XSR_MAX_MEBLK);
   if (pstMEArg->pstMEList == NULL)
      return (ONLD OPEN FAILURE);
   pstMEArg->nNumOfMList = (UINT16)0x00;
   pstMEArg->nBitMapErr = (UINT16)0x00;
   pstMEArg->bFlag
                    = FALSE32;
   pstPrevOpInfo[nDev]->nBufSel = DATA_BUF0;
   nBAddr = GET_DEV_BADDR(nDev);
   /* IO Buffer Enable for NAND interrupt enable/disable */
   ONLD_REG_SYS_CONF1(nBAddr) &= MASK_SYNC_BURST_READ;
   ONLD_REG_SYS_CONF1(nBAddr) |=
        (IOBE_ENABLE | BST_RD_LATENCY_4 | BST_LENGTH_8WD);
   ONLD_REG_SYS_CONF1(nBAddr) |= (SYNC_READ_MODE);
   LLD_RTL_PRINT((TEXT("[ONLD:MSG] nNumOfBlks = %d\r\n"),
astONLDDev[nDev].pstDevSpec->nNumOfBlks));
   LLD RTL PRINT((TEXT("[ONLD:MSG] nNumOfPlanes = %d\r\n"),
astONLDDev[nDev].pstDevSpec->nNumOfPlanes));
   LLD_RTL_PRINT((TEXT("[ONLD:MSG] nBlksInRsv = %d\r\n"),
astONLDDev[nDev].pstDevSpec->nBlksInRsv));
  LLD_RTL_PRINT((TEXT("[ONLD:MSG] nBadPos
                                                = %d\r\n"),
astONLDDev[nDev].pstDevSpec->nBadPos));
  LLD RTL PRINT((TEXT("[ONLD:MSG] nLsnPos
                                                = %d\r\n"),
astONLDDev[nDev].pstDevSpec->nLsnPos));
  LLD RTL PRINT((TEXT("[ONLD:MSG] nECCPos
                                                = %d\r\n"),
astONLDDev[nDev].pstDevSpec->nEccPos));
  LLD_RTL_PRINT((TEXT("[ONLD:MSG] nBWidth
                                                = %d\r\n"),
astONLDDev[nDev].pstDevSpec->nBWidth));
  LLD_RTL_PRINT((TEXT("[ONLD:MSG] nMEFlag
                                                = %d\r\n"),
astONLDDev[nDev].pstDevSpec->nMEFlag));
   LLD_RTL_PRINT((TEXT("[ONLD:MSG] nLKFlag
                                                = %d\r\n"),
astONLDDev[nDev].pstDevSpec->nLKFlag));
   return (ONLD_SUCCESS);
```

XXX_Init, XXX_Close



XXX Close

DESCRIPTION

This function closes XXX device and closes linking.

SYNTAX

```
INT32
XXX_Close(UINT32 nDev)
```

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Close Success
LLD_CLOSE_FAILURE	Close Failure

REMARKS

This function is a mandatory initialization function.

EXAMPLE

(1) Example to call the function

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
            nErr;
             nDev = 0;
   UINT32
   UINT32
           nVol = 0;
   LowFuncTbl stLFT[MAX_VOL];
   PAM_RegLFT((VOID *)stLFT);
   nErr = stLFT[nVol].Close(nDev);
   if (nErr != LLD_SUCCESS)
      printf("XXX_Close(%d) fail. ErrCode = %x\n", nDev, nErr);
      return (FALSE32);
   return (TRUE32);
```

(2) Example to implement the function in OneNAND



```
INT32
ONLD_Close(UINT32 nDev)
   UINT32 nBAddr;
   INT32    nRes = ONLD_SUCCESS;
  nBAddr = GET DEV BADDR(nDev);
   if ((nRes =ONLD FlushOp(nDev)) != ONLD SUCCESS)
      return nRes;
   if (pstPrevOpInfo[nDev] != (PrevOpInfo*)NULL)
      FREE(pstPrevOpInfo[nDev]->pstPreMEArg->pstMEList);
      pstPrevOpInfo[nDev]->pstPreMEArg->pstMEList
                                    = (LLDMEList*)NULL;
      FREE(pstPrevOpInfo[nDev]->pstPreMEArg);
      pstPrevOpInfo[nDev]->pstPreMEArg = (LLDMEArg*)NULL;
      FREE(pstPrevOpInfo[nDev]);
      pstPrevOpInfo[nDev] = (PrevOpInfo*)NULL;
  astONLDDev[nDev].pstDevSpec = NULL;
  return (ONLD_SUCCESS);
```

XXX_Init, XXX_Open



XXX GetDevInfo

DESCRIPTION

This function reports the device information to upper layer.

SYNTAX

```
INT32
XXX_GetDevInfo(UINT32 nDev, LLDSpec* pstDevInfo)
```

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
pstDevInfo	LLDSpec *	Out	Data structure of device information

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Sending the requested information
LLD_ILLEGAL_ACCESS	Illegal Access

REMARKS

This function is a mandatory device information query function.

LLDSpec data structure is declared in LLD.h.

☐ LLDSpec data structure

```
/* offset size */
typedef struct {
   UINT8 nMCode; /* Manufacturer Code 0x00 1 */
UINT8 nDCode; /* Device Code 0x01 1 */
UINT16 nNumOfBlks; /* The Number of Blocks 0x02 2 */
   UINT16 nPgsPerBlk; /* The Number of Pages per Block
                                                    0 \times 04 2
   UINT16 nBlksInRsv; /* The Number of Blocks 0x06 2
                                in Reserved Block Pool
   UINT8 nSctsPerPg; /* The Number of Sectors per Page
                                                    0x08 1 */
   UINT8 nNumOfPlane; /* The Number of Plane 0x09
                                                          1 */
   UINT8 nMEFlag; /* Multi-block Erase Flag 0x0A 1 */
   UINT8 nBWidth; /* Device Bus Width
UINT8 nBadPos; /* BadBlock Information
                                                   0x0C 1 */
                        /* BadBlock Information Position
                                             0x0E 1 */
0x0E 1 */
   UINT8 nLsnPos; /* LSN Position
                        /* ECC Value Position 0x0F 1 */
   UINT8 nEccPos;
   UINT8 aUID[XSR_UID_SIZE]; /* UID
                                                   0x10
                                                          16,
                                0xFF(absence case of UID) */
```



```
nTrTime; /* Physical Read Operation Time
 UINT16
                                                          2 */
        nTwTime; /* Physical Write Operation Time
 UINT16
                                                    0x22
                                                          2 */
         nTeTime; /* Physical Erase Operation Time
                                                    0x24
                                                          2 */
        nTfTime; /* Data Transfer Time
                                                    0x26
LLDSpec;
```

Table 5-2 explains LLDSpec data structure.

Table 5-2. LLDSpec in LLD.h

Member Variable	Member Variable
nMCode	Manufacturer code of a device
nDCode	Device code
nNumOfBlks	Total number of blocks of a device
nPgsPerBlk	The number of pages per one block of a device
nBlksInRsv	The number of blocks in reserved block pool
nSctsPerPg	The number of sectors per one page of device
nNumOfPlane	The number of planes of a device
nMEFlag	Flag for multi-block erase
nBWidth	Device bus width
nBadPos	Bad block information position
nLsnPos	Position to store LSN
nECCPos	Position to store ECC value
aUID	Unique ID of device
[XSR_UID_SIZE]	
nTrTime	Physical read operation time of a device (nsec)
nTwTime	Physical write operation time of a device (nsec)
nTeTime	Physical erase operation time of a device (nsec)
nTfTime	Data transfer time of a device (nsec)

Here is more detailed explanation about LLDSpec.

☐ nBlksInRsv

In general, NAND flash memory can contain bad block. nBlksInRsv is the number of the reserved block in NAND flash memory. The related information about the number of the reserved block is described in "VALID BLOCK" chapter inside data sheet of flash memory. In VALID BLOCK chapter, the maximum valid block number and the minimum valid block number is marked. nBlksInRsv is the remainder between the maximum valid block number and the minimum valid block number.

☐ nNumOfPlane

nNumOfPlane is the number of planes in NAND flash memory. NAND flash memory can consists of one or more planes internally.

☐ nMEFlag

nMEFlag means whether NAND flash memory support multi-block erase functionality or not. If NAND flash memory supports multi-block erase, nMEFlag can have LLD_ME_OK or LLD_ME_NO. However, NAND flash memory does not support multi-block erase, nMEFlag must have LLD_ME_NO. (For more information about which device supports multi-block erase, refer to the Specification of NAND flash memory.)

□ nBWidth

nBWidth is the data bus width in NAND flash memory. The data bus of NAND flash memory can be 8bit or 16bit. If the data bus is 8bit, nBWidth becomes LLD_BW_X08. If



the data bus is 16bit, nBWidth becomes LLD_BW_X16.

This value is used at software ECC module in BML. If this value is abnormal, the return value of software ECC can be abnormal.

□ nBadPos

To show a bad block, the blocks of NAND flash memory records the specific value at the specific position of spare array. nBadPos is offset of the bad block position of spare array. nBadPos depends on the kind of NAND flash memory. A user can know nBadPos in the data sheet of NAND flash memory or "Samsung NAND flash Spare Area Assignment Standard (21.Feb.2003)".

☐ nLsnPos

nLsnPos is offset that the first byte of LSN(Logical Sector Number) of spare array is located.

nLsnPos depends on the kind of NAND flash memory. A user can know nLsnPos in the data sheet of NAND flash memory or "Samsung NAND flash Spare Area Assignment Standard (21.Feb.2003)".

☐ nEccPos

nEccPos is offset that the first byte of ECC of spare array is located.

nEccPos depends on the kind of NAND flash memory. A user can know nEccPos in the data sheet of NAND flash memory or "Samsung NAND flash Spare Area Assignment Standard (21.Feb.2003)".

EXAMPLE

(1) Example to call the function

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
            nErr;
   UINT32
            nDev = 0;
   UINT32
            nVol = 0;
   LLDSpec
             stDevInfo;
   LowFuncTbl stLFT[MAX_VOL];
   PAM_RegLFT((VOID *)stLFT);
   nErr = stLFT[nVol].GetDevInfo(nDev, &stDevInfo);
   if (nErr != LLD_SUCCESS)
      printf("XXX_ GetDevInfo()fail. ErrCode = %x\n", nErr);
      return (FALSE32);
   return (TRUE32);
```

(2) Example to implement the function in OneNAND

```
INT32
ONLD GetDevInfo(UINT32 nDev, LLDSpec *pstFILDev)
```



```
UINT32 nBAddr;
if (astONLDDev[nDev].pstDevSpec == NULL)
   return(ONLD_ILLEGAL_ACCESS);
nBAddr = GET DEV BADDR(nDev);
pstFILDev->nMCode
       = (UINT8)astONLDDev[nDev].pstDevSpec->nMID;
pstFILDev->nDCode
       = (UINT8)astONLDDev[nDev].pstDevSpec->nDID;
pstFILDev->nNumOfBlks
       = (UINT16)astONLDDev[nDev].pstDevSpec->nNumOfBlks;
pstFILDev->nPasPerBlk
                      = (UINT16)GET_PGS_PER_BLK(nDev);
pstFILDev->nBlksInRsv
       = (UINT16)astONLDDev[nDev].pstDevSpec->nBlksInRsv;
pstFILDev->nSctsPerPg
                      = (UINT8)GET_SCTS_PER_PG(nDev);
pstFILDev->nNumOfPlane
       =(UINT8)astONLDDev[nDev].pstDevSpec->nNumOfPlanes;
pstFILDev->nBadPos
       = (UINT8)astONLDDev[nDev].pstDevSpec->nBadPos;
pstFILDev->nLsnPos
       = (UINT8)astONLDDev[nDev].pstDevSpec->nLsnPos;
pstFILDev->nEccPos
       = (UINT8)astONLDDev[nDev].pstDevSpec->nEccPos;
pstFILDev->nBWidth
       = (UINT8)astONLDDev[nDev].pstDevSpec->nBWidth;
pstFILDev->nMEFlag
       = (UINT8)astONLDDev[nDev].pstDevSpec->nMEFlag;
pstFILDev->aUID[0]
                      = 0xEC;
pstFILDev->aUID[1]
                      = 0x00;
                      = 0xC5;
pstFILDev->aUID[2]
pstFILDev->aUID[3]
                      = 0x5F;
pstFILDev->aUID[4]
                      = 0x3D;
pstFILDev->aUID[5]
                      = 0x12;
                      = 0x34;
pstFILDev->aUID[6]
pstFILDev->aUID[7]
                      = 0x37;
pstFILDev->aUID[8]
                       = 0x34;
pstFILDev->aUID[9]
                       = 0x33;
pstFILDev->aUID[10]
                       = 0x30;
                       = 0x30;
pstFILDev->aUID[11]
pstFILDev->aUID[12]
                       = 0 \times 03;
pstFILDev->aUID[13]
                      = 0 \times 03;
                      = 0x06;
pstFILDev->aUID[14]
                       = 0 \times 02;
pstFILDev->aUID[15]
pstFILDev->nTrTime
       = (UINT32)astONLDDev[nDev].pstDevSpec->nTrTime;
pstFILDev->nTwTime
      = (UINT32)astONLDDev[nDev].pstDevSpec->nTwTime;
pstFILDev->nTeTime
      = (UINT32)astONLDDev[nDev].pstDevSpec->nTeTime;
pstFILDev->nTfTime
```



```
= (UINT32)astONLDDev[nDev].pstDevSpec->nTfTime;
return (ONLD_SUCCESS);
```



XXX Read

DESCRIPTION

This function reads data from NAND flash memory. XXX_Read, unlikely XXX_MRead, only read sectors within a page boundry. The sector number of the large block and small block are different.

SYNTAX

INT32 XXX_Read(UINT32 nDev, UINT32 nPsn, UINT32 nNumOfScts, UINT8 *pMBuf, UINT8 *pSBuf, UINT32 nFlag)

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
nPsn	UINT32	In	Physical Sector Number
nNumOfScts	UINT32	In	Number of sectors
pMBuf	UINT8 *	Out	Memory buffer for main array of NAND
			flash memory
pSBuf	UINT8 *	Out	Memory buffer for spare array of NAND
			flash memory
nFlag	UINT32	In	Operation options (ECC on/off)

nFlag has the the operation options as follows.

Flag	Value	Description
LLD_FLAG_ECC_ON	(1 << 1)	ECC on (Read Operation with ECC)
LLD_FLAG_ECC_OFF	(0 << 1)	ECC off (Read Operation without ECC)

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Read Success
LLD_READ_ERROR ECC	Data Integrity Fault (1 or 2bit ECC error) This return
result code	value is available only in case of using Hardware ECC.
LLD_PREV_WRITE_ERROR	In DCOP (Deferred Check Operation), previous write
LLD_PREV_OP_RESULT	error happens.
LLD_PREV_ERASE_ERROR	In DCOP (Deferred Check Operation), previous erase
LLD_PREV_OP_RESULT	error happens.
LLD_ILLEGAL_ACCESS	Illegal Read Operation
LLD_READ_DISTURBANCE	1bit ECC error by read disturbance happens.

REMARKS

This function is a mandatory flash operation function.

DCOP (Deferred Check Operation): a method optimizing the operation performance. The DCOP method is a procedure to terminate the function (write or erase) right after the command issue. Then it checks the result of the operation at next function call.

The parameters nPsn and nNumOfScts read data as a unit of a sector. For more information about the byte alignment, refer to 오류! 참조 원본을 찾을 수



없습니다. 오류! 참조 원본을 찾을 수 없습니다.

EXAMPLE

(1) Example to call the function

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
            nErr;
   UINT32 nDev = 0;
   UINT32 nVol = 0;
   UINT32 nPSN = 0;
   UINT32 nNumOfScts = 1;
   UINT8
            aMBuf[LLD MAIN SIZE];
            aSBuf[LLD_SPARE_SIZE];
   UINT8
   UINT32    nFlag = LLD_FLAG_ECC_ON;
   LowFuncTbl stLFT[MAX_VOL];
   PAM_RegLFT((VOID *)stLFT);
   nErr = stLFT[nVol].Read(nDev, nPSN, nNumOfScts, aMBuf,
                            aSBuf, nFlag);
   if (nErr != LLD_SUCCESS)
      printf("XXX_Read() fail. ErrCode = %x\n", nErr);
      return (FALSE32);
   return (TRUE32);
```

(2) Example to implement the function in OneNAND

```
ONLD_Read(UINT32 nDev, UINT32 nPsn, UINT32 nScts,
        UINT8 *pMBuf, UINT8 *pSBuf, UINT32 nFlag)
  UINT32 nCnt;
  UINT16 nBSA;
  UINT32 *pONLDMBuf;
   UINT32 *pONLDSBuf;
   UINT32 nBAddr;
   UINT16 nPbn;
   UINT32 nPpn;
   UINT16 nEccRes
                    = (UINT16)0x0;
   UINT16 nEccMask = (UINT16)0x0;
                   = nPsn;
   UINT32 nPsnO
   UINT32 nScts0
                    = nScts;
   INT32 nRes;
   nBAddr = GET_DEV_BADDR(nDev);
   if ((pMBuf == NULL) && (pSBuf == NULL))
```



```
return (ONLD_ILLEGAL_ACCESS);
nPbn = GET_PBN(nDev, nPsn);
nPpn = GET_PPN(nDev, nPsn);
/* ECC Value Bit Mask Setting */
for (nCnt = 0; nCnt < nScts; nCnt++)</pre>
   if (pMBuf != NULL)
      nEccMask = (0x08 << (nCnt * 4));
   if (pSBuf != NULL)
      nEccMask = (0x02 << (nCnt * 4));
}
if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
   pstPrevOpInfo[nDev]->ePreOp = NONE;
   return nRes;
ONLD_REG_START_ADDR2(nBAddr) = (UINT16)MAKE_DBS(nPbn);
/* Block Number Set */
ONLD_REG_START_ADDR1(nBAddr) = (UINT16)MAKE_FBA(nPbn);
/* Sector Number Set */
ONLD_REG_START_ADDR8(nBAddr)
      = (UINT16)(
     ((nPsn << astONLDInfo[nDev].nFPASelSft) & MASK FPA)</pre>
     (nPsn & astONLDInfo[nDev].nFSAMask));
nBSA = (UINT16)MAKE BSA(nPsn, GET NXT BUF SEL(nDev));
/* Start Buffer Selection */
ONLD_REG_START_BUF(nBAddr)
     = (UINT16)((nBSA & MASK_BSA) | (nScts & MASK_BSC));
if (nFlag & ONLD_FLAG_ECC_ON)
   /* System Configuration Reg set (ECC On)*/
   ONLD_DBG_PRINT((TEXT("[ONLD : MSG] ECC ON\r\n")));
   ONLD_REG_SYS_CONF1(nBAddr) &= CONF1_ECC_ON;
}
else
   /* System Configuration Reg set (ECC Off)*/
   ONLD_DBG_PRINT((TEXT("[ONLD : MSG] ECC OFF\r\n")));
   ONLD_REG_SYS_CONF1(nBAddr) |= CONF1_ECC_OFF;
/* INT Stat Reg Clear */
ONLD_REG_INT(nBAddr)
                            = (UINT16)INT_CLEAR;
```



```
* /
   /*ONLD Read CMD is issued
   /*----*/
   if (pMBuf != NULL)
      /* Page Read Command issue */
      ONLD_DBG_PRINT((TEXT("[ONLD : MSG] Read Page\r\n")));
      ONLD_REG_CMD(nBAddr)
             = (UINT16)ONLD_CMD_READ_PAGE;
   }
   else
      /* Spare Read Command issue */
      ONLD_DBG_PRINT((TEXT("[ONLD : MSG] Read Spare\r\n")));
      ONLD_REG_CMD(nBAddr)
             = (UINT16)ONLD_CMD_READ_SPARE;
   while (GET_ONLD_INT_STAT(nBAddr, PEND_READ)
            != (UINT16)PEND_READ)
      /* Wait until device ready */
   pONLDMBuf = (UINT32*)GET_ONLD_MBUF_ADDR(
                  nBAddr, nPsnO, GET_NXT_BUF_SEL(nDev));
   pONLDSBuf = (UINT32*)GET_ONLD_SBUF_ADDR(nBAddr,
                  nPsnO, GET_NXT_BUF_SEL(nDev));
   if (pMBuf != NULL)
      /* Memcopy for main data */
      _ReadMain(pMBuf, pONLDMBuf, nSctsO);
   if (pSBuf != NULL)
      /* Memcopy for spare data */
      _ReadSpare(pSBuf, pONLDSBuf, nScts0);
   pstPrevOpInfo[nDev]->nBufSel = GET_NXT_BUF_SEL(nDev);
   if (nFlag & ONLD_FLAG_ECC_ON)
      nEccRes = (ONLD_REG_ECC_STAT(nBAddr) & nEccMask);
      if (nEccRes != 0)
         return (ONLD_READ_ERROR | nEccRes);
   return (ONLD_SUCCESS);
}
```



XXX_Write, XXX_Erase, XXX_Copyback, XXX_MRead, XXX_MWrite, XXX_MErase, XXX_EraseVerify



XXX_Write

DESCRIPTION

This function writes data into NAND flash memory. XXX_Write, unlikely XXX_MWrite, only write sectors within a page boundry. The sector number of the large block and small block are different.

SYNTAX

INT32

XXX_Write(UINT32 nDev, UINT32 nPsn, UINT32 nNumOfScts, UINT8 *pMBuf, UINT8 *pSBuf, UINT32 nFlag)

PARAMETERS

Parameter	Туре	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
nPsn	UINT32	In	Physical Sector Number
nNumOfScts	UINT32	In	Number of sectors
pMBuf	UINT8 *	In	Memory buffer for main array of NAND
			flash memory
pSBuf	UINT8 *	In	Memory buffer for spare array of NAND
			flash memory
nFlag	UINT32	In	Operation options (ECC on/off, Sync/Async)

nFlag has the the operation options as follows.

Flag	Value	Description
LLD_FLAG_ASYNC_OP	(1 << 0)	Asynchronous Operation
LLD_FLAG_SYNC_OP	(0 << 0)	Synchronous Operation
LLD_FLAG_ECC_ON	(1 << 1)	ECC on (Read Operation with ECC)
LLD_FLAG_ECC_OFF	(0 << 1)	ECC off (Read Operation without ECC)

Flag value is devided into Sync/Async Operation flag and ECC on/off flag. These two flags can be merged as follow.

nFlag = LLD_FLAG_SYNC_OP | LLD_FLAG_ECC_ON;

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Write Success
LLD_WRITE_ERROR	Write Failure
LLD_PREV_WRITE_ERROR	In DCOP (Deferred Check Operation), previous
LLD_PREV_OP_RESULT	write error happens
LLD_PREV_ERASE_ERROR	In DCOP (Deferred Check Operation), previous
LLD_PREV_OP_RESULT	erase error happens
LLD_WR_PROTECT_ERROR	Write Operation at Locked Area
LLD_ILLEGAL_ACCESS	Illegal Write Operation

REMARKS

This function is a mandatory flash operation function.



DCOP(Deferred Check Operation): a method optimizing the operation performance. The DCOP method is a procedure to terminate the function (write or erase) right after the command issue. Then it checks the result of the operation at next function call.

The parameters nPsn and nNumOfScts write data as a unit of a sector.

For more information about the byte alignment, refer to Chapter 오류! 참조 원본을 찾을 수 없습니다. 오류! 참조 원본을 찾을 수 없습니다.

In order to support asynchronous mode, codes which execute next steps must be added. First, check the value of a flag. And then, clear an interrupt. Finally, enable the interrupt. For more information about the interrupt, refer to Chapter 오류! 참조 원본을 찾을 수 없습니다. 오류! 참조 원본을 찾을 수 없습니다.

EXAMPLE

(1) Example to call the function

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
             nErr;
            nDev = 0;
   UINT32
   UINT32
             nVol = 0;
   UINT32
             nPSN = 0;
   UINT32
             nNumOfScts = 4;
   UINT8
             aMBuf[LLD_MAIN_SIZE * 4];
             aSBuf[LLD_SPARE_SIZE * 4];
   UINT8
            nFlag = LLD FLAG ASYNC OP | LLD FLAG ECC ON;
   UINT32
   LowFuncTbl stLFT[MAX VOL];
   PAM_RegLFT((VOID *)stLFT);
   nErr = stLFT[nVol].Write(nDev, nPSN, nNumOfScts, aMBuf,
                             aSBuf, nFlag);
   if (nErr != LLD_SUCCESS)
      printf("XXX_Write() fail. ErrCode = %x\n", nErr);
      return (FALSE32);
   return (TRUE32);
```

(2) Example to implement the function in OneNAND

```
ONLD_Write(UINT32 nDev, UINT32 nPsn, UINT32 nScts, UINT8 *pMBuf,
UINT8 *pSBuf,
         UINT32 nFlag)
   UINT16 nBSA;
   UINT32 *pONLDMBuf, *pONLDSBuf;
   UINT32 nBAddr;
   UINT32 nPbn;
```



```
INT32
       nRes;
nBAddr = GET_DEV_BADDR(nDev);
if ((pMBuf == NULL) && (pSBuf == NULL))
   return (ONLD ILLEGAL ACCESS);
nPbn = GET PBN(nDev, nPsn);
if ((GET_DEV_DID(nDev) \& 0x0008) == DDP_CHIP)
   if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
       return nRes;
/* Device BufferRam Select */
ONLD_REG_START_ADDR2(nBAddr) = (UINT16)MAKE_DBS(nPbn);
pONLDMBuf = (UINT32*)GET_ONLD_MBUF_ADDR(
                     nBAddr, nPsn, GET_NXT_BUF_SEL(nDev));
pONLDSBuf = (UINT32*)GET_ONLD_SBUF_ADDR(
                     nBAddr, nPsn, GET_NXT_BUF_SEL(nDev));
if (pMBuf != NULL)
   /* Memcopy for main data */
   _WriteMain(pMBuf, pONLDMBuf, nScts);
if (pSBuf != NULL)
   /* Memcopy for spare data */
   _WriteSpare(pSBuf, pONLDSBuf, nScts);
else
   /* Memset for spare data 0xff*/
   MEMSET(pONLDSBuf, 0xFF, (ONLD_SPARE_SIZE * nScts));
}
if ((GET_DEV_DID(nDev) & 0x0008) != DDP_CHIP)
   if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
      return nRes;
/* Block Number Set */
ONLD_REG_START_ADDR1(nBAddr) = (UINT16)MAKE_FBA(nPbn);
/* Sector Number Set */
ONLD_REG_START_ADDR8(nBAddr) = (UINT16)(
     ((nPsn << astONLDInfo[nDev].nFPASelSft) & MASK_FPA)</pre>
     (nPsn & astONLDInfo[nDev].nFSAMask));
```



```
nBSA = (UINT16)MAKE BSA(nPsn, GET NXT BUF SEL(nDev));
ONLD_REG_START_BUF(nBAddr)
     (UINT16)((nBSA & MASK_BSA) | (nScts & MASK_BSC));
if (nFlag & ONLD_FLAG_ECC_ON)
   /* System Configuration Reg set (ECC On)*/
   ONLD_DBG_PRINT((TEXT("[ONLD : MSG] ECC ON\r\n")));
   ONLD REG SYS CONF1(nBAddr) &= CONF1 ECC ON;
else
   /* System Configuration Reg set (ECC Off)*/
   ONLD_DBG_PRINT((TEXT("[ONLD : MSG] ECC OFF\r\n")));
   ONLD_REG_SYS_CONF1(nBAddr) |= CONF1_ECC_OFF;
/* in case of async mode, interrupt should be enabled */
if (nFlag & ONLD_FLAG_ASYNC_OP)
   PAM_ClearInt((UINT32)XSR_INT_ID_NAND_0);
   PAM_EnableInt((UINT32)XSR_INT_ID_NAND_0);
/* INT Stat Reg Clear */
ONLD_REG_INT(nBAddr) = (UINT16)INT_CLEAR;
/*____*/
/* ONLD Write CMD is issued
/*----*/
if (pMBuf != NULL)
   /* Main Write Command issue */
   ONLD DBG PRINT((TEXT("[ONLD : MSG] Write Page\r\n")));
   ONLD REG CMD(nBAddr) = (UINT16)ONLD CMD WRITE PAGE;
}
else
   /* Spare Write Command issue */
   ONLD_DBG_PRINT((TEXT("[ONLD : MSG] Write Spare\r\n")));
   ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_WRITE_SPARE;
pstPrevOpInfo[nDev]->ePreOp
                            = WRTTE;
pstPrevOpInfo[nDev]->nPsn
                           = nPsn;
pstPrevOpInfo[nDev]->nScts
                            = nScts;
pstPrevOpInfo[nDev]->nFlag
                           = nFlag;
pstPrevOpInfo[nDev]->nBufSel = GET_NXT_BUF_SEL(nDev);
return (ONLD_SUCCESS);
```

XXX_Read, XXX_Erase, XXX_Copyback, XXX_MRead, XXX_MWrite, XXX_MErase, XXX_EraseVerify



XXX Erase

DESCRIPTION

This function erases a block of NAND flash memory.

SYNTAX

INT32 XXX_Erase(UINT32 nDev, UINT32 nPbn, UINT32 nFlag)

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
nPbn	UINT32	In	Physical Block Number
nFlag	UINT32	In	Operation options (Sync/Async)

nFlag has the the operation options as follows.

Flag	Value	Description
LLD_FLAG_ASYNC_OP	(1 << 0)	Asynchronous Operation
LLD_FLAG_SYNC_OP	(0 << 0)	Synchronous Operation

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Erase Success
LLD_ERASE_ERROR	Erase Failure
LLD_WR_PROTECT_ERROR	Erase Operation Error at Locked Area
LLD_PREV_WRITE_ERROR	In DCOP (Deferred Check Operation), previous write
LLD_PREV_OP_RESULT	error happens
LLD_PREV_ERASE_ERROR	In DCOP (Deferred Check Operation), previous erase
LLD_PREV_OP_RESULT	error happens
LLD_ILLEGAL_ACCESS	Illigal Erase Operation

REMARKS

This function is a mandatory flash operation function.

DCOP(Deferred Check Operation): a method optimizing the operation performance. The DCOP method is a procedure to terminate the function (write or erase) right after the command issue. Then it checks the result of the operation at next function call.

In order to support asynchronous mode, codes which execute next steps must be added. First, check the value of a flag. And then, clear an interrupt. Finally, enable the interrupt. For more information about the interrupt, refer to Chapter 오류! 참조 원본을 찾을 수 없습니다. 오류! 참조 원본을 찾을 수 없습니다..

EXAMPLE

(1) Example to call the function

#include <XSRTypes.h> #include <PAM.h>



```
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
           nErr;
   INT32
           nDev = 0;
   UINT32
           nVol = 0;
   UINT32
           nPbn = 0;
   UINT32
   UINT32 nFlag = LLD FLAG ASYNC OP;
   LowFuncTbl stLFT[MAX_VOL];
   PAM_RegLFT((VOID *)stLFT);
   nErr = stLFT[nVol].Erase(nDev, nPbn, nFlag)
   if (nErr != LLD_SUCCESS)
      printf("XXX_Erase()fail. ErrCode = %x\n", nErr);
      return (FALSE32);
   return (TRUE32);
```

(2) Example to implement the function in OneNAND

```
ONLD_Erase(UINT32 nDev, UINT32 nPbn, UINT32 nFlag)
  UINT32 nBAddr;
  UINT32 nRes;
  nBAddr = GET_DEV_BADDR(nDev);
  if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
      return nRes;
  /* Block Number Set */
  ONLD_REG_START_ADDR1(nBAddr) = (UINT16)MAKE_FBA(nPbn);
  ONLD_REG_START_ADDR2(nBAddr) = (UINT16)MAKE_DBS(nPbn);
  /* INT Stat Reg Clear */
  ONLD_REG_INT(nBAddr)
                         = (UINT16)INT_CLEAR;
   /*----*/
  /* ONLD Erase CMD is issued
   ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_ERASE_BLK;
  pstPrevOpInfo[nDev]->ePreOp = ERASE;
  pstPrevOpInfo[nDev]->nPsn
                      = nPbn * GET SCTS PER BLK(nDev);
  pstPrevOpInfo[nDev]->nFlag
                             = nFlag;
  /* in case of async mode, interrupt should be enabled */
  if (nFlag & ONLD_FLAG_ASYNC_OP)
```



```
PAM_ClearInt((UINT32)XSR_INT_ID_NAND_0);
   PAM_EnableInt((UINT32)XSR_INT_ID_NAND_0);
return (ONLD_SUCCESS);
```

XXX_Read, XXX_Write, XXX_Copyback, XXX_MRead, XXX_MWrite, $\tt XXX_MErase$, $\tt XXX_EraseVerify$



XXX MRead

DESCRIPTION

This function reads data from NAND flash memory. XXX_MRead, unlikely XXX_Read, only read multiple sectors within a block boundry.

When an error occurs, LLD can return ECC error. If 1bit error occurs, this function returns SUCCESS. If 2bit error occurs, this function performs the read operation of the remaining sector and then returns READ ERROR.

SYNTAX

INT32 XXX_MRead(UINT32 nDev, UINT32 nPsn, UINT32 nNumOfScts, SGL *pstSGL, UINT8 *pSBuf, UINT32 nFlag)

PARAMETERS

Parameter	Туре	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
nPsn	UINT32	In	Physical Sector Number
nNumOfScts	UINT32	In	Number of sectors
pstSGL	SGL *	Out	Scatter gather list structure for main array of
			NAND flash memory
pSBuf	UINT8 *	Out	Memory buffer for spare array of NAND
			flash memory
nFlag	UINT32	In	Operation options (ECC on/off)

nFlag has the the operation options as follows.

Flag	Value	Description
LLD_FLAG_ECC_ON	(1 << 1)	ECC on (Read Operation with ECC)
LLD_FLAG_ECC_OFF	(0 << 1)	ECC off (Read Operation without ECC)

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Read Success
LLD_READ_ERROR ECC	Data Integrity Fault (1 or 2bit ECC error) This return
result code	value is available only in case of using Hardware ECC
LLD_WRITE_ERROR	In DCOP (Deferred Check Operation), previous write
LLD_PREV_OP_RESULT	error happens.
LLD_ERASE_ERROR	In DCOP (Deferred Check Operation), previous erase
LLD_PREV_OP_RESULT	error happens.
LLD_ILLEGAL_ACCESS	Illegal Read Operation
LLD_READ_DISTURBANCE	1bit ECC error by read disturbance happens.

REMARKS

This function is a mandatory flash operation function.

DCOP (Deferred Check Operation): a method optimizing the operation performance. The DCOP method is a procedure to terminate the function (write or erase) right after the command issue. Then it checks the result of the operation at next function call.



The parameters nPsn and nNumOfScts read data as a unit of a sector.

For more information about the byte alignment, refer to 오류! 참조 원본을 찾을 수 없습니다. 오류! 참조 원본을 찾을 수 없습니다..

SGL data structure is declared in XsrTypes.h.

☐ SGL data structure

```
typedef struct
                 nElements;
   STNTU
                 stSGLEntry[XSR_MAX_SGL_ENTRIES];
   SGLEntry
```

SGLEntry data structure is declared in XsrTypes.h.

☐ **SGLEntry** data structure

```
typedef struct
   UINT8* pBuf;
                   /* Buffer for data
   UINT16 nSectors;
             /* Number of sectors this entry represents
   UINT8 nFlaq;
                   /* user data or meta data
 SGLEntry;
```

SGL is abbreviation for Scatter Gather List. To read whole requested data and store it into several buffers within one function call, we use SGL.

EXAMPLE

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
            nErr;
   UINT32 nDev = 0;
           nVol = 0;
   UINT32
            nPSN = 0;
   UINT32
   UINT32
             nNumOfScts = 1;
   SGL
             stSGL;
             aMBuf[LLD_MAIN_SIZE * nNumOfScts];
   BTMIU
             aSBuf[LLD_SPARE_SIZE * nNumOfScts];
   UINT8
   UINT32
           nFlag = LLD_FLAG_ECC_ON;
   LowFuncTbl stLFT[MAX_VOL];
   PAM_RegLFT((VOID *)stLFT);
   stSGL.stSGLEntry[0].pBuf = aMBuf;
```



```
stSGL.stSGLEntry[0].nSectors = nNumOfScts;
stSGL.stSGLEntry[0].nFlag = SGL_ENTRY_USER_DATA;
stSGL.nElements = 1;
nErr = stLFT[nVol].MRead(nDev, nPSN, nNumOfScts, &stSGL,
                         aSBuf, nFlaq);
if (nErr != LLD SUCCESS)
   printf("XXX Read() fail. ErrCode = %x\n", nErr);
   return (FALSE32);
return (TRUE32);
```

```
ONLD_MRead(UINT32 nDev, UINT32 nPsn, UINT32 nScts, SGL *pstSGL,
UINT8 *pSBuf,
        UINT32 nFlag)
   UINT32 nCnt;
   UINT16 nBSA;
   UINT32 *pONLDMBuf;
   UINT32 *pONLDSBuf;
   UINT32 nBAddr;
   UINT16 nPbn;
   UINT16 nEccRes
                      = (UINT16)0x0;
   UINT16 nEccMask = (UINT16)0x0;
UINT32 nFlag0 = nFlag;
   UINT32 nReadPsn;
   UINT32 nCurReadPsn;
   UINT32 nReadScts = 0;
   UINT32 nCurReadScts;
   UINT32 nRemainScts;
   UINT32 nRet = ONLD_SUCCESS;
         nSGLIdx = 0;
   UINT8
   UINT32 nSctCount = 0;
   BTNIU
          *pMBuf;
   INT32 nRes;
   if (pstSGL == NULL)
      return (ONLD_ILLEGAL_ACCESS);
   nBAddr = GET_DEV_BADDR(nDev);
   if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
      pstPrevOpInfo[nDev]->ePreOp = NONE;
      return nRes;
   pMBuf = pstSGL->stSGLEntry[nSGLIdx].pBuf;
   nRemainScts = nScts;
                = nPsn;
   nReadPsn
   switch (nReadPsn & astONLDInfo[nDev].nSctSelSft)
```



```
case 0:
   nReadScts =
     (astONLDInfo[nDev].nSctsPerPG > nRemainScts) ?
    nRemainScts : astONLDInfo[nDev].nSctsPerPG;
   break;
case 1:
   nReadScts =
     (astONLDInfo[nDev].nSctSelSft > nRemainScts) ?
     nRemainScts : astONLDInfo[nDev].nSctSelSft;
   break;
case 2:
   nReadScts = (2 > nRemainScts) ?
      nRemainScts : 2;
   break;
case 3:
   nReadScts = (1 > nRemainScts) ?
      nRemainScts : 1;
   break;
nPbn = GET_PBN(nDev, nReadPsn);
/* Block Number Set */
ONLD_REG_START_ADDR1(nBAddr) = (UINT16)MAKE_FBA(nPbn);
ONLD_REG_START_ADDR2(nBAddr) = (UINT16)MAKE_DBS(nPbn);
/* Sector Number Set */
ONLD_REG_START_ADDR8(nBAddr) = (UINT16)(
((nReadPsn << astONLDInfo[nDev].nFPASelSft) & MASK_FPA)
(nReadPsn & astONLDInfo[nDev].nFSAMask));
nBSA =
  (UINT16)MAKE BSA(nReadPsn, GET CUR BUF SEL(nDev));
/* Start Buffer Selection */
ONLD REG START BUF(nBAddr) =
  (UINT16)((nBSA & MASK_BSA) | (nReadScts & MASK_BSC));
if (nFlag & ONLD_FLAG_ECC_ON)
   /* System Configuration Reg set (ECC On)*/
   ONLD_DBG_PRINT((TEXT("[ONLD : MSG] ECC ON\r\n")));
   ONLD_REG_SYS_CONF1(nBAddr) &= CONF1_ECC_ON;
}
else
   /* System Configuration Reg set (ECC Off)*/
   ONLD_DBG_PRINT((TEXT("[ONLD : MSG] ECC OFF\r\n")));
   ONLD_REG_SYS_CONF1(nBAddr) |= CONF1_ECC_OFF;
/* INT Stat Reg Clear */
ONLD REG INT(nBAddr)
                        = (UINT16)INT CLEAR;
/* -----*/
/* ONLD Read CMD is issued
/*----*/
```



```
if (pMBuf != NULL)
       /* Page Read Command issue */
      ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_READ_PAGE;
   else
       /* Spare Read Command issue */
      ONLD REG CMD(nBAddr) = (UINT16)ONLD CMD READ SPARE;
   if (nFlagO & ONLD_FLAG_ECC_ON)
       /* ECC Value Bit Mask Setting */
      for (nCnt = 0; nCnt < nReadScts; nCnt++)</pre>
          if (pMBuf != NULL)
             nEccMask = (0x08 << (nCnt * 4));
          if (pSBuf != NULL)
             nEccMask = (0x02 << (nCnt * 4));
      }
   }
   nCurReadPsn = nReadPsn;
   nCurReadScts = nReadScts;
   nRemainScts -= nReadScts;
   nReadPsn += nReadScts;
   nReadScts
       (astONLDInfo[nDev].nSctsPerPG > nRemainScts) ?
       nRemainScts : astONLDInfo[nDev].nSctsPerPG;
   while (GET ONLD INT STAT(nBAddr, PEND READ)
          != (UINT16)PEND_READ)
      /* Wait until device ready */
   }
   if (nFlagO & ONLD_FLAG_ECC_ON)
      /* No Cache Read */
      nEccRes = (ONLD_REG_ECC_STAT(nBAddr) & nEccMask);
      if (nEccRes != 0)
          nRet = ONLD_READ_ERROR | nEccRes;
   }
while (nRemainScts > 0)
   nPbn = GET_PBN(nDev, nReadPsn);
```



```
nSctCount += nCurReadScts;
if (nSctCount == pstSGL->stSGLEntry[nSGLIdx].nSectors)
   nSctCount = 0;
   nSGLIdx++;
if (pstSGL->stSGLEntry[nSGLIdx].nFlag
    == SGL_ENTRY_META_DATA)
{
   nReadPsn += pstSGL->stSGLEntry[nSGLIdx].nSectors;
   nReadScts -= pstSGL->stSGLEntry[nSGLIdx].nSectors;
   nRemainScts -= pstSGL->stSGLEntry[nSGLIdx].nSectors;
   nSctCount = 0;
   nSGLIdx++;
   if (GET_SCTS_PER_PG(nDev) == 2)
      nCurReadPsn = nReadPsn;
      nCurReadScts = nReadScts;
      nReadScts
         (astONLDInfo[nDev].nSctsPerPG > nRemainScts) ?
         nRemainScts : astONLDInfo[nDev].nSctsPerPG;
      continue;
   }
}
/* Block Number Set */
ONLD_REG_START_ADDR1(nBAddr) = (UINT16)MAKE_FBA(nPbn);
ONLD_REG_START_ADDR2(nBAddr) = (UINT16)MAKE_DBS(nPbn);
/* Sector Number Set */
ONLD REG START ADDR8(nBAddr) = (UINT16)(
 ((nReadPsn << astONLDInfo[nDev].nFPASelSft) & MASK FPA)
  (nReadPsn & astONLDInfo[nDev].nFSAMask));
nBSA =
   (UINT16)MAKE_BSA(nReadPsn, GET_NXT_BUF_SEL(nDev));
/* Start Buffer Selection */
ONLD_REG_START_BUF(nBAddr)
   (UINT16)((nBSA & MASK_BSA) | (nReadScts & MASK_BSC));
/* INT Stat Reg Clear */
ONLD_REG_INT(nBAddr) = (UINT16)INT_CLEAR;
/*----*/
/* ONLD Read CMD is issued
/*____*/
if (pMBuf != NULL)
   ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_READ_PAGE;
else
   ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_READ_SPARE;
```



```
pONLDMBuf = (UINT32*)GET_ONLD_MBUF_ADDR(
           nBAddr, nCurReadPsn, GET_CUR_BUF_SEL(nDev));
      pONLDSBuf = (UINT32*)GET_ONLD_SBUF_ADDR(
           nBAddr, nCurReadPsn, GET_CUR_BUF_SEL(nDev));
if (pMBuf != NULL)
   /* Memcopy for main data */
   _ReadMain(pMBuf, pONLDMBuf, nCurReadScts);
   pMBuf += (ONLD_MAIN_SIZE * nCurReadScts);
}
if (pSBuf != NULL)
   /* Memcopy for main data */
   _ReadSpare(pSBuf, pONLDSBuf, nCurReadScts);
   pSBuf += (ONLD_SPARE_SIZE * nCurReadScts);
}
if (nFlagO & ONLD_FLAG_ECC_ON)
   /* ECC Value Bit Mask Setting */
   for (nCnt = 0; nCnt < nReadScts; nCnt++)</pre>
      if (pMBuf != NULL)
          nEccMask = (0x08 << (nCnt * 4));
      if (pSBuf != NULL)
          nEccMask = (0x02 << (nCnt * 4));
   }
}
pstPrevOpInfo[nDev]->nBufSel = GET NXT BUF SEL(nDev);
nCurReadPsn = nReadPsn;
nCurReadScts = nReadScts;
nRemainScts -= nReadScts;
nReadPsn
           += nReadScts;
nReadScts
  (astONLDInfo[nDev].nSctsPerPG > nRemainScts) ?
   nRemainScts : astONLDInfo[nDev].nSctsPerPG;
while (GET_ONLD_INT_STAT(nBAddr, PEND_READ)
       != (UINT16)PEND_READ)
   /* Wait until device ready */
if (nFlagO & ONLD_FLAG_ECC_ON)
   /* No Cache Read */
   nEccRes = (ONLD_REG_ECC_STAT(nBAddr) & nEccMask);
   if (nEccRes != 0)
```



```
nRet = ONLD_READ_ERROR | nEccRes;
   }
   pONLDMBuf = (UINT32*)GET_ONLD_MBUF_ADDR(
       nBAddr, nCurReadPsn, GET_CUR_BUF_SEL(nDev));
   pONLDSBuf = (UINT32*)GET_ONLD_SBUF_ADDR(
       nBAddr, nCurReadPsn, GET_CUR_BUF_SEL(nDev));
   if (pMBuf != NULL)
      /* Memcopy for main data */
      _ReadMain(pMBuf, pONLDMBuf, nCurReadScts);
      pMBuf += (ONLD_MAIN_SIZE * nCurReadScts);
   }
   if (pSBuf != NULL)
      /* Memcopy for spare data */
      _ReadSpare(pSBuf, pONLDSBuf, nCurReadScts);
      pSBuf += (ONLD_SPARE_SIZE * nCurReadScts);
   }
   pstPrevOpInfo[nDev]->nBufSel
      GET_NXT_BUF_SEL(nDev);
return (nRet);
```

XXX_Read, XXX_Write, XXX_Erase, XXX_Copyback, XXX_MWrite, XXX_MErase, XXX_EraseVerify



XXX MWrite

DESCRIPTION

This function writes data into NAND flash memory. XXX_MWrite, unlikely XXX_Write, only write sectors within a block boundry.

SYNTAX

INT32 XXX_MWrite(UINT32 nDev, UINT32 nPsn, UINT32 nNumOfScts, SGL *pstSGL, UINT8 *pSBuf, UINT32 nFlag, UINT32 *pErrPsn)

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
nPsn	UINT32	In	Physical Sector Number
nNumOfScts	UINT32	In	Number of sectors
pstSGL	SGL *	In	Scatter gather list structure for main array of
			NAND flash memory
pSBuf	UINT8 *	In	Memory buffer for spare array of NAND
			flash memory
nFlag	UINT32	In	Operation options (ECC on/off, Sync/Async)
pErrPsn	UINT32 *	Out	Pointer of the sector number where the error
			occurs.
			When an error occurs, this function stops the
			write operation. The errored physical sector
			number is put on this parameter.

nFlag has the the operation options as follows.

Flag	Value	Description
LLD_FLAG_ASYNC_OP	(1 << 0)	Asynchronous Operation
LLD_FLAG_SYNC_OP	(0 << 0)	Synchronous Operation
LLD_FLAG_ECC_ON	(1 << 1)	ECC on (Read Operation with ECC)
LLD_FLAG_ECC_OFF	(0 << 1)	ECC off (Read Operation without ECC)

Flag value is devided into Sync/Async Operation flag and ECC on/off flag. These two flags can be merged as follow.

nFlag = LLD_FLAG_SYNC_OP | LLD_FLAG_ECC_ON;

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Write Success
LLD_WRITE_ERROR	Write Failure
LLD_WRITE_ERROR	In DCOP (Deferred Check Operation), previous
LLD_PREV_OP_RESULT	write error happens
LLD_ERASE_ERROR	In DCOP (Deferred Check Operation), previous
LLD_PREV_OP_RESULT	erase error happens
LLD_WR_PROTECT_ERROR	Write Operation at Locked Area
LLD_ILLEGAL_ACCESS	Illegal Write Operation



REMARKS

This function is a mandatory flash operation function.

DCOP(Deferred Check Operation): a method optimizing the operation performance. The DCOP method is a procedure to terminate the function (write or erase) right after the command issue. Then it checks the result of the operation at next function call.

The parameters nPsn and nNumOfScts write data as a unit of a sector. For more information about the byte alignment, refer to 오류! 참조 원본을 찾을 수 없습니다. 오류! 참조 원본을 찾을 수 없습니다..

SGL data structure is declared in XsrTypes.h.

□ **SGL** data structure

```
typedef struct
   UINT8
                 nElements;
                 stSGLEntry[XSR MAX SGL ENTRIES];
   SGLEntry
  SGL;
```

SGLEntry data structure is also declared in XsrTypes.h.

☐ SGLEntry data structure

```
typedef struct
   UINT8* pBuf;
                    /* Buffer for data
   UINT16 nSectors;
              /\,{}^{\star} Number of sectors this entry represents
                                                             * /
   UINT8 nFlag;
                   /* user data or meta data
  SGLEntry;
```

SGL is abbreviation for Scatter Gather List. To write whole requested data which exists in several different buffers within one function call, we use SGL.

This function does not support asynchronous mode, whereas XXX_Write supports asynchronous mode.

EXAMPLE

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h>
                  /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
             nErr;
   UINT32
             nDev = 0;
   UINT32
             nVol = 0;
   UINT32
             nPSN = 0;
```



```
stSGL;
SGL
         aMBuf[LLD_MAIN_SIZE * nNumOfScts];
UINT8
         aSBuf[LLD_SPARE_SIZE * nNumOfScts];
UINT8
UINT32
         nFlag = LLD_FLAG_ECC_ON | LLD_FLAG_SYNC_OP;
LowFuncTbl stLFT[MAX_VOL];
PAM ReqLFT((VOID *)stLFT);
stSGL.stSGLEntry[0].pBuf = aMBuf;
stSGL.stSGLEntry[0].nSectors = nNumOfScts;
stSGL.stSGLEntry[0].nFlag = SGL_ENTRY_USER_DATA;
stSGL.nElements = 1;
nErr = stLFT[nVol].MWrite(nDev, nPSN, nNumOfScts, &stSGL,
                          aSBuf, nFlag);
if (nErr != LLD_SUCCESS)
   printf("XXX_Write() fail. ErrCode = %x\n", nErr);
   return (FALSE32);
return (TRUE32);
```

```
INT32
ONLD_MWrite(UINT32 nDev, UINT32 nPsn, UINT32 nScts, SGL *pstSGL,
           UINT8 *pSBuf, UINT32 nFlag, UINT32 *pErrPsn)
   UINT16 nBSA;
   UINT32 *pONLDMBuf;
   UINT32 *pONLDSBuf;
   UINT32 nBAddr;
   UINT32 nPbn;
   UINT32 nWritePsn;
   UINT32 nWriteScts = 0;
   UINT32 nTmpWriteScts;
   UINT8 nBiWriteScts;
   UINT8 nSnapWriteScts;
   UINT32 nRemainScts;
   INT32 nRes;
   UINT8 nSGLIdx;
   UINT8 nSGLCount;
   UINT32 nSctCount = 0;
   UINT8 *pMBuf;
   UINT8 *pSGLBuf = NULL;
   UINT8 nIdx;
   UINT8   nPreSGLIdx = 0;
   UINT8 nTmpRemainScts = 0;
   SGLEntry *pSGLEnt;
   if (pstSGL == NULL)
      return (ONLD_ILLEGAL_ACCESS);
   nBAddr = GET_DEV_BADDR(nDev);
```



```
if ((GET DEV DID(nDev) & 0x0008) == DDP CHIP)
   if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
      return nRes;
/* Previous Operation should be flushed at a upper layer */
if (nFlag & ONLD FLAG ECC ON)
   /* System Configuration Reg set (ECC On)*/
   ONLD_REG_SYS_CONF1(nBAddr) &= CONF1_ECC_ON;
else
   /* System Configuration Reg set (ECC Off)*/
   ONLD_REG_SYS_CONF1(nBAddr) |= CONF1_ECC_OFF;
/* Set user Data Buffer point */
for (nSGLIdx = 0; nSGLIdx < pstSGL->nElements; nSGLIdx++)
   if (pstSGL->stSGLEntry[nSGLIdx].nFlag ==
       SGL_ENTRY_USER_DATA)
      pMBuf = pstSGL->stSGLEntry[nSGLIdx].pBuf;
      break;
   }
}
nSGLIdx
           = 0;
nRemainScts = nScts;
nWritePsn = nPsn;
switch (nWritePsn & astONLDInfo[nDev].nSctSelSft)
   case 0:
    nWriteScts =
        (astONLDInfo[nDev].nSctsPerPG > nRemainScts) ?
         nRemainScts : astONLDInfo[nDev].nSctsPerPG;
    break;
   case 1:
     nWriteScts =
        (astONLDInfo[nDev].nSctSelSft > nRemainScts) ?
         nRemainScts : astONLDInfo[nDev].nSctSelSft;
    break;
   case 2:
     nWriteScts = (2 > nRemainScts) ? nRemainScts : 2;
    break;
   case 3:
    nWriteScts = (1 > nRemainScts) ? nRemainScts : 1;
    break;
}
while (nRemainScts > 0)
   nPbn = GET_PBN(nDev, nWritePsn);
```



```
nTmpWriteScts = nWriteScts;
nSGLCount = 0;
if (nSctCount != 0 &&
    pstSGL->stSGLEntry[nSGLIdx].nSectors - nSctCount <</pre>
    nTmpWriteScts)
{
   nTmpRemainScts =
      pstSGL->stSGLEntry[nSGLIdx].nSectors-nSctCount;
}
do
   nSctCount += 1;
   if (nSctCount >=
       pstSGL->stSGLEntry[nSGLIdx].nSectors)
      nSctCount = 0;
      nSGLIdx++;
      nSGLCount++;
   else if (nWriteScts == 1)
      nSGLCount++;
} while(--nWriteScts);
nBiWriteScts = 0;
nSnapWriteScts = 0;
ONLD_REG_START_ADDR2(nBAddr) = (UINT16)MAKE_DBS(nPbn);
pONLDMBuf = (UINT32*)GET ONLD MBUF ADDR(
            nBAddr, nWritePsn, GET NXT BUF SEL(nDev));
pONLDSBuf = (UINT32*)GET ONLD SBUF ADDR(
            nBAddr, nWritePsn, GET NXT BUF SEL(nDev));
for (nIdx = 0; nIdx < nSGLCount; nIdx++)</pre>
   pSGLEnt = pstSGL->stSGLEntry[nPreSGLIdx + nIdx];
   switch(pSGLEnt->nFlag)
   case SGL_ENTRY_BISCT_VALID_DATA:
      pSGLBuf
                   = pSGLEnt->pBuf;
      nBiWriteScts += pSGLEnt->nSectors;
                    = pSGLEnt->nSectors;
      nWriteScts
      break;
   case SGL_ENTRY_BISCT_INVALID_DATA:
      pSGLBuf
                    = pSGLEnt->pBuf;
      nBiWriteScts += pSGLEnt->nSectors;
      nWriteScts
                    = pSGLEnt->nSectors;
      break;
   case SGL_ENTRY_META_DATA:
      pSGLBuf
                     = pSGLEnt->pBuf;
      nSnapWriteScts += pSGLEnt->nSectors;
      nWriteScts
                      = pSGLEnt->nSectors;
```



```
break;
   case SGL_ENTRY_USER_DATA:
      if (nTmpRemainScts != 0)
          nWriteScts
                       = nTmpRemainScts;
          nTmpRemainScts = 0;
      else
          nWriteScts
          nTmpWriteScts - nBiWriteScts - nSnapWriteScts;
          if (nWriteScts > pSGLEnt->nSectors)
             nWriteScts = pSGLEnt->nSectors;
      break;
   default:
      return (ONLD_ILLEGAL_ACCESS);
   if (pSGLEnt->nFlag != SGL_ENTRY_USER_DATA
       && pSGLBuf != NULL)
      _WriteMain(pSGLBuf, pONLDMBuf, nWriteScts);
      pONLDMBuf += (BUFF_MAIN_SIZE * nWriteScts);
   else if (pMBuf != NULL)
       /* Memcopy for main data */
      _WriteMain(pMBuf, pONLDMBuf, nWriteScts);
               += (ONLD_MAIN_SIZE * nWriteScts);
      pONLDMBuf += (BUFF_MAIN_SIZE * nWriteScts);
}
nPreSGLIdx = nSGLIdx;
nWriteScts = nTmpWriteScts;
if (pSBuf != NULL)
   /* Memcopy for spare data */
   _WriteSpare(pSBuf, pONLDSBuf, nWriteScts);
   pSBuf += (ONLD_SPARE_SIZE * nWriteScts);
}
else
   /* Memset for spare data 0xff*/
   MEMSET(pONLDSBuf, 0xFF,
           (ONLD_SPARE_SIZE * nWriteScts));
if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
   *pErrPsn = pstPrevOpInfo[nDev]->nPsn;
   return nRes;
```



```
/* Block Number Set */
   ONLD_REG_START_ADDR1(nBAddr) = (UINT16)MAKE_FBA(nPbn);
   /* Sector Number Set */
   ONLD_REG_START_ADDR8(nBAddr) =
   (UINT16)(((nWritePsn << astONLDInfo[nDev].nFPASelSft)</pre>
   & MASK FPA)
    (nWritePsn & astONLDInfo[nDev].nFSAMask));
   nBSA =
      (UINT16) MAKE BSA(nWritePsn, GET NXT BUF SEL(nDev));
   ONLD_REG_START_BUF(nBAddr)
      (UINT16)((nBSA & MASK_BSA) | (nWriteScts & MASK_BSC));
   /* INT Stat Reg Clear */
   ONLD_REG_INT(nBAddr)
                         = (UINT16)INT_CLEAR;
   /*____*/
   /* ONLD Write CMD is issued
   /*----*/
   if (pMBuf != NULL | | pSGLBuf != NULL)
      ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_WRITE_PAGE;
   }
   else
   {
      ONLD REG CMD(nBAddr) = (UINT16)ONLD CMD WRITE SPARE;
   }
   pstPrevOpInfo[nDev]->ePreOp = WRITE;
  pstPrevOpInfo[nDev]->nScts = nWriteScts
pstPrevOpInfo[nDev]
                               = nWriteScts;
   nRemainScts -= nWriteScts;
   nWritePsn += nWriteScts;
   nWriteScts =
      (astONLDInfo[nDev].nSctsPerPG > nRemainScts) ?
       nRemainScts : astONLDInfo[nDev].nSctsPerPG;
   pstPrevOpInfo[nDev]->nBufSel
      GET_NXT_BUF_SEL(nDev);
return (ONLD_SUCCESS);
```

XXX_Read, XXX_Write, XXX_Erase, XXX_Copyback, XXX_MRead, XXX MErase, XXX EraseVerify



XXX MErase

DESCRIPTION

This function erases blocks of NAND flash memory. XXX_MErase, unlikely XXX_Erase, erases multiple blocks simultaneously. When a device supports multi-block erase operation, XXX MErase can be used.

SYNTAX

XXX_MErase(UINT32 nDev, LLDMEArg *pstMEArg, UINT32 nFlag)

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
pstMEArg	LLDMEArg	In	Pointer to LLDMEArg data structure
nFlag	UINT32	In	Operation options (Sync/Async)

nFlag has the the operation options as follows.

Flag	Value	Description
LLD_FLAG_ASYNC_OP	(1 << 0)	Asynchronous Operation
LLD_FLAG_SYNC_OP	(0 << 0)	Synchronous Operation

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Erase Success
LLD_WR_PROTECT_ERROR	In DCOP (Deferred Check Operation), previous write
LLD_PREV_OP_RESULT	Protection error happens
LLD_PREV_WRITE_ERROR	In DCOP (Deferred Check Operation), previous write
LLD_PREV_OP_RESULT	error happens
LLD_PREV_ERASE_ERROR	In DCOP (Deferred Check Operation), previous erase
LLD_PREV_OP_RESULT	error happens
LLD_ILLEGAL_ACCESS	Illigal Erase Operation

REMARKS

This function is a mandatory flash operation function.

DCOP(Deferred Check Operation): a method optimizing the operation performance. The DCOP method is a procedure to terminate the function (write or erase) right after the command issue. Then it checks the result of the operation at next function call.

In order to support asynchronous mode, codes which execute next steps must be added. First, check the value of a flag. And then, clear an interrupt. Finally, enable the interrupt. For more information about the interrupt, refer to Chapter 오류! 참조 원본을 찾을 수 없습니다. 오류! 참조 원본을 찾을 수 없습니다.

XXX_MErase can be used by only devices which support multi-block erase feature (for example OneNAND256). Multi-block erase operation erases multiple blocks simultaneously. The unit of erase operation is 16 blocks at maximum. After XXX_MErase,



the blocks must be verified by XXX_EraseVerify.

XXX MErase must have information about blocks to be erased. **LLDMEArg** data structure and LLDMEList data structure that are required for additional information are as follows

LLDMEArg data structure is declared in LLD.h.

☐ **LLDMEArg** data structure

```
typedef struct {
   LLDMEList *pstMEList; /* Pointer to LLDMEList
             nNumOfMList; /* Number of Entries of LLDMEList */
   UINT16
              nBitMapErr; /* Error Bitmap Position of MEList */
   UINT16
   BOOL32
              bFlaq;
                           /* Valid Flag
 LLDMEArg;
```

Table 5-3 describes LLDMEArg data structure.

Table 5-3. LLDMEArg data structure in LLD.h

Member Varilable	Description
pstMEList	Pointer to LLDMEList data structure
nNumOfMList	Number of blocks to be erased simultaneously. The maximum number of blocks is 16.
nBitMapErr	Each bit indicates whether error occurs or not for each block
bFlag	Valid flag for a block list in LLDMEList

LLDMEList data structure is also declared in LLD.h.

☐ **LLDMEList** data structure

```
typedef struct {
   UINT16 nMEListSbn; /* MEList Semi-physical Block Number */
   UINT16 nMEListPbn; /* MEList Physical Block Number
} LLDMEList;
```

Table 5-4 describes LLDMEList data structure.

Table 5-4. LLDMEList data structure in LLD.h

Member Varilable	Description
nMEListSbn	Semi-physical block number of a block in block list
nMEListPbn	Physical block number of a block in block list

EXAMPLE

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
```



```
Example(VOID)
   INT32
            nErr;
            nDev = 0;
   UINT32
           nVol = 0;
   UINT32
   UINT16
            nPbn = 13;
   UINT16
            nSbn = 13;
   UINT16
            nNum = 0;
            nNumOfPbn = 1;
   UINT16
            nFlag = LLD FLAG ASYNC OP;
   UINT32
   LowFuncTbl stLFT[MAX_VOL];
   LLDMEArg *pstLLDMEArg[XSR_MAX_DEV];
   LLDMEList *pstLLDMEList;
   pstLLDMEArg[nDev]->nBitMapErr = (UINT16)0x0;
   pstLLDMEArg[nDev]->nNumOfMList = nNumOfPbn;
   pstLLDMEArg[nDev]->bFlag
                              = TRUE32;
   pstLLDMEList = pstLLDMEArg[nDev]->pstMEList;
   pstLLDMEList[nNum].nMEListSbn = nSbn;
   pstLLDMEList[nNum].nMEListPbn = nPbn;
   PAM_RegLFT((VOID *)stLFT);
   nErr = stLFT[nVol].MErase(nDev, pstLLDMEArg[nDev], nFlag)
   if (nErr != LLD SUCCESS)
      printf("XXX_MErase()fail. ErrCode = %x\n", nErr);
      return (FALSE32);
   return (TRUE32);
```

```
ONLD_MErase(UINT32 nDev, LLDMEArg *pstMEArg, UINT32 nFlag)
   UINT32
             nBAddr, nPbn;
   UINT32
             nCurPbn;
   UINT32
             nFirstchipPbn = 0xffff;
   UINT32
             nSecondchipPbn = 0xffff;
   UINT16
              nCnt;
   INT32
              nRes;
   INT32
             nRet = ONLD_SUCCESS;
   LLDMEList *pstMEPList;
   nBAddr = GET_DEV_BADDR(nDev);
   if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
      return nRes;
   pstMEPList = pstMEArg->pstMEList;
   for(nCnt = 0; nCnt < pstMEArg->nNumOfMList; nCnt++)
    nCurPbn = pstMEPList[nCnt].nMEListPbn;
```



```
if ((((nCurPbn << 5) & MASK_DBS) == 0x0000)
     && (nFirstchipPbn == 0xffff))
     nFirstchipPbn = nCurPbn;
     continue;
 else if (((nCurPbn << 5) \& MASK DBS) == 0x8000)
          && (nSecondchipPbn == 0xffff))
     nSecondchipPbn = nCurPbn;
     continue;
 /* Block Number Set */
 ONLD_REG_START_ADDR1(nBAddr) = (UINT16)MAKE_FBA(nCurPbn);
 ONLD_REG_START_ADDR2(nBAddr) =(UINT16)MAKE_DBS(nCurPbn);
 if(ONLD_REG_WR_PROTECT_STAT(nBAddr) !=
       (UINT16)(UNLOCKED_STAT))
    return (ONLD_WR_PROTECT_ERROR);
 /* INT Stat Reg Clear */
 ONLD_REG_INT(nBAddr)
                          = (UINT16)INT_CLEAR;
 /*____*/
 /* ONLD Erase CMD is issued
 /*----*/
 ONLD REG CMD(nBAddr) = (UINT16)ONLD CMD ERASE MBLK;
 while (GET_ONLD_INT_STAT(nBAddr, PEND_INT) !=
       (UINT16)PEND_INT)
 {
    /* Wait until device ready */
if ((nFirstchipPbn != 0xffff) && (nSecondchipPbn != 0xffff))
   /* Block Number Set */
  ONLD_REG_START_ADDR1(nBAddr) =
         (UINT16)MAKE_FBA(nFirstchipPbn);
  ONLD_REG_START_ADDR2(nBAddr) =
        (UINT16)MAKE_DBS(nFirstchipPbn);
   if (ONLD_REG_WR_PROTECT_STAT(nBAddr) !=
        (UINT16)(UNLOCKED_STAT))
      return (ONLD_WR_PROTECT_ERROR);
   /* INT Stat Reg Clear */
  ONLD_REG_INT(nBAddr)
                           = (UINT16)INT_CLEAR;
  ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_ERASE_BLK;
   while (GET_ONLD_INT_STAT(nBAddr, PEND_ERASE) !=
         (UINT16)PEND_ERASE)
```



```
/* Wait until device ready */
   /* Block Number Set */
   ONLD_REG_START_ADDR1(nBAddr) =
        (UINT16)MAKE_FBA(nSecondchipPbn);
   ONLD REG START ADDR2(nBAddr) =
        (UINT16)MAKE_DBS(nSecondchipPbn);
   if (ONLD REG WR PROTECT STAT(nBAddr) !=
        (UINT16)(UNLOCKED STAT))
       return (ONLD_WR_PROTECT_ERROR);
   /* INT Stat Reg Clear */
   ONLD_REG_INT(nBAddr) = (UINT16)INT_CLEAR;
   ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_ERASE_BLK;
   nPbn = nSecondchipPbn;
else if (nFirstchipPbn != 0xffff)
   /* Block Number Set */
   ONLD_REG_START_ADDR1(nBAddr) =
       (UINT16)MAKE_FBA(nFirstchipPbn);
   ONLD_REG_START_ADDR2(nBAddr) =
       (UINT16)MAKE_DBS(nFirstchipPbn);
   if (ONLD_REG_WR_PROTECT_STAT(nBAddr) !=
        (UINT16)(UNLOCKED_STAT))
   {
       return (ONLD WR PROTECT ERROR);
   }
   /* INT Stat Req Clear */
   ONLD REG INT(nBAddr)
                           = (UINT16)INT CLEAR;
                          = (UINT16)ONLD_CMD_ERASE_BLK;
   ONLD_REG_CMD(nBAddr)
   nPbn = nFirstchipPbn;
}
else
   /* Block Number Set */
   ONLD_REG_START_ADDR1(nBAddr) =
      (UINT16)MAKE_FBA(nSecondchipPbn);
   ONLD_REG_START_ADDR2(nBAddr) =
      (UINT16)MAKE_DBS(nSecondchipPbn);
   if (ONLD_REG_WR_PROTECT_STAT(nBAddr) !=
       (UINT16)(UNLOCKED_STAT))
       return (ONLD_WR_PROTECT_ERROR);
   /* INT Stat Reg Clear */
   ONLD_REG_INT(nBAddr) = (UINT16)INT_CLEAR;
ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_ERASE_BLK;
   nPbn = nSecondchipPbn;
```



```
while (GET_ONLD_INT_STAT(nBAddr, PEND_ERASE)
           != (UINT16)PEND_ERASE)
      /* Wait until device ready */
}
pstPrevOpInfo[nDev]->ePreOp = MERASE;
pstPrevOpInfo[nDev]->nFlag = nFlag;
pstPrevOpInfo[nDev]->nPsn = nPbn * GET_SCTS_PER_BLK(nDev);
MEMCPY(pstPrevOpInfo[nDev]->pstPreMEArg,
       pstMEArg, sizeof(LLDMEArg));
/* in case of async mode, interrupt should be enabled */
if (nFlag & ONLD_FLAG_ASYNC_OP)
   PAM_ClearInt((UINT32)XSR_INT_ID_NAND_0);
   PAM_EnableInt((UINT32)XSR_INT_ID_NAND_0);
return nRet;
```

XXX_Read, XXX_Write, XXX_Erase, XXX_Copyback, XXX_MRead, XXX_MWrite, XXX_EraseVerify



XXX EraseVerify

DESCRIPTION

This function verifies an erase operation whether it checks blocks are properly erased. Mainly this function is used with XXX_MErase function.

SYNTAX

INT32

MyLLD EraseVerify(UINT32 nDev, LLDMEArg *pstMEArg, UINT32 nFlag)

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
pstMEArg	LLDMEArg	In	Pointer to LLDMEArg data structure
nFlag	UINT32	In	Operation options (Sync/Async)

nFlag has the the operation options as follows.

Flag	Value	Description
LLD_FLAG_ASYNC_OP	(1 << 0)	Asynchronous Operation
LLD_FLAG_SYNC_OP	(0 << 0)	Synchronous Operation

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Erase Success
LLD_WR_PROTECT_ERROR	In DCOP (Deferred Check Operation), previous write
LLD_PREV_OP_RESULT	Protection error happens
LLD_PREV_WRITE_ERROR	In DCOP (Deferred Check Operation), previous write
LLD_PREV_OP_RESULT	error happens
LLD_PREV_ERASE_ERROR	In DCOP (Deferred Check Operation), previous erase
LLD_PREV_OP_RESULT	error happens
LLD_ERASE_ERROR	Erase Failure

REMARKS

This function is a mandatory flash operation function.

DCOP(Deferred Check Operation): a method optimizing the operation performance. The DCOP method is a procedure to terminate the function (write or erase) right after the command issue. Then it checks the result of the operation at next function call.

After erase operation, XXX_EraseVerify checks all blocks in LLDMEList of LLDMEArg. If blocks that is not erased properly are detected, XXX_EraseVerify returns erase error. XXX MErase requires XXX EraseVerify becasuse XXX MErase does not support the functionality to verify erase errors. XXX_EraseVerify only can be used when a device supports erase verify functionality. For more information about LLDMEList and LLDMEArg data structure, refer to the API page of XXX_MErase.

EXAMPLE



(1) Example to call the function

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
            nErr;
           nDev = 0;
   UINT32
           nVol = 0;
   UINT32
            nPbn = 13;
   UINT16
            nSbn = 13;
   UINT16
           nNum = 0;
   UINT16
            nNumOfPbn = 1;
   UINT16
   UINT32    nFlag = LLD_FLAG_ASYNC_OP;
   LowFuncTbl stLFT[MAX_VOL];
   LLDMEArg *pstLLDMEArg[XSR_MAX_DEV];
   LLDMEList *pstLLDMEList;
   pstLLDMEArg[nDev]->nBitMapErr = (UINT16)0x0;
   pstLLDMEArg[nDev]->nNumOfMList = nNumOfPbn;
                                 = TRUE32;
   pstLLDMEArg[nDev]->bFlag
   pstLLDMEList = pstLLDMEArg[nDev]->pstMEList;
   pstLLDMEList[nNum].nMEListSbn = nSbn;
   pstLLDMEList[nNum].nMEListPbn = nPbn;
   PAM ReqLFT((VOID *)stLFT);
   nErr = stLFT[nDev].EraseVerify(nDev, pstLLDMEArg[nDev],
                                                     nFlaq)
   if (nErr != LLD_SUCCESS)
      printf("XXX_EraseVerify()fail. ErrCode = %x\n", nErr);
      return (FALSE32);
   return (TRUE32);
```

```
INT32
ONLD_EraseVerify(UINT32 nDev, LLDMEArg *pstMEArg, UINT32 nFlag)
   UINT32
              nBAddr;
   UINT32
              nCnt;
              nRet = ONLD SUCCESS;
   TNT32
   LLDMEList *pstMEPList;
   nBAddr = GET_DEV_BADDR(nDev);
   /* for verify */
   pstMEPList = pstMEArg->pstMEList;
```



```
if((nFlag & ONLD FLAG SYNC MASK) == ONLD FLAG SYNC OP)
   while (GET_ONLD_INT_STAT(nBAddr, PEND_ERASE)
          != (UINT16)PEND_ERASE)
   {
      /* Wait until device ready */
   pstPrevOpInfo[nDev]->ePreOp = NONE;
for(nCnt = 0; nCnt < pstMEArg->nNumOfMList; nCnt++)
   /* Block Number Set */
   ONLD_REG_START_ADDR1(nBAddr)
        = (UINT16)MAKE_FBA(pstMEPList[nCnt].nMEListPbn);
   ONLD_REG_START_ADDR2(nBAddr)
        = (UINT16)MAKE_DBS(pstMEPList[nCnt].nMEListPbn);
   /* Erase Verify Command issue */
   ONLD_DBG_PRINT((TEXT("[ONLD:MSG] Erase Verify\r\n")));
    /* INT Stat Reg Clear */
   ONLD_REG_INT(nBAddr) = (UINT16)INT_CLEAR;
   ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_ERASE_VERIFY;
   while (GET_ONLD_INT_STAT(nBAddr, PEND_INT)
          != (UINT16)PEND INT)
   {
      /* Wait until device ready */
   }
   /* Erase Operation Verifying Error Check */
   if (GET ONLD CTRL STAT(nBAddr, ERROR STATE)
       == ERROR STATE)
   {
      pstMEArg->nBitMapErr |= (1 << nCnt);</pre>
      nRet = LLD MERASE ERROR;
   }
return (nRet);
```

XXX_Read, XXX_Write, XXX_Erase, XXX_Copyback, XXX_MRead, XXX_MWrite, XXX_MErase



XXX CopyBack

DESCRIPTION

This function copies data by using internal buffer in the device.

SYNTAX

INT32 XXX_CopyBack(UINT32 nDev, CpBkArg *pstCpArg, UINT32 nFlag)

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
pstCpArg	CpBkArg	In	Pointer to CpBkArg data structure
nFlag	UINT32	In	Operation options (ECC on/off, Sync/Async)

nFlag has the operaion options as follows.

Flag	Value	Description
LLD_FLAG_ASYNC_OP	(1 << 0)	Asynchronous Operation
LLD_FLAG_SYNC_OP	(0 << 0)	Synchronous Operation
LLD_FLAG_ECC_ON	(1 << 1)	ECC on (Read Operation with ECC)
LLD_FLAG_ECC_OFF	(0 << 1)	ECC off (Read Operation without ECC)

Flag value is divided into Sync/Async Operation flag and ECC on/off flag. These two flags can be merged as follows.

nFlag = LLD_FLAG_SYNC_OP | LLD_FLAG_ECC_ON;

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Copyback Success
LLD_READ_ ERROR ECC	Data Integrity Fault (1 or 2bit ECC error)
result code	
LLD_WRITE_ERROR	Write Operation Error
LLD_PREV_WRITE_ERROR	In DCOP (Deferred Check Operation), previous write
LLD_PREV_OP_RESULT	error happens
LLD_PREV_ERASE_ERROR	In DCOP (Deferred Check Operation), previous erase
LLD_PREV_OP_RESULT	error happens
LLD_ILLEGAL_ACCESS	Illegal Copyback Operaion

REMARKS

This function is mandatory.

DCOP(Deferred Check Operation): a method optimizing the operation performance. The DCOP method is a procedure to terminate the function (write or erase) right after the command issue. Then it checks the result of the operation at next function call.

Examples in this document do not implement the interrupt, because this Copyback example is implemented by calling Read and Write functions directly. If implementation of



Copyback does not call Read and Write functions directly, codes which execute next steps must be added to support asynchronous mode. First, check the value of a flag. And then, clear an interrupt. Finally, enable the interrupt.

Copyback means the operation method to copy pages using the internal buffer in a NAND device. This copyback method improves the performance by cutting the transfer time and operation procedure, because this method does not use the external memory. When copying a page using the copyback method, a part of data can be brought the outside device; this is called Random-in.

RndInArg and CpBkArg data structures are declared in XsrTypes.h.

☐ RndInArg data structure

```
typedef struct
   UINT16
             nOffset;
                           /* nOffset : sector offset(0 - 3) * 1024
                            + Main(0 - 511) + Spare(512 - 527) */
   UINT16
             nNumOfBytes;
                            /* Random In Bytes
   UINT8
            *pBuf;
                            /* Data Buffer Pointer
 RndInArg;
```

Table 5-5 describes RndInArg data structure.

Table 5-5. RndInArg data structure in XsrTypes.h

Member Varilable	Description
nNumOfBytes	The size of data to be changed
nOffset	The location of data to Random-in
	Offset: sector offset(0 - 3) * 1024+ Main(0 - 511) + Spare(512 -
	527)
pBuf	The pointer of data to be changed

☐ CpBkArg data structure

```
typedef struct
             nSrcSn;
                            /* Copy Back Source Vsn, should be page
   UINT32
                           aligned */
   UINT32
             nDstSn;
                            /*CopyBackDest. Vsn, shouldbepage
                           aligned */
                           /* Random In Count
   UTNT32
             nRndInCnt;
                                                              * /
   RndInArg *pstRndInArg; /* RndInArg Array pointer
 CpBkArg;
```

Table 5-6 describes CpBkArg data structure.

Table 5-6. CpBkArg data structure in XsrTypes.h

Member Varilable	Description	
nSrcSn	The location of a source page in NAND flash memory	
	Physical sector number aligned at Physical page address	



nDstSn	The location of data to be copied
	Physical sector number aligned at Physical page address
nRndInCnt	The count of Random-in
pstRndInArg	Pointer to RndInArg data structure

EXAMPLE

(1) Example to call the function

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
            nErr;
   UINT32
            nDev = 0;
   UINT32
            nVol = 0;
   UINT8
            aMBuf[XSR MAIN SIZE];
   UINT8
            aSBuf[XSR SPARE SIZE];
   CpBkArg stCpArg;
   RndInArg stRIArg[2];
   UINT32
            nFlag = LLD_FLAG_ASYNC_OP;
   LowFuncTbl stLFT[MAX_VOL];
   PAM_RegLFT((VOID *)stLFT);
   stCpArg.nSrcSn
                          = 32;
                      = 64;
   stCpArg.nDstSn
                        = 2;
   stCpArg.nRndInCnt
   stCpArg.pstRndInArg = &stRIArg[0];
                         = 0;
   stRIArg[0].nOffset
   stRIArg[0].nNumOfBytes = LLD_MAIN_SIZE;
   stRIArg[0].pBuf
                       = &aMBuf[0];
   stRIArg[1].nOffset
                         = 512;
   stRIArg[1].nNumOfBytes = LLD_SPARE_SIZE;
                          = &aSBuf[0];
   stRIArg[1].pBuf
   nErr = stLFT[nVol].CopyBack(nDev, &stCpArg, nFlag);
   if (nErr != LLD_SUCCESS)
      printf("XXX_CopyBack()fail. ErrCode = %x\n", nErr);
      return (FALSE32);
   return (TRUE32);
```

```
ONLD_CopyBack(UINT32 nDev, CpBkArg *pstCpArg, UINT32 nFlag)
   UINT8
                     aBABuf[2];
   UINT8
                    *pRIBuf;
                     nSctNum, nOffset;
   INT32
```



```
nBSA;
UINT16
UINT16
                nEccRes;
UINT32
                nCnt;
                *pONLDMBuf, *pONLDSBuf;
UINT32
                nBAddr;
UINT32
                nRISize;
UINT32
INT32
         nRes;
RndInArg *pstRIArg;
nBAddr = GET_DEV_BADDR(nDev);
if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
   return nRes;
/* Step 1. READ
/*----*/
nPbn = GET_PBN(nDev, pstCpArg->nSrcSn);
/* Block Number Set */
ONLD_REG_START_ADDR1(nBAddr) = (UINT16)MAKE_FBA(nPbn);
/* Device BufferRam Select */
ONLD_REG_START_ADDR2(nBAddr) = (UINT16)MAKE_DBS(nPbn);
/* Sector Number Set */
ONLD_REG_START_ADDR8(nBAddr) = (UINT16)(
    ((pstCpArg->nSrcSn << astONLDInfo[nDev].nFPASelSft)</pre>
     & MASK_FPA)
     (pstCpArg->nSrcSn & astONLDInfo[nDev].nFSAMask));
nBSA = (UINT16)MAKE BSA(0, DATA BUF0);
ONLD REG START BUF(nBAddr) = (UINT16)(
    (nBSA & MASK BSA) | (GET SCTS PER PG(nDev) & MASK BSC));
pONLDMBuf = (UINT32*)GET_ONLD_MBUF_ADDR(
            nBAddr, 0, DATA_BUF0);
pONLDSBuf = (UINT32*)GET_ONLD_SBUF_ADDR(
            nBAddr, 0, DATA_BUF0);
if (nFlag & ONLD_FLAG_ECC_ON)
   /* System Configuration Reg set (ECC On)*/
   ONLD_REG_SYS_CONF1(nBAddr) &= CONF1_ECC_ON;
else
   /* System Configuration Reg set (ECC Off)*/
   ONLD_REG_SYS_CONF1(nBAddr) |= CONF1_ECC_OFF;
/* INT Stat Reg Clear */
                        = (UINT16)INT_CLEAR;
ONLD_REG_INT(nBAddr)
```



```
/*----*/
/* ONLD Read CMD is issued
/*----*/
/* Page Read Command issue */
ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_READ_PAGE;
while (GET ONLD INT STAT(nBAddr, PEND READ)
     != (UINT16)PEND READ)
   /* Wait until device ready */
if (nFlag & ONLD_FLAG_ECC_ON)
  nEccRes = ONLD_REG_ECC_STAT(nBAddr);
  if (nEccRes & ONLD_READ_UERROR_A)
     return (ONLD_READ_ERROR | nEccRes);
/*____*/
/* Step 2. DATA RANDOM IN
/*----*/
pstRIArg = pstCpArg->pstRndInArg;
for (nCnt = 0 ; nCnt < pstCpArg->nRndInCnt ; nCnt++)
  nSctNum = (pstRIArg[nCnt].nOffset / 1024);
  nOffset = (pstRIArg[nCnt].nOffset % 1024);
  pRIBuf = pstRIArg[nCnt].pBuf;
  nRISize = pstRIArg[nCnt].nNumOfBytes;
   if (nOffset < ONLD MAIN SIZE)</pre>
      /* byte align for 16 */
     if ((nOffset % sizeof(UINT16)) != 0)
        pDevBuf =(volatile UINT16*)((UINT32)
                 pONLDMBuf + (nSctNum * ONLD_MAIN_SIZE)
                 + nOffset - 1);
        *(volatile UINT16*)aBABuf = *pDevBuf;
        aBABuf[1] = *pRIBuf++;
         *pDevBuf = *(volatile UINT16*)aBABuf;
        if (--nRISize <= 0)
           continue;
        nOffset++;
     }
     if ((nRISize % sizeof(UINT16)) != 0)
        pDevBuf = (volatile UINT16*)((UINT32)
                  pONLDMBuf + (nSctNum * ONLD_MAIN_SIZE)
```



```
+ nOffset + nRISize - 1);
       *(volatile UINT16*)aBABuf = *pDevBuf;
      aBABuf[0] = *(pRIBuf + nRISize - 1);
       *pDevBuf = *(volatile UINT16*)aBABuf;
      if (--nRISize <= 0)
          continue;
   }
   MEMCPY((UINT8*)((UINT32)
         pONLDMBuf+(nSctNum * ONLD_MAIN_SIZE)+nOffset),
         pRIBuf,
         nRISize);
}
else
   if ((nOffset % sizeof(UINT16)) != 0)
      pDevBuf = (volatile UINT16*)((UINT32)
                 pONLDSBuf + (nSctNum * ONLD_SPARE_SIZE)
                  + (nOffset - ONLD_MAIN_SIZE) - 1);
      *(volatile UINT16*)aBABuf = *pDevBuf;
      aBABuf[1] = *pRIBuf++;
      *pDevBuf = *(volatile UINT16*)aBABuf;
      if (--nRISize <= 0)
          continue;
      nOffset++;
   }
   if ((nRISize % sizeof(UINT16)) != 0)
      pDevBuf = (volatile UINT16*)((UINT32)
                 pONLDSBuf + (nSctNum * ONLD_SPARE_SIZE)
                  + (nOffset - ONLD_MAIN_SIZE)
                  + nRISize - 1);
      *(volatile UINT16*)aBABuf = *pDevBuf;
      aBABuf[0] = *(pRIBuf + nRISize - 1);
       *pDevBuf = *(volatile UINT16*)aBABuf;
      if (--nRISize <= 0)
          continue;
       }
   }
   MEMCPY((UINT8*)((UINT32)
           pONLDSBuf + (nSctNum * ONLD_SPARE_SIZE)
           + (nOffset - ONLD_MAIN_SIZE)),
           pRIBuf,
           nRISize);
```



```
/*----*/
/* Step 3. WRITE
/*----*/
nPbn = GET_PBN(nDev, pstCpArg->nDstSn);
/* Block Number Set */
ONLD_REG_START_ADDR1(nBAddr) = (UINT16)MAKE_FBA(nPbn);
ONLD_REG_START_ADDR2(nBAddr) = (UINT16)MAKE_DBS(nPbn);
/* Sector Number Set */
ONLD_REG_START_ADDR8(nBAddr) = (UINT16)(
       ((pstCpArg->nDstSn << astONLDInfo[nDev].nFPASelSft)</pre>
       & MASK_FPA)
       (pstCpArg->nDstSn & astONLDInfo[nDev].nFSAMask));
nBSA = (UINT16)MAKE_BSA(pstCpArg->nDstSn, DATA_BUF0);
ONLD_REG_START_BUF(nBAddr) = (UINT16)(
        (nBSA & MASK_BSA)
        (GET_SCTS_PER_PG(nDev) & MASK_BSC));
if (nFlag & ONLD_FLAG_ECC_ON)
   /* System Configuration Reg set (ECC On)*/
   ONLD_REG_SYS_CONF1(nBAddr) &= CONF1_ECC_ON;
}
else
{
   /* System Configuration Reg set (ECC Off)*/
   ONLD_REG_SYS_CONF1(nBAddr) |= CONF1_ECC_OFF;
ONLD REG INT(nBAddr) = (UINT16)INT CLEAR;
/*_____*/
/* ONLD Write CMD is issued
                                               * /
/*----*/
/* Main Write Command issue */
ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_WRITE_PAGE;
pstPrevOpInfo[nDev]->ePreOp
                              = CPBACK;
                             = pstCpArg->nDstSn;
pstPrevOpInfo[nDev]->nPsn
pstPrevOpInfo[nDev]->nFst

pstPrevOpInfo[nDev]->nFlag

= pstcpArg->nDstSn;

pstPrevOpInfo[nDev]->nFlag

= pstcpArg->nDstSn;

= GET_SCTS_PER_PG(nDev);

pstPrevOpInfo[nDev]->nFlag

= nFlag;
pstPrevOpInfo[nDev]->nBufSel = DATA_BUF0;
/* in case async mode, interrupt should be enabled */
if (nFlag & ONLD_FLAG_ASYNC_OP)
   PAM_ClearInt((UINT32)XSR_INT_ID_NAND_0);
   PAM_EnableInt((UINT32)XSR_INT_ID_NAND_0);
return (ONLD SUCCESS);
```



XXX_Read, XXX_Write, XXX_Erase, XXX_MRead, XXX_MWrite, XXX_MErase, XXX_EraseVerify



XXX ChkInitBadBlk

DESCRIPTION

This function checks whether a block is an initial bad block or not.

SYNTAX

```
INT32
XXX_ChkInitBadBlk(UINT32 nDev, UINT32 nPbn)
```

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
nPbn	UINT32	In	Physical Block Number

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Bad Block Check Success
LLD_INIT_GOODBLOCK	In a Good Block (Not a Bad Block)
LLD_INIT_BADBLOCK	In an Initial Bad Block
LLD_PREV_WRITE_ERROR	In DCOP (Deferred Check Operation), previous write
LLD_PREV_OP_RESULT	error happens
LLD_PREV_ERASE_ERROR	In DCOP (Deferred Check Operation), previous erase
LLD_PREV_OP_RESULT	error happens
LLD_ILLEGAL_ACCESS	Illegal Operation

REMARKS

This function is mandatory.

DCOP(Deferred Check Operation): a method optimizing the operation performance. The DCOP method is a procedure to terminate the function (write or erase) right after the command issue. Then it checks the result of the operation at next function call.

If the value of the bad mark position in the first or second page of a block is not 0xff(a normal statement), the block is the initial bad block.

EXAMPLE

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
            nErr;
   UINT32 nDev = 0;
   UINT32 nVol = 0;
   UINT32 nPbn = 0;
```



```
LowFuncTbl stLFT[MAX_VOL];
PAM_RegLFT((VOID *)stLFT);
nErr = stLFT[nVol].ChkInitBadBlk(nDev, nPbn);
if (nErr != LLD SUCCESS)
   printf("XXX ChkInitBadBlk()fail. ErrCode = %x\n", nErr);
   return (FALSE32);
return (TRUE32);
```

(2) Example to implement the fuinction in OneNAND

```
INT32
ONLD_ChkInitBadBlk(UINT32 nDev, UINT32 nPbn)
   INT32 nRet;
   UINT16 aSpare[ONLD_SPARE_SIZE / 2];
   UINT32 nPsn;
   UINT32 nBAddr;
   nBAddr = GET_DEV_BADDR(nDev);
   nPsn = nPbn * GET_SCTS_PER_BLK(nDev);
                                                            * /
   nRet = ONLD_Read(nDev,
                             /* Device Number
                                                            * /
                            /* Physical Sector Number
                 nPsn,
                             /* Number of Sectors to be read */
                  (UINT32)1,
                  (UINT8*)NULL,
                           /* Buffer pointer for Main area */
                  (UINT8*)aSpare,
                          /* Buffer pointer for Spare area */
                  (UINT32)ONLD_FLAG_ECC_OFF);/*flag
   if ((nRet != ONLD_SUCCESS) && ((nRet & (0xFFFF0000))
       != (UINT32)ONLD_READ_ERROR))
      return (nRet);
   if (aSpare[0] != (UINT16)VALID_BLK_MARK)
      return (ONLD_INIT_BADBLOCK);
   return (ONLD_INIT_GOODBLOCK);
```

SEE ALSO



XXX SetRWArea

DESCRIPTION

This function is called when NAND device provides write/erase protection functionality in hardware.

SYNTAX

```
INT32
XXX_SetRWArea(UINT32 nDev, UINT32 n1stUB, UINT32 nNumOfUBs)
```

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
n1stUB	UINT32	In	Start block index of unlocked area
nNumOfUBs	UINT32	In	Total number of blocks of unlocked area
			nNumOfUBs = 0, the device is locked.

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Unlock Aea Setting Success
LLD_ILLEGAL_ACCESS	Illegal Setting

REMARKS

This function is optional.

If the hardware does not provide write/erase protection functionality in hardware, a user does not need to implement this function.

EXAMPLE

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
           nErr;
   INT32
   UINT32 nDev = 0;
   nVol = 0;
UINT32 n1stUB = 0:
UINT32
   UINT32 nNumOfUBs = 1024;
   LowFuncTbl stLFT[MAX_VOL];
   PAM_RegLFT((VOID *)stLFT);
   nErr = stLFT[nVol].SetRWArea(nDev, n1stUB, nNumOfUBs);
```



```
if (nErr != LLD_SUCCESS)
   printf("XXX_ SetRWArea()fail. ErrCode = %x\n", nErr);
   return (FALSE32);
return (TRUE32);
```

(2) Example to implement the function in OneNAND

```
ONLD_SetRWArea(UINT32 nDev, UINT32 nSUbn, UINT32 nUBlks)
   INT32 nRes;
   if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
      pstPrevOpInfo[nDev]->ePreOp = NONE;
      return nRes;
   if (astONLDInfo[nDev].SetRWArea != NULL)
      astONLDInfo[nDev].SetRWArea(nDev, nSUbn, nUBlks);
   else
      return (ONLD_ILLEGAL_ACCESS);
   return (ONLD_SUCCESS);
```

SEE ALSO



XXX_IOCtI

DESCRIPTION

This function is called to extend LLD functionality.

SYNTAX

```
INT32
XXX_IOCtl(UINT32 nDev, UINT32 nCode, UINT8 *pBufl,
          UINT32 nLenI, UINT8 *pBufO, UINT32 nLenO,
          UINT32 *pByteRet)
```

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
nCode	UINT32	In	IO Control Command
pBufI	UINT8 *	In	Input Buffer pointer
nLenI	UINT32	In	Length of Input Buffer
pBuf0	UINT8 *	Out	Output Buffer pointer
nLen0	UINT32	In	Length of Output Buffer
pByteRet	UINT32 *	Out	The number of bytes (length) of Output
			Buffer as the result of function call

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Success
LLD_IOC_NOT_SUPPORT	In not-supported command

REMARKS

This function is optional.

DCOP(Deferred Check Operation): a method optimizing the operation performance. The DCOP method is a procedure to terminate the function (write or erase) right after the command issue. Then it checks the result of the operation at next function call.

The following list is IO control code command.

- LLD_IOC_SET_SECURE_LT
- LLD_IOC_SET_BLOCK_LOCK LLD_IOC_GET_SECURE_STAT
- LLD_IOC_RESET_NAND_DEV

The following explains the description, parameters, and return value of each IO control code.

LLD_IOC_SET_SECURE_LT

1. Description



If NAND flash memory supports the lock scheme, this command code lock-tighten the current lock statement.

If NAND flash memory does not support the lock scheme, this command returns LLD_ILLEGAL_ACCESS

2. Parameter

Parameter	Description
nDev	Physical Device Number (0 ~ 7)
nCode	LLD_IOC_SET_SECURE_LT
pBufI	Pointer to Start Block Number and Number of
	Blks if Lock Block device is used.
	Not used if Lock Range device is used
nLenI	Length of Input Buffer if Lock Block device is
	used
	Not used if Lock Range device is used
pBufO	Not used
nLen0	Not used
pByteRet	This value is set as 0 in XXX_IOCtl.

3. Return Value

Return Value	Description
LLD_SUCCESS	Lock-tighten the current lock statement

1. Description

If NAND flash memory supports the lock scheme, this command code locks the blocks given in pBufI.

2. Parameter

Parameter	Description
nDev	Physical Device Number (0 ~ 7)
nCode	LLD_IOC_SET_SECURE_LT
pBufI	Pointer to Start Block Number and Number of
	Blks
nLenI	Length of Input Buffer
pBuf0	Not used
nLen0	Not used
pByteRet	This value is set as 0 in XXX_IOCtl.

3. Return Value

Return Value	Description
LLD_SUCCESS	Lock the blocks given in pBufI



LLD_IOC_GET_SECURE_STAT

1. Description

If NAND flash memory supports the lock scheme, this command code gets the current lock statement. The current lock statement is saved at pBufO.

If NAND flash memory does not support the lock scheme, the current lock statement is LLD_IOC_SECURE_US.

2. Parameter

Parameter	Description
nDev	Physical Device Number (0 ~ 7)
nCode	LLD_IOC_GET_SECURE_STAT
pBufI	Not used
nLenI	Not used
pBufO	Buffer to store return value
nLen0	Length of pBufO
pByteRet	This value is set as output buffer length in
	XXX_IOCtl.

3. Return Value

Return Value	Description
LLD_SUCCESS	Get the current lock statement
LLD_ILLEGAL_ACCESS	The value of pBufO or nLenO parameter is abnormal

4. Remark

There are three values of the lock statement. The lock statement is declared in LLD.h. The following describes each lock statement.

LLD_IOC_SECURE_LT is that the locked block of NAND flash memory is lock-tightened.

The block cannot be changed to unlocked or locked by software.

LLD_IOC_SECURE_LS is that all block of NAND flash memory is locked. All block can be read and cannot be written or erased.

LLD_IOC_SECURE_US is that the sequential block of NAND flash memory is unlocked. The unlocked sequential block can be read/written/erased.

The locked block keeps the locked statement, so it cannot be read/written/erased.

LLD_IOC_RESET_NAND_DEV

1. Description

This control command resets NAND flash memory.

2. Parameter



Parameter	Description
nDev	Physical Device Number (0 ~ 7)
nCode	LLD_IOC_RESET_NAND_DEV
pBufI	Not used
nLenI	Not used
pBuf0	Not used
nLen0	Not used
pByteRet	This value is set as 0 in XXX_IOCtl.

3. Return Value

Return Value	Description
LLD_SUCCESS	Reset NAND flash memory

EXAMPLE

(1) Example to implement the function in OneNAND

```
ONLD_IOCtl(UINT32 nDev, UINT32 nCode,
         UINT8 *pBufI, UINT32 nLenI,
UINT8 *pBufO, UINT32 nLenO,
         UINT32 *pByteRet)
   INT32 nRet;
   UINT32 nBAddr;
   UINT16 nRegVal;
   INT32
          nRes;
   if (pByteRet == NULL)
       return (ONLD_ILLEGAL_ACCESS);
   nBAddr = GET DEV BADDR(nDev);
   if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
       return nRes;
   switch (nCode)
       case LLD_IOC_SET_SECURE_LT:
          if (astONLDInfo[nDev].LockTight != NULL)
              astONLDInfo[nDev].LockTight(nDev, pBufI, nLenI);
          else
              return (ONLD_ILLEGAL_ACCESS);
          *pByteRet = (UINT32)0;
          nRet = ONLD_SUCCESS;
          break;
       case LLD_IOC_SET_BLOCK_LOCK:
          if (_LockBlock(nDev, pBufI, nLenI) != ONLD_SUCCESS)
```



```
return (ONLD_ILLEGAL_ACCESS);
   *pByteRet = (UINT32)0;
   nRet = ONLD_SUCCESS;
   break;
case LLD_IOC_GET_SECURE_STAT:
   if ((pBufO == NULL) | (nLenO < 2))
     return (ONLD_ILLEGAL_ACCESS);
   }
  nRegVal = ONLD_REG_WR_PROTECT_STAT(nBAddr);
   MEMCPY(pBufO, &nRegVal, sizeof(UINT16));
   *pByteRet = (UINT32)2;
  nRet = ONLD_SUCCESS;
  break;
case LLD_IOC_RESET_NAND_DEV:
   if ((GET_DEV_DID(nDev) \& 0x0008) == DDP_CHIP)
   {
      ONLD_REG_START_ADDR1(nBAddr) = (UINT16)(0x0000);
      ONLD_REG_START_ADDR2(nBAddr) = (UINT16)(0x0000);
      ONLD_REG_INT(nBAddr) = (UINT16)INT_CLEAR;
      /*----*/
                                          * /
      /* ONLD Unlock CMD is issued
      /*----*/
      ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_RESET;
      while (GET_ONLD_INT_STAT(nBAddr, PEND_RESET)
           != (UINT16)PEND RESET)
         /* Wait until device ready */
      }
      ONLD_REG_START_ADDR1(nBAddr) = (UINT16)(0x8000);
      ONLD_REG_START_ADDR2(nBAddr) = (UINT16)(0x8000);
   } /*if DDP_CHIP */
                             = (UINT16)INT_CLEAR;
   ONLD_REG_INT(nBAddr)
   /*____*/
   /* ONLD Unlock CMD is issued */
   /*____*/
   ONLD_REG_CMD(nBAddr) = (UINT16)ONLD_CMD_RESET;
   while (GET_ONLD_INT_STAT(nBAddr, PEND_RESET)
        != (UINT16)PEND_RESET)
      /* Wait until device ready */
   *pByteRet = (UINT32)0;
   nRet = ONLD_SUCCESS;
```



```
break;
   default:
      nRet = ONLD_IOC_NOT_SUPPORT;
      break;
return nRet;
```



XXX GetPrevOpData

DESCRIPTION

This function copies data of previous write operation to the given buffer. This function is called to rewrite the block in the error case of the previous write operation.

SYNTAX

```
INT32
XXX_GetPrevOpData(UINT32 nDev, UINT8 *pMBuf, UINT8 *pSBuf)
```

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)
pMBuf	UINT8 *	Out	Memory buffer for main array of NAND
			flash memory
pSBuf	UINT8 *	Out	Memory buffer for spare array of NAND
			flash memory

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Copy Success
LLD_ILLEGAL_ACCESS	Illegal access

REMARKS

This function is an optional Deferred Check Operation function.

DCOP(Deferred Check Operation): a method optimizing the operation performance. The DCOP method is a procedure to terminate the function (write or erase) right after the command issue. Then it checks the result of the operation at next function call.

EXAMPLE

(1) Example to call the function

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
           nErr;
   INT32
           nDev = 0;
   UINT32
   UINT32 nVol = 0;
         aMBuf[LLD_MAIN_SIZE];
   UINT8
   UINT8
            aSBuf[LLD_SPARE_SIZE];
   LowFuncTbl stLFT[MAX_VOL];
   PAM_RegLFT((VOID *)stLFT);
```



```
nErr = stLFT[nVol].GetPrevOpData(nDev, aMBuf, aSBuf);
if (nErr != LLD_SUCCESS)
   printf("XXX_GetPrevOpData()fail. ErrCode = %x\n", nErr);
   return (FLASE32);
return (TRUE32);
```

(2) Example to implement the function in OneNAND

```
ONLD_GetPrevOpData(UINT32 nDev, UINT8 *pMBuf, UINT8 *pSBuf)
  UINT32 nBAddr;
   UINT32 nPbn;
   UINT32 *pONLDMBuf, *pONLDSBuf;
   nBAddr = GET_DEV_BADDR(nDev);
   if ((pMBuf == NULL) && (pSBuf == NULL))
      return (ONLD_ILLEGAL_ACCESS);
   nPbn = GET_PBN(nDev, pstPrevOpInfo[nDev]->nPsn);
   ONLD_REG_START_ADDR2(nBAddr) = (UINT16)MAKE_DBS(nPbn);
   pONLDMBuf = (UINT32*)GET_ONLD_MBUF_ADDR(
                               nBAddr,
                               pstPrevOpInfo[nDev]->nPsn,
                               GET_CUR_BUF_SEL(nDev));
   pONLDSBuf = (UINT32*)GET_ONLD_SBUF_ADDR(
                               nBAddr,
                               pstPrevOpInfo[nDev]->nPsn,
                               GET_CUR_BUF_SEL(nDev));
   /*----*/
   /* Data is loaded into Memory
   if (pMBuf != NULL)
      /* Memcopy for main data */
      MEMCPY(pMBuf, pONLDMBuf,
            (ONLD_MAIN_SIZE * pstPrevOpInfo[nDev]->nScts));
   if (pSBuf != NULL)
      /* Memcopy for spare data */
      MEMCPY(pSBuf, pONLDSBuf,
            (ONLD_SPARE_SIZE * pstPrevOpInfo[nDev]->nScts));
   return (ONLD_SUCCESS);
```





XXX_FlushOp

DESCRIPTION

This function completes the current working operation.

SYNTAX

```
INT32
XXX_FlushOp(UINT32 nDev)
```

PARAMETERS

Parameter	Type	In/Out	Description
nDev	UINT32	In	Physical Device Number (0 ~ 7)

RETURN VALUE

Return Value	Description
LLD_SUCCESS	Success
LLD_ILLEGAL_ACCESS	Illegal Access
LLD_PREV_WRITE_ERROR	In DCOP (Deferred Check Operation), previous write
LLD_PREV_OP_RESULT	error happens
LLD_PREV_ERASE_ERROR	In DCOP (Deferred Check Operation), previous erase
LLD_PREV_OP_RESULT	error happens

REMARKS

This function is an optional Deferred Check Operation function.

EXAMPLE

(1) Example to call the function

```
#include <XSRTypes.h>
#include <PAM.h>
#include <LLD.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
BOOL32
Example(VOID)
   INT32
           nErr;
            nDev = 0;
   UINT32
   UINT32 nVol = 0;
   LowFuncTbl stLFT[MAX_VOL];
   PAM_RegLFT((VOID *)stLFT);
   nErr = stLFT[nVol].FlushOp(nDev);
   if (nErr != LLD_SUCCESS)
      printf("XXX_ FlushOp()fail. ErrCode = %x\n", nErr);
      return (FALSE32);
```



```
return (TRUE32);
```

(2) Example to implement the function in OneNAND

```
ONLD_FlushOp(UINT32 nDev)
   UINT32 nBAddr;
   INT32 nRes;
   nBAddr = GET_DEV_BADDR(nDev);
   if ((nRes = _ChkPrevOpResult(nDev)) != ONLD_SUCCESS)
      return nRes;
   return (ONLD_SUCCESS);
```

SEE ALSO

XXX_GetPrevOpData



PAM (Platform Adaptation Module)

This chapter describes the definition, system architecture, features, and APIs of PAM.

6.1. Description & Architecture

PAM is an abbreviation of Platform Adaptation Module. PAM links XSR with the platform. PAM is responsible for the platform-dependent part of XSR layer (STL, and BML). If the platform is changed, a user only changes PAM.

Reference

Generally, the platform is underlying the computer system on which application program can run. This document calls the platform is the board that consists of CPU, DRAM, NAND flash memory, etc.

For example, a layer of XSR wants to requests the volume and device information of NAND flash memory. The requested information is dependent on the platform. Each layer calls an adaptation module PAM to use the platform functionalities. Therefore, a user must implement PAM suitable for the platform when a user ports XSR.

Figure 6-1 shows PAM in XSR system architecture.






Figure 6-1. PAM in XSR System Architecture

PAM has 9 functions that are classified into 4 categories as follows.

- ☐ Initialization function : hardware initialization
- ☐ Device Configuration functions : LFT registration, and XSR and LLD information return
- ☐ Interrupt functions: interrupt initialization, interrupt bind, interrupt enable, interrupt disable, and interrupt clear
- ☐ **Memory Operation function :** memory copy

In the next chapter, PAM APIs are covered in detail.



6.2. API

This chapter describes PAM APIs.

Reference

All the PAM function has a prefix "PAM_" on each function name.

Table 6-1 shows the lists of PAM APIs.

The right row in table shows that the function is Mandatory or Optional or Recommended. Optional functions should be existed, but contents of the functions does not need to be implemented.

Table 6-1. PAM API

Function	Description	
PAM_Init	This function initializes NAND specific hardware	0
PAM_GetPAParm	This function maps the platform and device.	M
PAM_RegLFT	This function registers LLD to XSR.	M
PAM_InitInt	This function initializes the interrupt for NAND device.	0
PAM_BindInt	This function binds the interrupt for NAND device.	0
PAM_EnableInt	This function enables the interrupt for NAND device.	0
PAM_DisableInt	This function disables the interrupt for NAND device.	0
PAM_ClearInt	This function clears the interrupt for NAND device.	0
PAM_Memcpy	This function copies data from source to destination	M



PAM Init

DESCRIPTION

This function initializes NAND specific Hardware.

SYNTAX

```
VOID
PAM_Init(VOID)
```

PARAMETERS

None

RETURN VALUE

None

REMARKS

This function performs platform specific initialization for allowing access to NAND flash device. If necessary, this function should initialize memory bus width, and memory configuration registers for NAND flash device.

EXAMPLE

(1) Example to call the function

```
#include <PAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   /* PAM_Init() should be called at open time */
   PAM_Init();
   /* LLD Function Table initialization */
   PAM_RegLFT(gstLFT);
```

(2) Example to implement the function in S3C2410

```
VOID
PAM_Init(VOID)
```

SEE ALSO



PAM GetPAParm

DESCRIPTION

This function maps the platform and device.

SYNTAX

```
VOID*
PAM_GetPAParm(VOID)
```

PARAMETERS

None

RETURN VALUE

Return Value	Description
VOID *	Returns the address of the array having information
	about the volume and device

REMARKS

This function is mandatory.

Currently, XSR supports two volumes and eight devices at maximum, because the number of maximum volume (XSR_MAX_VOL) is defined as 2 and the number of maximum device (XSR_MAX_DEV) is defined as 8 in XSRTypes. When calling PAM_GetPAParm, a user can get the volume and device information together. So, a user gets the platform information by calling PAM_GetPAParm.

XsrVolParm data structure is declared in PAM.h.

☐ XsrVolParm data structure

```
typedef struct {
   UINT32 nBaseAddr[XSR_MAX_DEV/XSR_MAX_VOL];
   /* the base address for accessing NAND device*/
   UINT16 nEccPol;
   /* Ecc Execution Section
      NO_ECC : No ECC or ECC execution by
               another type of ECC algorithm
      SW_ECC : ECC execution by XSR Software
                (based on Hamming code)
      HW_ECC : ECC execution by HW
                (if HW has ECC functionality
                based on Hamming code) */
   UINT16 nLSchemePol;
   /* Lock Scheme Policy Section
      NO_LOCK_SCHEME : No Lock Scheme
      SW_LOCK_SCHEME : Lock Scheme Execution by SW
      HW_LOCK_SCHEME : Lock Scheme Execution by HW
```



```
(if HW has Lock/Unlock functionality)*/
 BOOL32 bByteAlign;
 /* Memory Byte Alignment Problem
    TRUE32: Byte Align Problem Free in XSR and LLD
               (Memory usage increased)
     FALSE32 : No Action for Byte Align Problem */
 UINT32 nDevsInVol;
 /* number of devices in the volume */
 VOID
        *pExInfo;
 /* For Device Extension. For Extra Information of Device,
    data structure can be mapped.
XsrVolParm;
```

More detailed explanation about XsrVolParm is as follow.

□ nBaseAddr is a base address of NAND device for LLD.
□ nEccPol is a policy whether using ECC code or not: neccPol can be HW_ECC, SW_ECC and NO_ECC. A user sets as HW_ECC when NAND device provides ECC generation/correction based on Hamming code. In that case, spare assignment for generated ECC code should be compatible with Samsung spare assignment standard. A user sets as NO_ECC when NAND device uses no ECC algorithm or hardware ECC algorithm which is not compatible with Samsung standards ⁶ . When a user wants to use software ECC supported by XSR and sets as SW_ECC, BML handles ECC generation/correction. For more information about the ECC policy, refer to Chapter 7.6 ECC Policy.
□ nLSchemePol is a policy related to write/erase protection: nLSchemePol can be HW_LOCK_SCHEME, SW_LOCK_SCHEME, and NO_LOCK_SCHEME. A user sets as NO_LOCK_SCHEME when NAND device does not provide the lock scheme, and sets as HW_LOCK_SCHEME when NAND device use the lock scheme. When a user wants to use the lock scheme in software and sets as SW_LOCK_SCHEME, BML handles the write/erase protection.
□ bByteAlign is used to decide whether LLD fits the alignment or not, when LLD gets not-aligned buffer from the upper layer in read/write operation. A users set as TRUE32 that means to fit the alignment, while a user sets as FALSE32 that means to hand it over LLD, although it is not-aligned.
□ nDevsInVol is the number of the allocated device in the volume.

DEXINFO is entry for extension usage. It is available for developers who want to add

EXAMPLE

(1) Example to call the function

their own platform dependent information.

Memory Division, Samsung Electronics Co., Ltd, "NAND Flash Spare Assignment recommendation", http://www.samsung.com/Products/Semiconductor/Flash/TechnicalInfo/Spare_assignment_recommendation.pd f

⁶ Memory Division, Samsung Electronics Co., Ltd, "ECC(Error Checking & Correction) Algorithm", http://www.samsung.com/Products/Semiconductor/Flash/TechnicalInfo/eccalgo_040624.pdf



```
#include <PAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   XsrVolParm *pstPAM;
   pstPAM = (XsrVolParm *) PAM_GetPAParm();
```

(2) Example to implement the function in S3C2410

```
#include <XSRTypes.h>
#include <PAM.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
#define VOL0
#define VOL1
#define DEV0
              Ω
#define
       DEV1
               1
#define
        DEV2
#define
        DEV3
VOID*
PAM_GetPAParm(VOID)
   gstParm[VOL0].nBaseAddr[DEV0] = 0x20000000;
   gstParm[VOL0].nBaseAddr[DEV1] = NOT_MAPPED;
   gstParm[VOL0].nBaseAddr[DEV2] = NOT_MAPPED;
   gstParm[VOL0].nBaseAddr[DEV3] = NOT_MAPPED;
   gstParm[VOL0].nEccPol
                              = SW ECC;
  gstParm[VOL0].nLSchemePol
                              = SW_LOCK_SCHEME;
   gstParm[VOL0].bByteAlign
                              = TRUE32;
   gstParm[VOL0].nDevsInVol
                               = 1;
   gstParm[VOL0].pExInfo
                              = NULL;
   gstParm[VOL1].nBaseAddr[DEV0] = NOT_MAPPED;
   gstParm[VOL1].nBaseAddr[DEV1] = NOT_MAPPED;
   gstParm[VOL1].nBaseAddr[DEV2] = NOT_MAPPED;
   gstParm[VOL1].nBaseAddr[DEV3] = NOT_MAPPED;
   gstParm[VOL1].nEccPol
                              = HW_ECC;
  gstParm[VOL1].nDevsInVol
                              = 0;
                              = NULL;
   gstParm[VOL1].pExInfo
   return (VOID *) gstParm;
```

SEE ALSO



PAM_RegLFT

DESCRIPTION

This function registers functions to XSR.

SYNTAX

VOID PAM_RegLFT(VOID *pstFunc)

PARAMETERS

Parameter	Type	In/Out	Description
pstFunc	VOID *	Out	Pointer to LowFuncTbl data structure

RETURN VALUE

None

REMARKS

This function is mandatory.

1. Registering LLD address to BML




Figure 6-2. Register LLD Address to BML

BML encapsulates the various device driver(LLD)s. LFT(LLD Function Table) is a list of 17 functions that is encapsulated by BML. LFT is defined at LLD.h as LowFuncTbl.

☐ LowFuncTbl data structure



```
typedef struct {
   INT32 (*Init)
                    (VOID *pParm);
   INT32 (*Open)
                     (UINT32 nDev);
   INT32 (*Close)
                     (UINT32 nDev);
   INT32 (*Read)
                     (UINT32 nDev, UINT32 nPsn, UINT32 nScts,
                     UINT8 *pMBuf, UINT8 *pSBuf, UINT32 nFlag);
                     (UINT32 nDev, UINT32 nPsn, UINT32 nScts,
   INT32 (*Write)
                     UINT8 *pMBuf, UINT8 *pSBuf, UINT32 nFlag);
                     (UINT32 nDev, UINT32 nPsn, UINT32 nScts, SGL *pstSGL, UINT8 *pSBuf, UINT32 nFlag);
   INT32 (*MRead)
   INT32 (*MWrite)
                    (UINT32 nDev, UINT32 nPsn, UINT32 nScts,
                     SGL *pstSGL, UINT8 *pSBuf, UINT32 nFlag,
                     UINT32 *pErrPsn);
   INT32 (*CopyBack)(UINT32 nDev, CpBkArg *pstCpArg,
                     UINT32 nFlag);
                     (UINT32 nDev, UINT32 Pbn, UINT32 nFlag);
   INT32 (*Erase)
   INT32 (*GetDevInfo)(UINT32 nDev, LLDSpec *pstDevInfo);
   INT32 (*ChkInitBadBlk)(UINT32 nDev, UINT32 Pbn);
   INT32 (*FlushOp) (UINT32 nDev);
   INT32 (*SetRWArea)(UINT32 nDev, UINT32 nSUbn, UINT32 nUBlks);
   INT32 (*GetPrevOpData)(UINT32 nDev, UINT8 *pMBuf,
                            UINT8 *pSBuf);
   INT32 (*IOCtl)
                     (UINT32 nDev, UINT32 nCmd,
                     UINT8 *pBufI, UINT32 nLenI,
                     UINT8 *pBufO, UINT32 nLenO,
                     UINT32 *pByteRet);
   INT32 (*MErase)
                     (UINT32 nDev, LLDMEArg *pstMEArg,
                     UINT32 nFlag);
   INT32 (*EraseVerify)(UINT32 nDev, LLDMEArg *pstMEArg,
                     UINT32 nFlag);
 LowFuncTbl;
```

LowFuncTb1 is allocated corresponding to each device and is able to support up to 8. Thus, it is necessary to register the function of real LLD to the corresponding LowFuncTbl.

XSR can work together by calling PAM_RegLFT and registering the implemented LLD function. BML can call the real LLD function using the function pointer defined at LFT.

pstFunc is a pointer of LowFuncTbl, a LLD address table.

When BML calls PAM_RegLFT, it finds the real function address to access NAND device using LFT.

2. Defining the volume and device of BML






Figure 6-3. Define Volume and Device of BML

A user must recognize the definition of a volume and device to use BML. XSR can support the device up to eight, and BML can manage several devices once bind them with a volume.

BML can support the plural volumes, but it currently supports 2 volumes. BML binds the maximum four devices with a volume, and the devices must be the same type in a volume. For example, the device number $\#0 \sim \#3$ and $\#4 \sim \#7$ must be the same type of LLD.

A user should know this volume and device features at BML, so a user can understand the mapping from BML to LLD using LFT.

EXAMPLE

(1) Example to call the function

```
#include <PAM.h>
#include <XSRTypes.h>
VOID
Example(VOID)
   PAM_Init();
   /* LLD Function Table initialization */
   PAM_RegLFT(gstLFT);
```

(2) Example to implement the function in S3C2410

```
#include <XSRTvpes.h>
#include <PAM.h>
#include <XXX.h> /* Header File of Low Level Device Driver */
#define
          VOL0
                0
VOID
PAM_RegLFT(VOID *pstFunc)
   LowFuncTbl *pstLFT;
   pstLFT = (LowFuncTbl*)pstFunc;
   pstLFT[VOL0].Init
                                  = ONLD_Init;
```



```
= ONLD_Open;
= ONLD_Close;
= ONLD_Read;
pstLFT[VOL0].Open
pstLFT[VOL0].Close
pstLFT[VOL0].Read
```



PAM InitInt

DESCRIPTION

This function initializes the specified logical interrupt.

SYNTAX

```
VOID
PAM_InitInt(UINT32 nLogIntId)
```

PARAMETERS

Parameter	Type	In/Out	Description
nLogIntId	UINT32	In	Logical interrupt ID number

RETURN VALUE

None

REMARKS

This function is an optional interrupt function.

Currently, this function is used for asynchronous operation.

This function set registers to use interrupts of platform. This function initializes the specified logical interrupt through OS dependent interrupt initialization function.

EXAMPLE

(1) Example to call the function

```
#include <PAM.h>
#include <XSRTypes.h>
          INT_ID_NAND_0 (0) /* Interrupt ID : 1st NAND */
#define
VOID
Example(VOID)
   /* initializes interrupt for 1st NAND device */
   PAM_InitInt((UINT32)INT_ID_NAND_0);
   /* initializes interrupt for 1st NAND device */
   PAM_BindInt((UINT32)INT_ID_NAND_0);
```

(2) Example to implement the function in S3C2410

```
PAM_InitInt(UINT32 nLogIntId)
   switch (nLogIntId)
      case XSR_INT_ID_NAND_0:
          TS3C2440::GPIO::SelectSignalMethod(EExtInt4,
             ERisingEdgeSignal);
```



```
break;
   default:
      break;
OAM_InitInt(nLogIntId);
```

PAM_BindInt, PAM_EnableInt, PAM_DisableInt, PAM_ClearInt



PAM BindInt

DESCRIPTION

This function binds the specified logical interrupt for NAND device.

SYNTAX

```
VOID
PAM_BindInt(UINT32 nLogIntId)
```

PARAMETERS

Parameter	Type	In/Out	Description
nLogIntId	UINT32	In	Logical interrupt ID number

RETURN VALUE

None

REMARKS

This function is an optional interrupt function.

Currently, this function is used for asynchronous operation.

This function translates the specified logical interrupt ID into the physical interrupt ID and binds the interrupt through OS dependent function which binds interrupt.

EXAMPLE

(1) Example to call the function

```
#include <PAM.h>
#include <XSRTypes.h>
#define
           INT_ID_NAND_0 (0) /* Interrupt ID : 1st NAND */
VOID
Example(VOID)
   /* initializes interrupt for 1st NAND device */
   PAM_InitInt((UINT32)INT_ID_NAND_0);
   /* initializes interrupt for 1st NAND device */
   PAM_BindInt((UINT32)INT_ID_NAND_0);
```

(2) Example to implement the function in S3C2410

```
VOID
PAM_BindInt(UINT32 nLogIntId)
   UINT32 nPhyIntId = 0;
   switch (nLogIntId)
      case XSR_INT_ID_NAND_0:
```



```
nPhyIntId = EIrqExt4_7;
      break;
   default:
      break;
OAM_BindInt(nLogIntId, nPhyIntId);
```

PAM_InitInt, PAM_EnableInt, PAM_DisableInt, PAM_ClearInt



PAM EnableInt

DESCRIPTION

This function enables the specified logical interrupt for NAND device.

SYNTAX

```
VOID
PAM_EnableInt(UINT32 nLogIntId)
```

PARAMETERS

Parameter	Type	In/Out	Description
nLogIntId	UINT32	In	Logical interrupt ID number

RETURN VALUE

None

REMARKS

This function is an optional interrupt function.

Currently, this function is used for asynchronous operation.

This function translates the specified logical interrupt ID into the physical interrupt ID and enables the interrupt through OS dependent function which enables interrupt.

EXAMPLE

(1) Example to call the function

```
#include <PAM.h>
#include <XSRTypes.h>
#define
           INT_ID_NAND_0 (0) /* Interrupt ID : 1st NAND */
VOID
Example(VOID)
   PAM_ClearInt((UINT32)INT_ID_NAND_0);
   PAM_EnableInt((UINT32)INT_ID_NAND_0);
```

(2) Example to implement the function in S3C2410

```
VOID
PAM_EnableInt(UINT32 nLogIntId)
   UINT32 nPhyIntId = 0;
   switch (nLogIntId)
       case XSR_INT_ID_NAND_0:
          nPhyIntId = EIrqExt4_7;
          break;
```



```
default:
      break;
OAM_EnableInt(nLogIntId, nPhyIntId);
```

PAM_InitInt, PAM_BindInt, PAM_DisableInt, PAM_ClearInt



PAM DisableInt

DESCRIPTION

This function disables the specified logical interrupt for NAND device.

SYNTAX

```
VOID
PAM_DisableInt(UINT32 nLogIntId)
```

PARAMETERS

Parameter	Type	In/Out	Description
nLogIntId	UINT32	In	Logical interrupt ID number

RETURN VALUE

None

REMARKS

This function is an optional interrupt function.

Currently, this function is used for asynchronous operation.

This function translates the specified logical interrupt ID into the physical interrupt ID and disables the interrupt through OS dependent function which disables interrupt.

EXAMPLE

(1) Example to call the function

```
#include <PAM.h>
#include <XSRTypes.h>
#define
           INT_ID_NAND_0 (0) /* Interrupt ID : 1st NAND */
VOID
Example(VOID)
   PAM_ClearInt((UINT32)INT_ID_NAND_0);
   PAM_DisableInt((UINT32)INT_ID_NAND_0);
```

(2) Example to implement the function in S3C2410

```
VOID
PAM_DisableInt(UINT32 nLogIntId)
   UINT32 nPhyIntId = 0;
   switch (nLogIntId)
       case XSR_INT_ID_NAND_0:
          nPhyIntId = EIrqExt4_7;
          break;
```



```
default:
      break;
OAM_DisableInt(nLogIntId, nPhyIntId);
```

PAM_InitInt, PAM_BindInt, PAM_EnableInt, PAM_ClearInt



PAM ClearInt

DESCRIPTION

This function clears the specified logical interrupt for NAND device.

SYNTAX

```
VOID
PAM_ClearInt(UINT32 nLogIntId)
```

PARAMETERS

Parameter	Type	In/Out	Description
nLogIntId	UINT32	In	Logical interrupt ID number

RETURN VALUE

None

REMARKS

This function is an optional interrupt function.

Currently, this function is used for asynchronous operation.

This function translates the specified logical interrupt ID into the physical interrupt ID and clears the interrupt through OS dependent function which clears interrupt.

EXAMPLE

(1) Example to call the function

```
#include <PAM.h>
#include <XSRTypes.h>
#define
           INT_ID_NAND_0 (0) /* Interrupt ID : 1st NAND */
VOID
Example(VOID)
   PAM_ClearInt((UINT32)INT_ID_NAND_0);
   PAM_EnableInt((UINT32)INT_ID_NAND_0);
```

(2) Example to implement the function in S3C2410

```
VOID
PAM_ClearInt(UINT32 nLogIntId)
   UINT32 nPhyIntId = 0;
   switch (nLogIntId)
       case XSR_INT_ID_NAND_0:
          nPhyIntId = EIrqExt4_7;
          break;
```



```
default:
      break;
OAM_ClearInt(nLogIntId, nPhyIntId);
```

PAM_InitInt, PAM_BindInt, PAM_EnableInt, PAM_DisableInt



PAM_Memcpy

DESCRIPTION

This function copies data from the source to the destination.

SYNTAX

```
VOID
PAM_Memcpy(VOID *pDst, VOID *pSrc, UINT32 nLen)
```

PARAMETERS

Parameter	Type	In/Out	Description
pDst	VOID *	Out	Array Pointer of destination data to be copied
pSrc	VOID *	In	Array Pointer of source data to be copied
nLen	UINT32	In	Length to be copied

RETURN VALUE

None

REMARKS

This function is a mandatory memory operation function.

This function is called by the function that wants to copy data in the source buffer to data in the destination buffer. If system can support a functionality for memory copy by hardware, PAM_Memcpy uses it to adjust the memory copy operation to specific environment of platform. If not, PAM_Memcpy just calls OS dependent Memcpy function.

EXAMPLE

(1) Example to call the function

```
#include <PAM.h>
#include <XSRTypes.h>
UINT8 SrcBuf[512];
UINT8 DstBuf[512];
VOID
Example(VOID)
   PAM_Memcpy(&DstBuf[0], &SrcBuf[0], (512));
```

(2) Example to implement the function in S3C2410

```
VOID
PAM_Memcpy(VOID *pDst, VOID *pSrc, UINT32 nLen)
   OAM_Memcpy(pDst, pSrc, nLen);
```

(3) Example to implement the function in O5912

```
VOID
```



```
PAM_Memcpy(VOID *pDst, VOID *pSrc, UINT32 nLen)
   if (nLen > 0xffff) return;
   DMA_CSSA_L = (unsigned short)((unsigned int)
                                  (src)&0x0000FFFF);
   DMA_CSSA_U = (unsigned short)(((unsigned int)
                                  (src)&0xFFFF0000)>>16);
   DMA_CDSA_L = (unsigned short)((unsigned int)
                                  (dst)&0x0000FFFF);
   DMA_CDSA_U = (unsigned short)(((unsigned int)
                                  (dst)&0xFFFF0000)>>16);
   DMA_CEN = byte_len >> 1;  /* channel element number */
   DMA_CCR = 0x54c0;
   /* poll if dma finished */
   while (!(DMA_CSR&0x8))
      //polling if DMA finished
   return;
```



Index

	PAM_ClearInt	178
	PAM_DisableInt	176
0	PAM_EnableInt	
	PAM_GetPAParm	
OAM_AcquireSM59	PAM_Init	
OAM_BindInt65	PAM_InitInt	170
OAM_ClearInt71	PAM_Memcpy	
OAM_CreateSM55	PAM_RegLFT	
OAM_Debug54	_ 0	
OAM_DestroySM 57		
OAM_DisableInt69	X	
OAM_EnableInt67		
OAM_Free	XXX_ChkInitBadBlk	143
OAM_GetROLockFlag81	XXX_Close	90
OAM_GetTime75	XXX_CopyBack	135
OAM_Idle 80	XXX_Erase	107
OAM_InitInt63	XXX_EraseVerify	132
OAM_Malloc47	XXX_FlushOp	156
OAM_Memcmp52	XXX_GetDevInfo	92
OAM_Memcpy49	XXX_GetPrevOpData	153
OAM_Memset51	XXX_Init	
OAM_Pa2Va78	XXX_IOCtl	147
OAM_ReleaseSM61	XXX_MErase	126
OAM_ResetTimer73	XXX_MRead	110
OAM_WaitNMSec77	XXX_MWrite	118
	XXX_Open	87
	XXX_Read	97
P	XXX_SetRWArea	145
	XXX_Write	
PAM_BindInt 172	_	