

SPARKBRIDGE EDGE

Edge is a Sparkplug B edge node module for Ignition. It subscribes to a site gateway's tag layer, applies report-by-exception with batching and deadband, publishes BIRTH/DATA/DEATH, and buffers to disk through a broken link so a lost session cannot drop data.

— VERSION 2.8.0 IGNITION 8.1.19+ AND 8.3

RUNS ON: ANY IGNITION GATEWAY AT THE SITE BEING COLLECTED

CONTENTS

ON THIS PAGE

1. [Overview](#)
2. [What You Need](#)
3. [Install](#)
4. [License](#)
5. [Configure](#)
6. [Operate](#)
7. [Verify](#)
8. [Troubleshoot](#)
9. [Reference](#)

OVERVIEW

1. OVERVIEW

Edge runs on the gateway physically closest to the equipment. It reads the gateway's own tag tree, applies report-by-exception (only publish what changed), and sends Sparkplug B BIRTH, DATA and DEATH messages to a broker managed by a SparkBridge Provider. It is not a broker and not a historian: it has no opinion about what happens to the data once published, and it does not decode anyone else's Sparkplug traffic. A durable store-and-forward buffer on disk means a broken MQTT session does not lose data; queued messages replay on reconnect.

Edge is the first leg of the SparkBridge backbone: Edge publishes, Provider routes, Host decodes. Install Edge after Provider and Host are running.

REQUIREMENTS

IGNITION

JAVA

GATEWAY ROLE

NETWORK

OTHER SPARKBRIDGE
MODULES REQUIRED

INSTALL

3. INSTALL

1. Download the release bundle for your Ignition line from the [download page](#):
`SparkBridge-Provider.mod1`, `SparkBridge-Host.mod1`, `SparkBridge-Edge.mod1`, plus `SHA256SUMS.txt` and `sparkbridge-signing-cert.pem`.
2. Install order matters: Provider, then Host, then Edge. In the gateway, go to Config > Modules > Install or Upgrade a Module and upload `SparkBridge-Edge.mod1` last.
3. The gateway checks the module's signature against the shipped certificate on upload. Accept the certificate and license once.
4. Confirm Config > Modules shows SparkBridge Edge state = Running.

Upgrade every installed SparkBridge module together, from the same release bundle, in the same maintenance window. Host, Edge and Provider agree on which settings key each of them owns; a gateway running mixed versions can disagree on ownership for a key like `hostId` or `foldtarget` and silently misbehave.

LICENSE

FILE

RE-CHECK INTERVAL

From release 2.7.0, Edge runs on Ignition's standard two-hour module trial (the gateway's Reset Trial button restarts the clock). When the trial expires with no verified key naming the product, Edge publishes NDEATH and stops publishing, while its store-and-forward buffer keeps capturing underneath. A key dropped in after expiry lifts the pause on its own within the 30-second re-check, no button press and no restart. A verified key overrides the trial entirely.

CONFIGURE

5. CONFIGURE

Config > SparkBridge Edge > Settings. Set **source** to the tag folder to publish, for example `[default]Plant/Line1`. Edge polls its settings every five seconds and rebuilds its node runtime when edge-owned settings change; no restart is required. Every key below is Edge-owned: Edge is the only module that ever writes it, and every one hot-reloads on that five-second poll.

SETTING

MEANING, DEFAULT

source	Tag subscription root. Default [System]Gateway/Performance.
nodes	Explicit group,edge,source;... runtime list, up to 8. Empty falls back to one implicit Ignition/Gateway runtime.
batchms	NData batch window, milliseconds. Default 100.
deadband	Publish deadband fraction. Default 0.0.
uns	Turns on the UNS application-topic mirror. Default off.
unsprefix	Application topic prefix used by the UNS mirror. Default sparkbridge.
fold	Folds UDT property members into the published Template. Default off. Must agree with the Host tab's Fold Target setting; changing one without the other silently loses the property mapping.
foldmembers	Name patterns matched for folding. Default Units,Description,Address*,IO_Loc*,Number,PV_L,PV_U.
primaryHost	Host application id this edge watches for STATE. Must match the Host tab's Host Id. Default SparkBridge.
maxtags	Discovery cap on tag count. Default 250000.
subchunk	Subscription chunk size. Default 10000.
rescansec	Tag rescan period, seconds. Default 300.
devicelevel	Device modeling depth, 0 disables it, max 8. Default 0.
devicefolders	Folder markers used for device modeling. Default empty.

SETTING

MEANING, DEFAULT

devicewritable	Device ids that accept DCMD writes. Default empty.
sfhours	Store-and-forward retention target, hours, 0-8760. Default 24.
sfmax	Store-and-forward hard byte cap. Blank derives it from the retention target.

Edge-only identity and enrollment stay as –D system properties, not on this page: `sparkbridge.edge.username`, `sparkbridge.edge.password` (secrets file, never the command line), and `sparkbridge.enrollment.code` (one-time first-boot code against Host; Edge clears it after success).

OPERATE

Day to day, Edge needs no attention once BIRTH is confirmed. Watch the gateway log for repeated NDEATH/rebirth cycles, which usually mean a flapping network link rather than a SparkBridge problem.

On a link loss, Edge keeps publishing into its store-and-forward buffer on disk rather than dropping data; queued messages replay in order once the session reconnects. On gateway restart, Edge rebuilds its runtime from the last saved settings and re-publishes a fresh BIRTH with a new `bdSeq`.

SparkLink (bundled with Edge) shapes deadbands and publish intervals against a measured byte budget on metered links, with a fixed set of metrics exempt from any degradation.

VERIFY

7. VERIFY

Check the gateway log for the startup and BIRTH lines:

```
SparkBridge Edge: built 1 runtime(s), generation 1
SparkBridge Host: BIRTH Ignition/Gateway (N metrics)
```

A second BIRTH ... (N metrics) line with a changed metric count confirms a settings change was picked up. On the Host side, expand the managed tag provider in the Designer or gateway tag browser and confirm values update.

TROUBLESHOOT

SYMPTOM	LIKELY CAUSE	FIX
	Provider not running yet, or wrong broker address	Confirm Provider is Running and check source and broker connectivity before Edge

SYMPTOM	LIKELY CAUSE	FIX
	Flapping network link, not a module fault	Check link stability; store-and-forward keeps capturing meanwhile
	Edge's <code>fold/foldmembers</code> disagree with Host's Fold Target	Set both ends to the same folding intent
	Module trial expired, no verified key	Drop a valid <code>sparkbridge-license.key</code> in the data directory; picked up within 30 seconds
	<code>maxtags</code> cap reached	Raise <code>maxtags</code> or narrow source

REFERENCE

9. REFERENCE

LICENSE FILE	<code><data>/sparkbridge-license.key</code>
MODULE FILE	<code>SparkBridge-Edge.modl</code>
DEFAULT BROKER PORTS	1883 plaintext, 8883 TLS
SETTINGS POLL	5 seconds
LICENSE RE-CHECK	30 seconds

NODE RUNTIME LIMIT

8 explicit runtimes via nodes

SUPPORT

Full install and config detail: [SparkBridge Docs](#), [Edge](#). Questions: [Contact](#). Release history: [GitHub releases](#).