

WSL SETUP

1. Install wsl from the official website on your laptop or simply use the command **wsl-install** and select the version that is required.
2. Set up your linux account and set the username and the password as per the requirements and then install the required basic libraries or the essentials by using the command **sudo apt install -y build-essential curl wget git unzip zip**.
3. Once done exit from wsl and within the powershell check the WSL that is being used with the help of the command **wsl --list --verbose**
4. And set the default version using **wsl --set-default-version <VERSION NAME>**
5. And once these are done then install the requirements for the sake of ARM GCC toolchain using the commands
 - a. **sudo apt update**
 - b. **sudo apt install -y gcc-arm-none-eabi**
 - c. **sudo apt install -y **
 - d. **binutils-arm-none-eabi **
 - e. **libnewlib-arm-none-eabi **
 - f. **libstdc++-arm-none-eabi-dev**
6. Verify the installation using the command **arm-none-eabi-gcc --version**.