Hot key Description



F1: Decrease Screen Brightness



F2: Increase Screen Brightness



F3: Mission Control



F4: Launchpad



F5: Decrease Keyboard Brightness



F6: Increase keyboard Brightness



F7: Previous Track



F8: Play Pause



F9: Next Track



F10 : Mute



F11: Decrease Volume



F12: Increase Volume

Warranty

This warranty does not cover problems or damage resulting from, but not limited to, any of the following:

- · Wear and tear associated with normal use.
- · Any unauthorized modification or repair, accidental damage or disassembly.
- · Removal of any manufacturer label(s) or sticker(s).
- Any improper operation, including any use not in accordance with any supplied product instructions.
- Connection to any improper voltage supply.
- Any other cause which does not relate to a product defect in materials or manufacturing.
- Counterfeit products; (MISTEL, at its sole discretion, determines were not manufactured by MISTEL or any of its authorized manufacturing partners).

RMA services contact : <u>services@mistelkeyboard.com</u> <u>www.mistelkeyboard.com</u>



Warranty confirmation from Reseller



DREAMING ON YOUR FINGERTIPS.







Description SLEEKER is a mechanical keyboard compatible with Mac OS X, SLEEKER is equipped with OS X hot

keys, you can see the hot keys icon on the keycap, no firmware or software is required. SLEEKER also supports Windows OS, by pressing Fn+ Space Bar Key, you can switch between Mac and Windows OS layouts very easily. SLEEKER has a unique, simple yet elegant design, outlined with smooth curves, the entire case is made of CNC aluminum material with added hair lines on the surface.

Specification

Package Accessories 1. Sleeker Keyboard x 1

- 2. Key puller x 1
- 3. User manual x 1 4. Type C cable x 1 5. Type C to Type A adapter x 1
- 6. keyboard bag x 1

7. Extra 13 keys

System requirement OS X 10.4.10V or Later

Keycap: Cherry low profile PBT keycap and Polling rate: 1000Hz

1. Fn + F13 = turn on the LED for Breathing Mode / Turn off

- 2. Fn + Home = Turn the Left side "Control" key into a second Fn key, that means there are 2 Fn keys,
- one on the right and left side.
- 3. Fn + End = Switch Capslock key with left Control key (When you press Fn+ home then press Fn+ End, the original caplock position is Fn then left side control is capslock.)

4. Fn + Arrow key ← → **=** adjust Keyboard LED speed

5. Press Fn + 5 again = go back to original factory setting.

Mac function

- Windows function
- 1. Fn + Space bar = Switch to Windows OS (MD870 : LED light up in left pilot lamp, MD880 : LED light

10. Fn + Delete = Keyboard Reset

- up in middle pilot lamp) 2. Fn + 5 = Turn on LED / Breathing Mode / Turn off LED
- 3. Fn + Arrow key $\uparrow \downarrow$ = adjust keyboard LED brightness
- 5. FN + Right win = Windows lock, press FN+ right Win key again: Windows unlock

(for MD880 only)

6. Fn + home = exchange left alt and windows

4. Fn + 5 (Number Pad Area) = Turn on Arrow functions, 2 is down/ 4 is left/ 6 is right / 8 is up.

- 7. Fn + end = exchange capslock and left control
- 8. In MD870, Press Fn+ F1/F2/F3 = (Mute/ Volume down/ Volume up) 9. In MD880, Press Fn+F16/F17/F18/F19 = (Mute/Volume down/Volume up/Calculation)