

DIHWorld Audio

Mastering Core Technical Manual

Current product versions, controls, presets, meters, and placement

DIHWorld Audio builds connected production systems around the Imhotep 369 Engine—a Triadic Harmonic Lattice—and Ma'at 357 / MomentumBend. Phi-derived control and the canonical Phi/2 ceiling preserve movement, balance, and musical intent without brickwall limiting.

This edition documents 5 current products. Release numbers are taken from the installed DIHWorld Audio Audio Units verified on 2026-10-05; they are product versions, not a shared catalog version.

Canon reference: normalized $\Phi/2 = 0.809016994$. MomentumBend shapes motion and containment; the ceiling is a canonical boundary, not permission for hard limiting.

Operating law: begin from reset or a purpose-matched preset, compare at equal loudness, change one system at a time, and judge the result in the full arrangement.

ANKH

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Master Field

Sacred optical leveler for late-stage compression, Ma'at limiting, attack, release, drive, ratio, stereo link, Flower luminosity, and final containment.

Recommended use: final containment authority

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
gainmatch	Gain Match	Bool
inputDb	RA Input	Float
mix	Mix	Float
attack	Sekhem Attack	Float
release	Ma'at Release	Float
drive	Ptah Drive	Float
ascension	Ascension Ratio	Float
outputDb	Amun Output	Float
compress	Compress	Bool
limit_on	Limit	Bool
flower_of_life	Flower of Life	Bool
link	Stereo Link	Bool
bypass	Bypass	Bool
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice

Factory starting points — source-derived purpose

[Stereo] ESSENTIAL / Default

ESSENTIAL / Default — Returns the dynamics stage to a neutral essential setting for level-matched setup. Stereo variant: keep the linked center intact and audition width in the full mix.

[Stereo] COLOR / Soft Optical

COLOR / Soft Optical — Uses slower, softer compression behavior for optical color without a hard ceiling. Stereo variant: keep the linked center intact and audition width in the full mix.

[Stereo] BUS / Life Compress

BUS / Life Compress — Glues a bus with the life/attack/release relationship kept musical. Stereo variant: keep the linked center intact and audition width in the full mix.

[Stereo] MASTER / Canon Ceiling

MASTER / Canon Ceiling — Sets the master lane and ceiling behavior for a final-stage check, not a loudness contest. Stereo variant: keep the linked center intact and audition width in the full mix.

[Stereo] REPAIR / Transient Watch

REPAIR / Transient Watch — Watches transient events and recovery so the source remains intact. Stereo variant: keep the linked center intact and audition width in the full mix.

[Stereo] UTILITY / Unity Reference

UTILITY / Unity Reference — Provides a unity reference for checking the chain without a special effect. Stereo variant: keep the linked center intact and audition width in the full mix.

[Mono] ESSENTIAL / Default

ESSENTIAL / Default — Returns the dynamics stage to a neutral essential setting for level-matched setup. Mono variant: collapse the field and use it as a

center-focused insert.

[Mono] COLOR / Soft Optical

COLOR / Soft Optical — Uses slower, softer compression behavior for optical color without a hard ceiling. Mono variant: collapse the field and use it as a center-focused insert.

[Mono] BUS / Life Compress

BUS / Life Compress — Glues a bus with the life/attack/release relationship kept musical. Mono variant: collapse the field and use it as a center-focused insert.

[Mono] MASTER / Canon Ceiling

MASTER / Canon Ceiling — Sets the master lane and ceiling behavior for a final-stage check, not a loudness contest. Mono variant: collapse the field and use it as a center-focused insert.

[Mono] REPAIR / Transient Watch

REPAIR / Transient Watch — Watches transient events and recovery so the source remains intact. Mono variant: collapse the field and use it as a center-focused insert.

[Mono] UTILITY / Unity Reference

UTILITY / Unity Reference — Provides a unity reference for checking the chain without a special effect. Mono variant: collapse the field and use it as a center-focused insert.

[Dual Mono] ESSENTIAL / Default

ESSENTIAL / Default — Returns the dynamics stage to a neutral essential setting for level-matched setup. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

[Dual Mono] COLOR / Soft Optical

COLOR / Soft Optical — Uses slower, softer compression behavior for optical color without a hard ceiling. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

[Dual Mono] BUS / Life Compress

BUS / Life Compress — Glues a bus with the life/attack/release relationship kept musical. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

[Dual Mono] MASTER / Canon Ceiling

MASTER / Canon Ceiling — Sets the master lane and ceiling behavior for a final-stage check, not a loudness contest. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

[Dual Mono] REPAIR / Transient Watch

REPAIR / Transient Watch — Watches transient events and recovery so the source remains intact. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

[Dual Mono] UTILITY / Unity Reference

UTILITY / Unity Reference — Provides a unity reference for checking the chain without a special effect. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

Meters and visualizers

INPUT LEVEL: Peak level entering ANKH. Use to verify healthy mastering-chain entry.

GAIN REDUCTION: Current optical/limiter attenuation. More fill means more level is being removed.

OUTPUT LEVEL: Peak level after containment. Compare with Input for level-fair decisions.

SPHYNX

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Mix Bus

Mastering normalizer and calibrator that prepares input level, target, engine strength, normalization amount, mix, and output.

Recommended use: prepares material before field/finalization

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
INPUT	Input	Float
CALIBRATE	Calibrate	Float
NORMALIZE	Normalize	Float
ENGINE	Engine	Float
TARGET	Target	Float
MIX	Mix	Float
OUTPUT	Output	Float
gainmatch	Gain Match	Bool
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice

Factory starting points — source-derived purpose

SPHYNX CANON ALIGN [Stereo]

SPHYNX CANON ALIGN — Returns the translation engine to the canonical alignment point. Stereo variant: keep the linked center intact and audition width in the full mix.

SPHYNX GENTLE CALIBRATE [Stereo]

SPHYNX GENTLE CALIBRATE — Applies a light calibration pass that preserves normal dynamics. Stereo variant: keep the linked center intact and audition width in the full mix.

SPHYNX TRANSLATION [Stereo]

SPHYNX TRANSLATION — Prioritizes cross-system translation and center stability over coloration. Stereo variant: keep the linked center intact and audition width in the full mix.

SPHYNX DYNAMIC PRESERVE [Stereo]

SPHYNX DYNAMIC PRESERVE — Preserves movement while the target/normalize engine checks the field. Stereo variant: keep the linked center intact and audition width in the full mix.

SPHYNX MASTER ANCHOR [Stereo]

SPHYNX MASTER ANCHOR — Anchors a finished master to the selected target without substituting for a level match. Stereo variant: keep the linked center intact and audition width in the full mix.

SPHYNX LEVEL MATCH [Stereo]

SPHYNX LEVEL MATCH — Sets a fair level comparison so decisions are not driven by output gain. Stereo variant: keep the linked center intact and audition width in the full mix.

SPHYNX CANON ALIGN [Mono]

SPHYNX CANON ALIGN — Returns the translation engine to the canonical alignment point. Mono variant: collapse the field and use it as a center-focused insert.

SPHYNX GENTLE CALIBRATE [Mono]

SPHYNX GENTLE CALIBRATE — Applies a light calibration pass that preserves normal dynamics. Mono variant: collapse the field and use it as a center-focused insert.

SPHYNX TRANSLATION [Mono]

SPHYNX TRANSLATION — Prioritizes cross-system translation and center stability over coloration. Mono variant: collapse the field and use it as a center-focused insert.

SPHYNX DYNAMIC PRESERVE [Mono]

SPHYNX DYNAMIC PRESERVE — Preserves movement while the target/normalize engine checks the field. Mono variant: collapse the field and use it as a center-focused insert.

SPHYNX MASTER ANCHOR [Mono]

SPHYNX MASTER ANCHOR — Anchors a finished master to the selected target without substituting for a level match. Mono variant: collapse the field and use it as a center-focused insert.

SPHYNX LEVEL MATCH [Mono]

SPHYNX LEVEL MATCH — Sets a fair level comparison so decisions are not driven by output gain. Mono variant: collapse the field and use it as a center-focused insert.

SPHYNX CANON ALIGN [Dual Mono]

SPHYNX CANON ALIGN — Returns the translation engine to the canonical alignment point. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

SPHYNX GENTLE CALIBRATE [Dual Mono]

SPHYNX GENTLE CALIBRATE — Applies a light calibration pass that preserves normal dynamics. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

SPHYNX TRANSLATION [Dual Mono]

SPHYNX TRANSLATION — Prioritizes cross-system translation and center stability over coloration. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

SPHYNX DYNAMIC PRESERVE [Dual Mono]

SPHYNX DYNAMIC PRESERVE — Preserves movement while the target/normalize engine checks the field. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

SPHYNX MASTER ANCHOR [Dual Mono]

SPHYNX MASTER ANCHOR — Anchors a finished master to the selected target without substituting for a level match. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

SPHYNX LEVEL MATCH [Dual Mono]

SPHYNX LEVEL MATCH — Sets a fair level comparison so decisions are not driven by output gain. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

Meters and visualizers

INPUT PEAK: Peak entering calibration. Confirms available headroom before normalization.

PROGRAM RMS: Average program energy. Use to understand body level, not final delivery loudness alone.

AUTO TRIM: Gain correction calculated by SPHYNX. Center is 0 dB; left cuts and right boosts.

OUTPUT PEAK: Peak after normalization. Verify headroom after calibration.

Crest / headroom: Peak-to-RMS and remaining space. Use together to avoid flattening transient structure.

Maat

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Mix Bus

Mastering balance processor for foundation and air, bandwidth, truth, architecture, phase, stereo link, saturation mode, and output.

Recommended use: mastering balance/justice stage with secondary observation/advisor dot

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice
FOUNDATION_BOOST	Foundation Boost	Float
FOUNDATION_ATTEN	Foundation Atten	Float
FOUNDATION_FREQ	Foundation Frequency	Float
AIR_BOOST	Air Boost	Float
AIR_ATTEN	Air Atten	Float
BANDWIDTH	Bandwidth	Float
BALANCE	Balance	Float
TRUTH	Truth	Float
ARCHITECTURE	Architecture	Float
OUTPUT	Output	Float
POWER	Power	Bool
gainmatch	Gain Match	Bool
PHASE_INVERT	Phase Invert	Bool
FOUNDATION_WEIGHT_ON	Foundation Weight On	Bool
RUMBLE_HPF	Rumble HPF	Float
STEREO_LINK_MODE	Stereo Link Mode	Float
SATURATION	Saturation Tube Tape	Float

Factory starting points — source-derived purpose

MAAT SWEET SPOT [Stereo]

MAAT SWEET SPOT — Returns the sacred balance controls to the centered MAAT starting point. Stereo variant: keep the linked center intact and audition width in the full mix.

TRUTH ALIGN [Stereo]

TRUTH ALIGN — Centers Truth and Balance for a reference decision before boosting or attenuating a band. Stereo variant: keep the linked center intact and audition width in the full mix.

FOUNDATION WEIGHT [Stereo]

FOUNDATION WEIGHT — Sets the Foundation frequency and boost/atten pair for low-center balance. Stereo variant: keep the linked center intact and audition width in the full mix.

AIR SHEEN [Stereo]

AIR SHEEN — Uses Air Boost/Atten and Bandwidth to correct the upper field without over-brightening. Stereo variant: keep the linked center intact and audition width in the full mix.

LOW END MERCY [Stereo]

LOW END MERCY — Sets the Foundation frequency and boost/atten pair for low-center balance. Stereo variant: keep the linked center intact and audition width in the full mix.

BRIGHTNESS MERCY [Stereo]

BRIGHTNESS MERCY — Uses Air Boost/Atten and Bandwidth to correct the upper field without over-brightening. Stereo variant: keep the linked center intact and audition width in the full mix.

MIX SEAT [Stereo]

MIX SEAT — Seats the mix or chamber by combining Balance, Architecture, and a restrained tonal move. Stereo variant: keep the linked center intact and audition width in the full mix.

WARM BALANCE [Stereo]

WARM BALANCE — Tilts the balance toward body while retaining enough air for the source to speak. Stereo variant: keep the linked center intact and audition width in the full mix.

MASTER READY [Stereo]

MASTER READY — A restrained final-balance recipe; verify low-center, stereo integrity, loudness, and ceiling. Stereo variant: keep the linked center intact and audition width in the full mix.

CHAMBER POLISH [Stereo]

CHAMBER POLISH — Seats the mix or chamber by combining Balance, Architecture, and a restrained tonal move. Stereo variant: keep the linked center intact and audition width in the full mix.

GENTLE FINISH [Stereo]

GENTLE FINISH — A restrained final-balance recipe; verify low-center, stereo integrity, loudness, and ceiling. Stereo variant: keep the linked center intact and audition width in the full mix.

BREATH ROOT [Stereo]

BREATH ROOT — Balances a vocal's breath and root so neither the air nor the low center dominates. Stereo variant: keep the linked center intact and audition width in the full mix.

CANON GROUND [Stereo]

CANON GROUND — Returns MAAT to a grounded reference for judging the chain before correction. Stereo variant: keep the linked center intact and audition width in the full mix.

FULL RESET [Stereo]

FULL RESET — Returns MAAT to a grounded reference for judging the chain before correction. Stereo variant: keep the linked center intact and audition width in the full mix.

MAAT SWEET SPOT [Mono]

MAAT SWEET SPOT — Returns the sacred balance controls to the centered MAAT starting point. Mono variant: collapse the field and use it as a center-focused insert.

TRUTH ALIGN [Mono]

TRUTH ALIGN — Centers Truth and Balance for a reference decision before boosting or attenuating a band. Mono variant: collapse the field and use it as a center-focused insert.

FOUNDATION WEIGHT [Mono]

FOUNDATION WEIGHT — Sets the Foundation frequency and boost/atten pair for low-center balance. Mono variant: collapse the field and use it as a center-focused insert.

AIR SHEEN [Mono]

AIR SHEEN — Uses Air Boost/Atten and Bandwidth to correct the upper field without over-brightening. Mono variant: collapse the field and use it as a center-focused insert.

LOW END MERCY [Mono]

LOW END MERCY — Sets the Foundation frequency and boost/atten pair for low-center balance. Mono variant: collapse the field and use it as a center-focused insert.

BRIGHTNESS MERCY [Mono]

BRIGHTNESS MERCY — Uses Air Boost/Atten and Bandwidth to correct the upper field without over-brightening. Mono variant: collapse the field and use it as a center-focused insert.

MIX SEAT [Mono]

MIX SEAT — Seats the mix or chamber by combining Balance, Architecture, and a restrained tonal move. Mono variant: collapse the field and use it as a center-focused insert.

WARM BALANCE [Mono]

WARM BALANCE — Tilts the balance toward body while retaining enough air for the source to speak. Mono variant: collapse the field and use it as a center-focused insert.

MASTER READY [Mono]

MASTER READY — A restrained final-balance recipe; verify low-center, stereo integrity, loudness, and ceiling. Mono variant: collapse the field and use it as a center-focused insert.

CHAMBER POLISH [Mono]

CHAMBER POLISH — Seats the mix or chamber by combining Balance, Architecture, and a restrained tonal move. Mono variant: collapse the field and use it as a center-focused insert.

GENTLE FINISH [Mono]

GENTLE FINISH — A restrained final-balance recipe; verify low-center, stereo integrity, loudness, and ceiling. Mono variant: collapse the field and use it as a center-focused insert.

BREATH ROOT [Mono]

BREATH ROOT — Balances a vocal's breath and root so neither the air nor the low center dominates. Mono variant: collapse the field and use it as a center-focused insert.

CANON GROUND [Mono]

CANON GROUND — Returns MAAT to a grounded reference for judging the chain before correction. Mono variant: collapse the field and use it as a center-focused insert.

FULL RESET [Mono]

FULL RESET — Returns MAAT to a grounded reference for judging the chain before correction. Mono variant: collapse the field and use it as a center-focused insert.

MAAT SWEET SPOT [Dual Mono]

MAAT SWEET SPOT — Returns the sacred balance controls to the centered MAAT starting point. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

TRUTH ALIGN [Dual Mono]

TRUTH ALIGN — Centers Truth and Balance for a reference decision before boosting or attenuating a band. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

FOUNDATION WEIGHT [Dual Mono]

FOUNDATION WEIGHT — Sets the Foundation frequency and boost/atten pair for low-center balance. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

AIR SHEEN [Dual Mono]

AIR SHEEN — Uses Air Boost/Atten and Bandwidth to correct the upper field without over-brightening. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

LOW END MERCY [Dual Mono]

LOW END MERCY — Sets the Foundation frequency and boost/atten pair for low-center balance. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

BRIGHTNESS MERCY [Dual Mono]

BRIGHTNESS MERCY — Uses Air Boost/Atten and Bandwidth to correct the upper field without over-brightening. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

MIX SEAT [Dual Mono]

MIX SEAT — Seats the mix or chamber by combining Balance, Architecture, and a restrained tonal move. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

WARM BALANCE [Dual Mono]

WARM BALANCE — Tilts the balance toward body while retaining enough air for the source to speak. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

MASTER READY [Dual Mono]

MASTER READY — A restrained final-balance recipe; verify low-center, stereo integrity, loudness, and ceiling. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

CHAMBER POLISH [Dual Mono]

CHAMBER POLISH — Seats the mix or chamber by combining Balance, Architecture, and a restrained tonal move. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

GENTLE FINISH [Dual Mono]

GENTLE FINISH — A restrained final-balance recipe; verify low-center, stereo integrity, loudness, and ceiling. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

BREATH ROOT [Dual Mono]

BREATH ROOT — Balances a vocal's breath and root so neither the air nor the low center dominates. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

CANON GROUND [Dual Mono]

CANON GROUND — Returns MAAT to a grounded reference for judging the chain before correction. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

FULL RESET [Dual Mono]

FULL RESET — Returns MAAT to a grounded reference for judging the chain before correction. Dual-mono variant: preserve independent left/right decisions for asymmetric sources.

Meters and visualizers

TRUTH: Composite tonal/phase balance score. Higher values mean the current foundation/air balance is closer to the intended field.

INPUT / OUTPUT: Live pre/post level. Use for level matching.

FOUNDATION: Low-frequency contribution. Shows active foundation energy.

AIR: Upper-frequency contribution. Shows active air energy.

HORIZON X

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Mix Bus

Mastering finalizer with dawn/dusk states, volume, drive, maximizer, depth, clarity, gravity, pull, collapse, return, and blended Horizon/Event modes.

Recommended use: mastering finalizer and controlled lift

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
input	Input	Float
output	Output	Float
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice
bypass	Bypass	Bool
clip	RA Clip	Bool
gainmatch	Gain Match	Bool
volume	Volume	Factory
drive	Drive	Factory
maximizer	Maximizer	Factory
depth	Depth	Factory
clarity	Clarity	Factory
mix	Mix	Factory
gravity	Gravity	Factory
pull	Pull	Factory
collapse	Collapse	Factory
return	Return	Factory
eventBlend	Event Blend	Factory
horizonBlend	Horizon Blend	Factory
field	Field Of Life	Factory
mode	Mode	Factory

Factory starting points — source-derived purpose

[FINALIZER] Canon Open

Canon Open — Sets HORIZON X's drive, maximizer, depth, and clarity for the named finalizer role. Factory recipe: Drive 25%, Maximizer 24%, Depth 23%, Clarity 34%, Mode 0%.

[CLARITY] Source True

Source True — Sets HORIZON X's drive, maximizer, depth, and clarity for the named finalizer role. Factory recipe: Drive 38%, Maximizer 37%, Depth 36%, Clarity 62%, Mode 0%.

[DEPTH] Root Anchor

Root Anchor — Sets HORIZON X's drive, maximizer, depth, and clarity for the named finalizer role. Factory recipe: Drive 31%, Maximizer 34%, Depth 53%, Clarity 40%, Mode 20%.

[EVENT] Motion Rise

Motion Rise — Uses the event mode for audible movement rather than a static finalizer. Factory recipe: Drive 38%, Maximizer 37%, Depth 36%, Clarity 37%, Mode 100%.

[MAXIMIZER] Expansion

Expansion — Tests expansion/Maximizer authority; match output and check transients. Factory recipe: Drive 47%, Maximizer 53%, Depth 38%, Clarity 50%, Mode 60%.

[FINALIZER] Full Field

Full Field — Sets HORIZON X's drive, maximizer, depth, and clarity for the named finalizer role. Factory recipe: Drive 48%, Maximizer 47%, Depth 46%, Clarity 47%, Mode 0%.

[UTILITY] Canon Reset

Canon Reset — Returns the horizon/finalizer lanes to the utility reference point. Factory recipe: Drive 51%, Maximizer 50%, Depth 49%, Clarity 50%, Mode 0%.

Meters and visualizers

LIVE SIGNAL: Per-channel input RMS on a -60 to 0 dBFS scale. Shows program energy entering the finalizer.

FIELD STATE: Combined Horizon/Event processing state. A process-state visualization, not a delivery-loudness meter.

OUTPUT LEVEL: Post-finalizer level on a -60 to 0 dBFS scale. Use with LIVE SIGNAL for level-fair review.

PLATINUM

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Mix Bus

Mastering authority processor using silver air, gold drive, copper body, iron glue, nickel focus, platinum authority, and final output.

Recommended use: master bus authority; secondary red-orange color/amp/tape support

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice
gainmatch	Gain Match	Bool
AG_AIR	AG Air	Factory
AU_DRIVE	AU Drive	Factory
CU_BODY	CU Body	Factory
FE_GLUE	FE Glue	Factory
NI_FOCUS	NI Focus	Factory
PT_AUTHORITY	PT Authority	Factory
OUTPUT	Output	Factory

Factory starting points — source-derived purpose

PLATINUM CANON RESET

PLATINUM CANON RESET — Returns the hardware-inspired material lanes to the canonical center.

PLATINUM AIR CROWN

PLATINUM AIR CROWN — Raises AG Air and PT Authority toward an open, polished crown.

PLATINUM BODY THRONE

PLATINUM BODY THRONE — Uses CU Body and AU Drive for a broad, authoritative center.

PLATINUM GLUE FIELD

PLATINUM GLUE FIELD — Uses FE Glue to bring the master together without replacing its transient contrast.

PLATINUM FOCUS CUT

PLATINUM FOCUS CUT — Uses NI Focus to clarify a crowded center before adding more authority.

PLATINUM DUAL AUTH

PLATINUM DUAL AUTH — Balances independent authority lanes for a dual-source or asymmetric master.

PLATINUM FULL RANGE

PLATINUM FULL RANGE — Engages the complete Platinum material authority field; use only after a level-matched reference.