

DIHWorld Audio

Mastering Core Technical Manual

Current product versions, controls, presets, meters, and placement

DIHWorld Audio builds connected production systems around the Imhotep 369 Engine—a Triadic Harmonic Lattice—and Ma'at 357 / MomentumBend. Phi-derived control and the canonical Phi/2 ceiling preserve movement, balance, and musical intent without brickwall limiting.

This edition documents 5 current products. Release numbers are taken from the installed DIHWorld Audio Audio Units verified on 2026-09-05; they are product versions, not a shared catalog version.

Canon reference: normalized $\Phi/2 = 0.809016994$. MomentumBend shapes motion and containment; the ceiling is a canonical boundary, not permission for hard limiting.

Operating law: begin from reset or a purpose-matched preset, compare at equal loudness, change one system at a time, and judge the result in the full arrangement.

ANKH

RELEASE	FAMILY	PLACEMENT
v2.1.4	Mastering Core	Master Field

Sacred optical leveler for late-stage compression, Ma'at limiting, attack, release, drive, ratio, stereo link, Flower luminosity, and final containment.

Recommended use: final containment authority

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
gainmatch	Gain Match	Bool
inputDb	RA Input	Float
mix	Mix	Float
attack	Sekhem Attack	Float
release	Ma'at Release	Float
drive	Ptah Drive	Float
ascension	Ascension Ratio	Float
outputDb	Amun Output	Float
compress	Compress	Bool
limit_on	Limit	Bool
flower_of_life	Flower of Life	Bool
link	Stereo Link	Bool
bypass	Bypass	Bool
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice

Factory starting points

[Stereo] ESSENTIAL / Default • [Stereo] COLOR / Soft Optical • [Stereo] BUS / Life Compress • [Stereo] MASTER / Canon Ceiling • [Stereo] REPAIR / Transient Watch • [Stereo] UTILITY / Unity Reference • [Mono] ESSENTIAL / Default • [Mono] COLOR / Soft Optical • [Mono] BUS / Life Compress • [Mono] MASTER / Canon Ceiling • [Mono] REPAIR / Transient Watch • [Mono] UTILITY / Unity Reference • [Dual Mono] ESSENTIAL / Default • [Dual Mono] COLOR / Soft Optical • [Dual Mono] BUS / Life Compress • [Dual Mono] MASTER / Canon Ceiling • [Dual Mono] REPAIR / Transient Watch • [Dual Mono] UTILITY / Unity Reference

Meters and visualizers

INPUT LEVEL: Peak level entering ANKH. Use to verify healthy mastering-chain entry.

GAIN REDUCTION: Current optical/limiter attenuation. More fill means more level is being removed.

OUTPUT LEVEL: Peak level after containment. Compare with Input for level-fair decisions.

SPHYNX

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Mix Bus

Mastering normalizer and calibrator that prepares input level, target, engine strength, normalization amount, mix, and output.

Recommended use: prepares material before field/finalization

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
INPUT	Input	Float
CALIBRATE	Calibrate	Float
NORMALIZE	Normalize	Float
ENGINE	Engine	Float
TARGET	Target	Float
MIX	Mix	Float
OUTPUT	Output	Float
gainmatch	Gain Match	Bool
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice

Factory starting points

SPHYNX CANON ALIGN [Stereo] • SPHYNX GENTLE CALIBRATE [Stereo] • SPHYNX TRANSLATION [Stereo] • SPHYNX DYNAMIC PRESERVE [Stereo] • SPHYNX MASTER ANCHOR [Stereo] • SPHYNX LEVEL MATCH [Stereo] • SPHYNX CANON ALIGN [Mono] • SPHYNX GENTLE CALIBRATE [Mono] • SPHYNX TRANSLATION [Mono] • SPHYNX DYNAMIC PRESERVE [Mono] • SPHYNX MASTER ANCHOR [Mono] • SPHYNX LEVEL MATCH [Mono] • SPHYNX CANON ALIGN [Dual Mono] • SPHYNX GENTLE CALIBRATE [Dual Mono] • SPHYNX TRANSLATION [Dual Mono] • SPHYNX DYNAMIC PRESERVE [Dual Mono] • SPHYNX MASTER ANCHOR [Dual Mono] • SPHYNX LEVEL MATCH [Dual Mono]

Meters and visualizers

INPUT PEAK: Peak entering calibration. Confirms available headroom before normalization.

PROGRAM RMS: Average program energy. Use to understand body level, not final delivery loudness alone.

AUTO TRIM: Gain correction calculated by SPHYNX. Center is 0 dB; left cuts and right boosts.

OUTPUT PEAK: Peak after normalization. Verify headroom after calibration.

Crest / headroom: Peak-to-RMS and remaining space. Use together to avoid flattening transient structure.

Maat

RELEASE	FAMILY	PLACEMENT
v1.0.12	Mastering Core	Mix Bus

Mastering balance processor for foundation and air, bandwidth, truth, architecture, phase, stereo link, saturation mode, and output.

Recommended use: mastering balance/justice stage with secondary observation/advisor dot

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice
FOUNDATION_BOOST	Foundation Boost	Float
FOUNDATION_ATTEN	Foundation Atten	Float
FOUNDATION_FREQ	Foundation Frequency	Float
AIR_BOOST	Air Boost	Float
AIR_ATTEN	Air Atten	Float
BANDWIDTH	Bandwidth	Float
BALANCE	Balance	Float
TRUTH	Truth	Float
ARCHITECTURE	Architecture	Float
OUTPUT	Output	Float
POWER	Power	Bool
gainmatch	Gain Match	Bool
PHASE_INVERT	Phase Invert	Bool
FOUNDATION_WEIGHT_ON	Foundation Weight On	Bool
RUMBLE_HPF	Rumble HPF	Float
STEREO_LINK_MODE	Stereo Link Mode	Float
SATURATION	Saturation Tube Tape	Float

Factory starting points

MAAT SWEET SPOT [Stereo] • TRUTH ALIGN [Stereo] • FOUNDATION WEIGHT [Stereo] • AIR SHEEN [Stereo] • LOW END MERCY [Stereo] • BRIGHTNESS MERCY [Stereo] • MIX SEAT [Stereo] • WARM BALANCE [Stereo] • MASTER READY [Stereo] • CHAMBER POLISH [Stereo] • GENTLE FINISH [Stereo] • BREATH ROOT [Stereo] • CANON GROUND [Stereo] • FULL RESET [Stereo] • MAAT SWEET SPOT [Mono] • TRUTH ALIGN [Mono] • FOUNDATION WEIGHT [Mono] • AIR SHEEN [Mono] • LOW END MERCY [Mono] • BRIGHTNESS MERCY [Mono] • MIX SEAT [Mono] • WARM BALANCE [Mono] • MASTER READY [Mono] • CHAMBER POLISH [Mono] • GENTLE FINISH [Mono] • BREATH ROOT [Mono] • CANON GROUND [Mono] • FULL RESET [Mono] • MAAT SWEET SPOT [Dual Mono] • TRUTH ALIGN [Dual Mono] • FOUNDATION WEIGHT [Dual Mono] • AIR SHEEN [Dual Mono] • LOW END MERCY [Dual Mono] • BRIGHTNESS MERCY [Dual Mono] • MIX SEAT [Dual Mono] • WARM BALANCE [Dual Mono] • MASTER READY [Dual Mono] • CHAMBER POLISH [Dual Mono] • GENTLE FINISH [Dual Mono] • BREATH ROOT [Dual Mono] • CANON GROUND [Dual Mono] • FULL RESET [Dual Mono]

Meters and visualizers

TRUTH: Composite tonal/phase balance score. Higher values mean the current foundation/air balance is closer to the intended field.

INPUT / OUTPUT: Live pre/post level. Use for level matching.

FOUNDATION: Low-frequency contribution. Shows active foundation energy.

AIR: Upper-frequency contribution. Shows active air energy.

HORIZON X

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Mix Bus

Mastering finalizer with dawn/dusk states, volume, drive, maximizer, depth, clarity, gravity, pull, collapse, return, and blended Horizon/Event modes.

Recommended use: mastering finalizer and controlled lift

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
input	Input	Float
output	Output	Float
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice
bypass	Bypass	Bool
clip	RA Clip	Bool
gainmatch	Gain Match	Bool
volume	Volume	Factory
drive	Drive	Factory
maximizer	Maximizer	Factory
depth	Depth	Factory
clarity	Clarity	Factory
mix	Mix	Factory
gravity	Gravity	Factory
pull	Pull	Factory
collapse	Collapse	Factory
return	Return	Factory
eventBlend	Event Blend	Factory
horizonBlend	Horizon Blend	Factory
field	Field Of Life	Factory
mode	Mode	Factory

Factory starting points

[FINALIZER] Canon Open • [CLARITY] Source True • [DEPTH] Root Anchor • [EVENT] Motion Rise • [MAXIMIZER] Expansion • [FINALIZER] Full Field • [UTILITY] Canon Reset

Meters and visualizers

LIVE SIGNAL: Per-channel input RMS on a -60 to 0 dBFS scale. Shows program energy entering the finalizer.

FIELD STATE: Combined Horizon/Event processing state. A process-state visualization, not a delivery-loudness meter.

OUTPUT LEVEL: Post-finalizer level on a -60 to 0 dBFS scale. Use with LIVE SIGNAL for level-fair review.

PLATINUM

RELEASE	FAMILY	PLACEMENT
v1.0.2	Mastering Core	Mix Bus

Mastering authority processor using silver air, gold drive, copper body, iron glue, nickel focus, platinum authority, and final output.

Recommended use: master bus authority; secondary red-orange color/amp/tape support

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice
gainmatch	Gain Match	Bool
AG_AIR	AG Air	Factory
AU_DRIVE	AU Drive	Factory
CU_BODY	CU Body	Factory
FE_GLUE	FE Glue	Factory
NI_FOCUS	NI Focus	Factory
PT_AUTHORITY	PT Authority	Factory
OUTPUT	Output	Factory

Factory starting points

PLATINUM CANON RESET • PLATINUM AIR CROWN • PLATINUM BODY THRONE • PLATINUM GLUE FIELD • PLATINUM FOCUS CUT • PLATINUM DUAL AUTH • PLATINUM FULL RANGE