

DIHWorld Audio

Mastering Core Manual

Current product versions, controls, presets, meters, and placement

DIHWorld Audio builds connected production systems around the Imhotep 369 Engine—a Triadic Harmonic Lattice—and Ma'at 357 / MomentumBend. Phi-derived control and the canonical Phi/2 ceiling preserve movement, balance, and musical intent without brickwall limiting.

This edition documents 5 current products. Release numbers are taken from the installed DIHWorld Audio Audio Units verified on 2026-10-05; they are product versions, not a shared catalog version.

Canon reference: normalized $\text{Phi}/2 = 0.809016994$. MomentumBend shapes motion and containment; the ceiling is a canonical boundary, not permission for hard limiting.

Operating law: begin from reset or a purpose-matched preset, compare at equal loudness, change one system at a time, and judge the result in the full arrangement.

ANKH

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Master Field

Sacred optical leveler for late-stage compression, Ma'at limiting, attack, release, drive, ratio, stereo link, Flower luminosity, and final containment.

Recommended use: final containment authority

Customer formats: AU, VST3, Standalone

Primary controls

Gain Match • RA Input • Mix • Sekhem Attack • Ma'at Release • Ptah Drive • Ascension Ratio • Amun Output • Compress • Limit • Flower of Life • Stereo Link

Factory starting points

[Stereo] ESSENTIAL / Default • [Stereo] COLOR / Soft Optical • [Stereo] BUS / Life Compress • [Stereo] MASTER / Canon Ceiling • [Stereo] REPAIR / Transient Watch • [Stereo] UTILITY / Unity Reference • [Mono] ESSENTIAL / Default • [Mono] COLOR / Soft Optical • [Mono] BUS / Life Compress • [Mono] MASTER / Canon Ceiling • [Mono] REPAIR / Transient Watch • [Mono] UTILITY / Unity Reference • [Dual Mono] ESSENTIAL / Default • [Dual Mono] COLOR / Soft Optical • [Dual Mono] BUS / Life Compress • [Dual Mono] MASTER / Canon Ceiling • [Dual Mono] REPAIR / Transient Watch • [Dual Mono] UTILITY / Unity Reference

Meters and visualizers

INPUT LEVEL: Peak level entering ANKH. Use to verify healthy mastering-chain entry.

GAIN REDUCTION: Current optical/limiter attenuation. More fill means more level is being removed.

OUTPUT LEVEL: Peak level after containment. Compare with Input for level-fair decisions.

SPHYNX

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Mix Bus

Mastering normalizer and calibrator that prepares input level, target, engine strength, normalization amount, mix, and output.

Recommended use: prepares material before field/finalization

Customer formats: AU, VST3, Standalone

Primary controls

Input • Calibrate • Normalize • Engine • Target • Mix • Output • Gain Match • Channel Mode • Dual Mono Link

Factory starting points

SPHYNX CANON ALIGN [Stereo] • SPHYNX GENTLE CALIBRATE [Stereo] • SPHYNX TRANSLATION [Stereo] • SPHYNX DYNAMIC PRESERVE [Stereo] • SPHYNX MASTER ANCHOR [Stereo] • SPHYNX LEVEL MATCH [Stereo] • SPHYNX CANON ALIGN [Mono] • SPHYNX GENTLE CALIBRATE [Mono] • SPHYNX TRANSLATION [Mono] • SPHYNX DYNAMIC PRESERVE [Mono] • SPHYNX MASTER ANCHOR [Mono] • SPHYNX LEVEL MATCH [Mono] • SPHYNX CANON ALIGN [Dual Mono] • SPHYNX GENTLE CALIBRATE [Dual Mono] • SPHYNX TRANSLATION [Dual Mono] • SPHYNX DYNAMIC PRESERVE [Dual Mono] • SPHYNX MASTER ANCHOR [Dual Mono] • SPHYNX LEVEL MATCH [Dual Mono]

Meters and visualizers

INPUT PEAK: Peak entering calibration. Confirms available headroom before normalization.

PROGRAM RMS: Average program energy. Use to understand body level, not final delivery loudness alone.

AUTO TRIM: Gain correction calculated by SPHYNX. Center is 0 dB; left cuts and right boosts.

OUTPUT PEAK: Peak after normalization. Verify headroom after calibration.

Crest / headroom: Peak-to-RMS and remaining space. Use together to avoid flattening transient structure.

Maat

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Mix Bus

Mastering balance processor for foundation and air, bandwidth, truth, architecture, phase, stereo link, saturation mode, and output.

Recommended use: mastering balance/justice stage with secondary observation/advisor dot

Customer formats: AU, VST3, Standalone

Primary controls

Channel Mode • Dual Mono Link • Foundation Boost • Foundation Atten • Foundation Frequency • Air Boost • Air Atten • Bandwidth • Balance • Truth • Architecture • Output

Factory starting points

MAAT SWEET SPOT [Stereo] • TRUTH ALIGN [Stereo] • FOUNDATION WEIGHT [Stereo] • AIR SHEEN [Stereo] • LOW END MERCY [Stereo] • BRIGHTNESS MERCY [Stereo] • MIX SEAT [Stereo] • WARM BALANCE [Stereo] • MASTER READY [Stereo] • CHAMBER POLISH [Stereo] • GENTLE FINISH [Stereo] • BREATH ROOT [Stereo] • CANON GROUND [Stereo] • FULL RESET [Stereo] • MAAT SWEET SPOT [Mono] • TRUTH ALIGN [Mono] • FOUNDATION WEIGHT [Mono] • AIR SHEEN [Mono] • LOW END MERCY [Mono] • BRIGHTNESS MERCY [Mono] • MIX SEAT [Mono] • WARM BALANCE [Mono] • MASTER READY [Mono] • CHAMBER POLISH [Mono] • GENTLE FINISH [Mono] • BREATH ROOT [Mono] • CANON GROUND [Mono] • FULL RESET [Mono] • MAAT SWEET SPOT [Dual Mono] • TRUTH ALIGN [Dual Mono] • FOUNDATION WEIGHT [Dual Mono] • AIR SHEEN [Dual Mono] • LOW END MERCY [Dual Mono] • BRIGHTNESS MERCY [Dual Mono] • MIX SEAT [Dual Mono] • WARM BALANCE [Dual Mono] • MASTER READY [Dual Mono] • CHAMBER POLISH [Dual Mono] • GENTLE FINISH [Dual Mono] • BREATH ROOT [Dual Mono] • CANON GROUND [Dual Mono] • FULL RESET [Dual Mono]

Meters and visualizers

TRUTH: Composite tonal/phase balance score. Higher values mean the current foundation/air balance is closer to the intended field.

INPUT / OUTPUT: Live pre/post level. Use for level matching.

FOUNDATION: Low-frequency contribution. Shows active foundation energy.

AIR: Upper-frequency contribution. Shows active air energy.

HORIZON X

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Mix Bus

Mastering finalizer with dawn/dusk states, volume, drive, maximizer, depth, clarity, gravity, pull, collapse, return, and blended Horizon/Event modes.

Recommended use: mastering finalizer and controlled lift

Customer formats: AU, VST3, Standalone

Primary controls

Input • Output • Channel Mode • Dual Mono Link • Bypass • RA Clip • Gain Match • Volume • Drive • Maximizer • Depth • Clarity

Factory starting points

[FINALIZER] Canon Open • [CLARITY] Source True • [DEPTH] Root Anchor • [EVENT] Motion Rise • [MAXIMIZER] Expansion • [FINALIZER] Full Field • [UTILITY] Canon Reset

Meters and visualizers

LIVE SIGNAL: Per-channel input RMS on a -60 to 0 dBFS scale. Shows program energy entering the finalizer.

FIELD STATE: Combined Horizon/Event processing state. A process-state visualization, not a delivery-loudness meter.

OUTPUT LEVEL: Post-finalizer level on a -60 to 0 dBFS scale. Use with LIVE SIGNAL for level-fair review.

PLATINUM

RELEASE	FAMILY	PLACEMENT
v1.0.1	Mastering Core	Mix Bus

Mastering authority processor using silver air, gold drive, copper body, iron glue, nickel focus, platinum authority, and final output.

Recommended use: master bus authority; secondary red-orange color/amp/tape support

Customer formats: AU, VST3, Standalone

Primary controls

Channel Mode • Dual Mono Link • Gain Match • AG Air • AU Drive • CU Body • FE Glue • NI Focus • PT Authority • Output

Factory starting points

PLATINUM CANON RESET • PLATINUM AIR CROWN • PLATINUM BODY THRONE • PLATINUM GLUE FIELD • PLATINUM FOCUS CUT • PLATINUM DUAL AUTH • PLATINUM FULL RANGE