

Headless Writer

Keyboard & LED quick reference — keep this by the machine

KEYS

F2

New page — ends the current one; your next keystroke starts a fresh, freshly-timestamped page.

F8

Wi-Fi setup — type the network name, Enter, type the password, Enter.

Esc

Cancel — backs out of Wi-Fi setup at any point, no harm done.

**F12
F12**

Maintenance shell — press twice to confirm. Any other key after the first F12 cancels instead.

DOING THINGS

Connect to Wi-Fi

1. Press F8
2. Type network name, Enter
3. Type password, Enter
4. Watch the LEDs for the result.

Do maintenance / update / plug in a screen

1. Press F12 twice
2. Log in
3. **exit** when done — writing mode resumes on its own. Need to see the screen? Run **enable-hdmi.sh** once logged in.

LEDS — MAINTENANCE MODE

Shown left-to-right as Num Lock, then Caps Lock:

PATTERN



Both blinking slowly, together — press F12 again to confirm, or any other key to cancel.



Both blinking, alternating — you're in the maintenance shell now.

The small power-symbol light is wired directly to the power supply, not to any of this: steady is normal, blinking means the power supply or battery can't keep up.

LEDS — NORMAL USE

NUM LOCK — the machine itself



Brief flash every few seconds — alive and working normally.



Solid on — stuck; hasn't responded in a while.



One quick flash — a page was just saved.



Three quick blips — the last background backup failed.

CAPS LOCK — Wi-Fi



Off — not connected.



Brief flash every few seconds — connected.

LEDS — SETUP IN PROGRESS

Both LEDs work together while setting up Wi-Fi (or, later, cloud sync) — each pattern shown left-to-right as Num Lock, then Caps Lock:

PATTERN



Num off, Caps on — typing the first field (e.g. network name).



Both on — typing the second field (e.g. password).



Both blinking quickly together — working on it.



Both flash quickly three times — success.



Both stutter, held ~25 sec — failed. Try again with F8.