

## **Washer - Drum will not spin**

**SAFETY:** Isolate the machine at the main disconnect and apply lockout/tagout before any inspection. Confirm the drum has fully stopped before opening the panel. Moving parts and residual voltage can cause serious injury.

Step 1 - Door interlock. A failed door interlock reports as error code E14 and prevents the motor from energising. Verify interlock continuity and door strike alignment before anything else.

Step 2 - Drive belt. Inspect the belt for wear, glazing, or slippage. Replace a cracked or glazed belt. Correct belt tension is 12 mm deflection at mid-span under light thumb pressure.

Step 3 - Motor and inverter. If the interlock and belt are good, check the motor capacitor and the inverter output. Do not probe the inverter terminals while energised; use the service test point instead.

## **Washer - Will not fill or will not drain**

SAFETY: Close the water supply before removing hoses. Standing water may be hot.

No fill - Check the water inlet valve and the supply tap. Error code E18 indicates the fill timeout was exceeded. Clean the inlet filter screens.

No drain - Error code E22 indicates water is not draining. Check the drain pump and hose for blockage, and clear the pump filter, before restarting a cycle.

Overflow - Error code E27 indicates an overflow or a stuck pressure switch. Inspect the pressure hose for kinks and the air trap for debris.

## **Washer - Excessive vibration or walking**

**SAFETY:** Never restrain a vibrating machine by hand. Stop the cycle first.

**Load** - Uneven loads are the most common cause. Redistribute laundry and avoid single bulky items. The control aborts spin and shows E45 on repeated imbalance.

**Suspension** - Inspect shock absorbers and suspension springs for wear. Replace absorbers in pairs.

**Levelling** - Confirm all four feet are on the floor and the machine is level within 2 mm. Tighten the locknuts after adjustment.

## Error code quick reference

E14 - Door interlock open or faulty. Controller inhibits spin. Check interlock continuity and door strike alignment.

E18 - Fill timeout. Water did not reach level in time. Check inlet valve, tap, and filter screens.

E22 - Water not draining. Check drain pump and hose for blockage.

E27 - Overflow or stuck pressure switch. Inspect pressure hose and air trap.

E31 - Over-temperature on the heating circuit. Allow to cool and inspect the NTC sensor.

E45 - Repeated spin imbalance. Redistribute the load; inspect suspension.

E52 - Motor tachometer signal lost. Check the tachometer connector and motor wiring.

## **Dryer - No heat or overheating**

**SAFETY:** Dryers reach high temperatures. Allow the cabinet to cool and isolate power before servicing. Clean lint before every inspection - lint is a fire hazard.

**No heat** - Check the heating element, the thermal fuse, and the gas valve (gas models). A blown thermal fuse usually indicates restricted airflow.

**Overheating** - Error code E31 indicates over-temperature. Inspect the NTC temperature sensor and the high-limit thermostat. Verify the exhaust duct is not blocked and the lint filter is clean.

**Airflow** - Restricted airflow is the root cause of most heat faults. Check the lint screen, blower wheel, and exhaust run for blockage.

## **Dryer - Drum not turning**

SAFETY: Confirm the drum has stopped and isolate power before opening the cabinet.

Belt - A snapped or stretched drum belt is the most common cause. Replace the belt and inspect the idler pulley for free rotation.

Motor - If the belt is intact, check the drive motor and its start capacitor. A humming motor that will not start often indicates a failed capacitor.

## **Ironer and flatwork - Steam valve maintenance**

**SAFETY:** Steam lines operate at high temperature and pressure. Close the steam supply and allow the line to cool before servicing. Wear heat-resistant gloves.

**Leaking valve** - A leaking steam valve is usually caused by a worn seat or diaphragm. Replace the diaphragm kit; the part reference varies by model, so confirm it against the parts list.

**Testing** - After reassembly, pressure-test the valve at working pressure and check for leaks while restoring the supply slowly.

**Temperature** - If the roll temperature is unstable, inspect the steam trap and the condensate return before suspecting the controller.

## **Electrical safety and lockout/tagout**

Always assume circuits are live until proven otherwise. Isolate at the main disconnect, apply your personal lock and tag, and verify zero energy with a meter before touching terminals.

Capacitors can hold a charge after power is removed. Discharge motor-run and inverter capacitors through a suitable resistor before handling.

Never bypass a door interlock or a thermal safety device to keep a machine running. Report and replace failed safety components.



## **Preventive maintenance schedule**

Daily - Clean lint filters on dryers. Wipe door seals and check for foreign objects in drums.

Weekly - Inspect drive belts for wear and correct tension (washer belt: 12 mm mid-span deflection). Check hoses and clamps for leaks.

Monthly - Clean drain pump filters, inspect suspension and shock absorbers, and verify machine levelling. Test door interlocks for correct operation.

Quarterly - Inspect steam valves and traps, check electrical terminals for tightness, and review error-code history for recurring faults.