

StiMBER J70

FORMWORK RUNNERS SYSTEM

USER MANUAL & STANDARD OPERATING PROCEDURES

Installation • Usage • Storage • Handling • Safety

Covers All Variants: Basic (Spruce) | Plus (OSB) | Pro (Plastic LVL)

Tested At IIT Madras (Chennai) and Bureau Veritas, Bangalore

Manufactured & Marketed by Wallgreens Formsolutions LLP

Economic. Ecofriendly. Everlasting.

! IMPORTANT – READ BEFORE USE

Safety-Critical Document – Mandatory Reading

This manual must be read completely before the StiMBER J70 system is used on any project. All installation, usage, storage and handling must comply strictly with the instructions herein. Failure to follow these guidelines may result in structural failure, serious personal injury, or death. This document does not substitute a qualified structural engineer's design and approval.

Qualified Supervision Required

The J70 beam system must be installed, used, and struck only under the supervision of a qualified and experienced formwork or site engineer. All workers must be briefed on the contents of this manual before commencing work.

Rental Product – Handle with Care

StiMBER J70 beams are rental products supplied by Wallgreens Formsolutions LLP. Damage due to misuse, improper storage, or negligent handling will be charged to the hirer. Please refer to your rental agreement for full terms and conditions.

This manual is the property of Wallgreens Formsolutions LLP and is issued to clients for operational guidance only. Information is based on structural testing by IIT Madras (Chennai) and Bureau Veritas, Bangalore. Wallgreens reserves the right to revise this manual without prior notice. Always work from the latest version – confirm with your Wallgreens representative.

1 PRODUCT OVERVIEW

1.1 Introduction

The StiMBER J70 is a patented, high-performance engineered formwork runner developed by Wallgreens Formsolutions LLP, Mumbai. It combines the structural strength of a hot-dip galvanized steel rectangular tube with the nailability of a solid timber insert – creating a composite beam that is stronger, safer, more durable, and more economical than conventional timber runners.

The J70 is designed as a direct drop-in replacement for not only wooden and aluminium H beams but also all conventional solid timber runners – silver wood, pine wood, hollow steel channels, and LVL beams – in Indian construction formwork. Its slotted steel tube design allows nailing of plywood shuttering directly through the slots without any proprietary accessories, making it fully compatible with existing conventional formwork systems at zero additional investment.

1.2 Product Family – Three Variants

The J70 is available in three variants differentiated by the timber insert material. The steel tube, end caps, dimensions, and fixing hardware are identical across all three variants.

Feature	J70 Basic	J70 Plus (OSB)	J70 Pro (Plastic LVL)
Insert Material	European Spruce C24	OSB 3-layer cross-battened	Waterproof LVL + 4-side plastic wrap
Insert Density	~600-700 kg/m3	~750 kg/m3	~650 kg/m3
Moisture Content	12-16%	< 5%	< 5% (sealed)
Core Gaps	None (solid)	None (solid)	May Slightly Occur
Screw Holding	Moderate	Excellent	Excellent
Rot/Decay Resistance	Moderate	Good	Excellent (plastic-coated)
Termite Resistance	Moderate	100% Resistant	100% Resistant
Rental Rate	INR 20/m/month	INR 23/m/month	INR 25/m/month
Best Suited For	General slab/beam/column	High repetition, moisture-prone sites	Aggressive environments, long-term

1.3 Key Value Proposition

- **Up to 300 repetitions – versus 2-3 for pine/silver wood and ~30 for wooden H-beams**

- Cost per usage as low as INR 2/metre – lowest total cost of ownership in its category
- No new accessories required – 100% compatible with existing conventional formwork
- Nailable through slots – plywood fixed directly; familiar workflow for site carpenters
- Hot-dip galvanized at 70 microns – superior corrosion resistance and site durability
- Independently tested – IIT Madras (Chennai) and Bureau Veritas, Bangalore
- Lightweight at 4.5 kg/m – faster erection, easier handling vs heavier alternatives
- Uniform, consistent quality – every beam manufactured to identical factory specifications
- Sustainable – dramatically reduces site dependence on raw timber and deforestation

2 COMPONENTS & TECHNICAL SPECIFICATIONS

2.1 Component Identification

Each J70 beam is a factory-assembled composite of four components. No site assembly of components is required or permitted.

No.	Part	Description	Material & Standard
1	Steel Tube	70x50x2mm thick rectangular tube with 22 slotted openings at 100mm centres	YST 310 per IS 4923. HDG post slot-cutting @ 700 GSM. Pre-galvanizing NOT permitted.
2	Timber Insert	63x43mm solid insert seated inside the steel tube	Spruce C24 per EN 338. MC 12-16%. Painted Golden Yellow (IS 5, Shade 356). [Basic variant – see Section 1.2 for Plus & Pro]
3	End Caps (x2)	2mm pressed steel caps at each beam end	IS 2062 Grade A. HDG post-fabrication @ 700 GSM.
4	Screws (x4)	4.8mm dia x 25mm countersunk screws securing timber to tube	Grade 8.8 galvanized

2.2 Dimensional Data – Standard Lengths

Standard Length	Overall Width	Overall Depth	Tube Wall Thk.	Insert Section	Approx. Weight
1.2 m	50 mm	70 mm	2 mm	63 x 43 mm	5.4 kg
1.5 m	50 mm	70 mm	2 mm	63 x 43 mm	6.75 kg
1.8 m	50 mm	70 mm	2 mm	63 x 43 mm	8.1 kg
2.4 m	50 mm	70 mm	2 mm	63 x 43 mm	10.8 kg
3.0 m	50 mm	70 mm	2 mm	63 x 43 mm	13.5 kg

Standard Length	Overall Width	Overall Depth	Tube Wall Thk.	Insert Section	Approx. Weight
3.6 m	50 mm	70 mm	2 mm	63 x 43 mm	16.2 kg

NOTE Weight calculated at 4.5 kg/m per product specification. The 70mm dimension is the load-bearing depth and must always be oriented VERTICALLY in use. The 50mm face sits horizontally.

2.3 Slot & Fixing Geometry

- Slots per 3.6m beam: 22 nos. through-slots in the 50mm (depth) face
- Slot spacing: 100mm centres, with 175mm end margins at each end
- End detail (3.6m): 175mm from beam end to first slot, then 150mm, then 50mm, then 100mm centres
- Pilot holes: 5mm diameter, both sides of tube at slot positions – to assist nail alignment
- End cap length: 620mm with 4x R2.5 radius corners

i

Correct Orientation in Slab Use

Place J70 beams with the slotted 50mm face UPWARD. Nails pass downward through the slots into the timber insert. The golden-yellow timber insert visible through the slots is a quick visual confirmation of correct orientation.

2.4 Structural Test Data

The following values are from independent structural testing. These are ultimate (failure) capacities. A suitable factor of safety must be applied by the project structural engineer for all design calculations.

Test Parameter	J70 Basic (BV)	J70 Basic (IIT)	J70 Plus (IIT)	J70 Pro (IIT)
Ultimate Shear Capacity (kN)	8.99 avg	8.11	8.12	8.14
Shear Failure Load (kN)	Avg: 8.99	16.23	16.5	16.6
Avg. Ultimate Moment Capacity (kNm)	4.01	3.80	3.875	4.08
EI Flexural Rigidity – Test 1 (kNm2)	65.52	60.5	65.52	65.52
EI Flexural Rigidity – Test 2 (kNm2)	60.80	61.3	60.80	60.80
Testing Bodies	Bureau Veritas	IIT Madras	IIT Madras	IIT Madras

Design Responsibility

These are ultimate failure values. All structural design must apply an appropriate factor of safety as determined by the project structural engineer. Wallgreens does not provide structural design services. Never deploy the J70 system without engineer approval.

3 PRE-USE INSPECTION

3.1 Inspection on Receipt

Inspect every beam upon delivery and before each use. Notify Wallgreens immediately of any defective material received.

3.1.1 Steel Tube Checks

- Galvanizing intact – no bare metal patches, rust streaks, or flaking zinc
- No visible bends, kinks, or permanent deformation along length
- Slots are clean, free of concrete blockages, burrs, or sharp edges
- End caps present and firmly attached at both ends
- No cracking or splitting of weld seam
- Straightness: lay beam on flat surface; maximum bow must not exceed L/500 (e.g., 7.2mm for a 3.6m beam)

3.1.2 Timber Insert Checks

- Golden yellow paint coat present and largely intact (Basic variant)
- No visible splits, cracks, or fractures along the grain
- No bore holes, frass, or tunnels indicating pest infestation
- No fungal growth or discolouration indicating rot
- Timber firmly seated – should not rattle or shift inside tube
- Plus variant: OSB surface intact with no delamination or swelling
- Pro variant: Plastic wrapping continuous with no tears exposing LVL core

3.1.3 Assembly Check

- All four countersunk screws present and tight
- Beam length matches ordered/required length – confirm from label
- No signs of previous overloading – permanent camber, crushed end caps, or split timber

3.2 Rejection Criteria – Remove From Service

Withdraw and return to Wallgreens any beam showing:

- **Permanent bow/bend exceeding L/500**
- **Cracked or split steel tube**
- **Rust penetrating through galvanizing to base metal**
- **Timber split along full or partial length**
- **Timber insert loose or missing**
- **Missing or detached end caps**
- **Evidence of prior overloading – crushed sections or permanent deformation**
- **Pro variant: LVL core exposed over more than 10% of beam length**

!

Do Not Repair on Site

Damaged J70 beams must NOT be repaired, welded, bent back, or have inserts replaced on site. All repairs must be performed at Wallgreens' facility. Using damaged beams creates serious risk of formwork collapse and injury.

4 INSTALLATION & USAGE – SOP

4.1 System Assembly Overview

The J70 functions as the secondary beam (runner) in a conventional prop, cup lock or ring lock supported formwork system. The assembly hierarchy from bottom to top is:

Level	Component
1 (Base)	Adjustable steel props/cuploc/ringlock at designed spacing
2	4-way prop head / fork head on top of the staging
3	Primary beams – aluminium or wooden H beams, steel channels (one direction)
4	StiMBER J70 secondary runners (perpendicular to primary beams)
5 (Top)	Plywood shuttering nailed to J70 through the slots

J70 beams sit in the fork of the 4-way head or on the primary beams, with the 70mm depth vertical. Plywood is placed on top and nailed through the slots into the timber insert, creating a unified shuttering panel. No proprietary connectors or clamps are required.

NOTE

The J70 requires NO special accessories. It is fully compatible with existing conventional props, cup lock or ring lock on site – zero new investment required.

4.2 SOP – Slab Formwork

Step 1: Design Verification

1. Obtain the approved formwork design from the structural engineer, specifying prop spacing, primary beam spacing, and J70 beam spacing.
2. Confirm the specified J70 span does not exceed the safe working load for the expected slab thickness and pour rate.
3. Mark out prop positions on the floor below per the approved design.

Step 2: Prop Setting

1. Erect adjustable props at the designed spacing. Check props are plumb using a spirit level.
2. Tighten prop collars securely. The prop must support the full dead and live load from the slab.
3. Set prop height accounting for the combined thickness of primary beam + J70 beam + plywood.

Step 3: Primary Beam Placement

1. Place primary aluminium or wooden H beams or steel channels across the prop heads in the designed direction.
2. Seat firmly in the 4-way fork head. Do not allow primary beams to cant or sit off-centre.
3. Check that primary beams are level using a straight edge and spirit level.

Step 4: J70 Beam Placement

1. Place J70 beams perpendicular to primary beams at the designed spacing – typically 200mm to 400mm centres depending on slab thickness and structural design.
2. Orient beams with the 70mm dimension VERTICAL and slots facing UPWARD. The golden-yellow timber insert must be visible through slots from above.
3. Beams placed end-to-end must have their overlaps located over a primary beam – never in mid-span.
4. For longer spans, use the longest suitable beam length to minimise overlaps.
5. Ensure beam ends bear a minimum of 100mm on the primary beam at each end.

> **i**
> **Beam Joints**
> When two J70 beams meet end-to-end, both ends must bear on the same primary beam. Never place a joint in free span. Stagger joints between adjacent beam rows.

Step 5: Plywood Placement & Nailing

1. Place plywood sheets on top of the J70 beams, covering the full slab area.
2. Nail plywood through the slots into the timber insert using 75mm or 100mm wire nails, driven vertically through each slot.
3. Do not nail through the steel tube face – nails must only pass through the slots.

4. Minimum 2 nails per beam-to-plywood contact, at available slot positions.
5. Check plywood alignment and surface level. Apply form release oil before concreting.

Step 6: Pre-Pour Final Checks

1. Verify all props are plumb, tightened, and at correct height.
2. Verify all J70 beams are correctly oriented (slots up), properly seated, and not overhanging excessively.
3. Verify plywood is fully nailed, all edges are supported, and release oil is applied.
4. Verify no beams are cracked, bent, or showing signs of damage.
5. Obtain written sign-off from the site/formwork engineer before commencing pour.

!

Concrete Pour Rate

Concrete must be poured at the rate specified in the formwork design. Excessive speed, impact from concrete bucket drops, or vibrator contact with J70 beams can cause overloading and formwork failure.

4.3 SOP – Column Formwork

In column formwork, J70 beams are used as vertical soldier/waling runners positioned against the back face of plywood shuttering. Slots allow tie-rod hardware to pass through, eliminating the need for separate proprietary soldier profiles.

1. Erect plywood panels to the column lines against the reinforcement cage.
2. Position J70 beams VERTICALLY against the plywood back face at the designed horizontal spacing. Nail the plywood onto the J70 beams.
3. Pass tie rods through the plywood and fit horizontal walers or yoke clamps over the J70 beams at the designed vertical spacings.
4. Fit washers and wing nuts on the outside and tighten to specified torque.
5. Check all sides are plumb and square before concreting.
6. Pour concrete in lifts not exceeding the design pour height assumed in the formwork design.

NOTE

Plan plywood sheet layout and J70 positions together before erection to ensure tie rod locations coincide with available slots.

4.4 SOP – Retaining Wall Formwork

Procedure for retaining walls is similar to column formwork. J70 beams are positioned horizontally as waling runners behind the plywood, with tie rods through the slots at regular intervals. Diagonal raker props support the assembly at the calculated spacing per the structural design.

- J70 beams run horizontally across the plywood face at designed vertical intervals
- Slots must align with tie rod positions – plan layout before erection
- Diagonal raker props must anchor to a fixed point capable of resisting the full horizontal force
- Formwork height must not exceed the approved lateral pressure design limit

5 STRIKING & DESHUTTERING

5.1 Minimum Striking Times

Striking must not commence until concrete has achieved sufficient strength per IS 456 and as directed by the project structural engineer. The table below is a general guide only:

Structural Element	OPC Concrete (min.)	PPC / Blended Cement
Slab / Beam – full props removal	14-21 days (per design)	21-28 days
Column sides	24-48 hours	48-72 hours
Retaining walls	24-48 hours	48-72 hours

!

Never Strike Early

Early striking is a leading cause of slab collapse. Always obtain written approval from the structural engineer and confirm adequate cube strength test results before striking.

5.2 Deshuttering Procedure

1. Obtain written clearance from the structural engineer confirming adequate concrete strength.
2. Loosen prop adjustors gradually and uniformly. Do not release props suddenly or all at once.
3. Remove tie rods from column/wall forms carefully. Do not use the J70 as a lever.
4. Carefully lower the formwork assembly. Do not drop, throw, or allow assembly to fall.
5. Extract nails from plywood using a nail puller braced against the plywood – NOT against the J70 beam.
6. Separate plywood from J70 beams and stack each separately on level ground.
7. Remove concrete splatter from beams while still green if possible, using a scraper.
8. Inspect each beam immediately post-strike per Section 3 criteria.

Nail Removal – Critical

The most common cause of beam damage during deshuttering is levering against the J70 end cap or tube when extracting nails. Always brace the nail puller against the plywood sheet. Levering against the J70 bends end caps and splits the timber insert.

6 CLEANING & MAINTENANCE

6.1 Cleaning After Each Use

Clean beams after every use before storage or redeployment. Concrete residue degrades the galvanizing and timber, reducing service life significantly.

1. Remove loose concrete and mortar with a plastic scraper while material is still in the green stage if possible.
2. For hardened concrete, use a wire brush or light tapping with a rubber mallet. Do not use steel hammers directly on the tube face.
3. Do not use acid washes (e.g., hydrochloric acid) to clean beams – this destroys the galvanized coating irreversibly.
4. After cleaning, inspect galvanizing. Touch up minor scratches with cold galvanizing spray (minimum 95% zinc content).
5. Basic variant: Re-apply golden yellow enamel paint (IS 5, Shade 356) to any bare or weathered timber visible through slots.
6. Pro variant: Seal any small tears in plastic wrapping with UV-resistant waterproof tape pending return to Wallgreens for formal repair.

NOTE Concrete inside slots will prevent nailing in subsequent uses. Clear all slots after every use using a rod, screwdriver, or slot cleaning tool.

6.2 Timber Insert Maintenance

- Basic variant: Re-paint timber if more than 40% of visible surface shows bare wood
- Do not allow beams to sit in standing water or on saturated ground between uses
- Pro variant: Do not attempt to repair torn plastic wrap on site – return to Wallgreens

7 STORAGE

7.1 On-Site Storage

Correct storage preserves beam straightness, galvanizing integrity, and timber condition. Non-compliance with storage requirements is the primary cause of avoidable beam damage.

7.1.1 Ground Preparation

- Storage area must be flat, firm, and well-drained. Do not store on soft or waterlogged ground.
- Place timber or rubber packers at ground level – minimum 2 supports per beam, spaced max 1.0m apart, giving minimum 100mm ground clearance.
- Align all packers so beams lie flat without induced bow or twist.

7.1.2 Stacking

- Stack beams in layers with spacer battens between each layer. Battens must be vertically aligned between layers.
- Maximum recommended stack height: 2.0m (approximately 8-10 layers for 3.6m beams).
- Do not step on or walk over stacked beams.
- Face all beam slots in the same direction to allow visual inspection and slot cleaning without unstacking.
- Sort and stack beams by length – do not mix lengths in the same stack.

7.1.3 Weather Protection

- Cover stacked beams with a breathable tarpaulin or shade net. Do not use impermeable plastic sheeting that traps moisture.
- Basic variant: Never store in direct contact with rain or standing water – timber swelling within the tube can make the insert difficult to service.
- In coastal or high-humidity environments, apply a thin coat of anti-corrosion oil to exposed slot edges as a precaution.

7.1.4 Duration

- Short-term (up to 30 days): stack as above with tarpaulin cover, inspect weekly.
- Long-term (over 30 days): store indoors in a covered warehouse where possible. If outdoor, inspect weekly and after every major rain event.
- Do not store adjacent to generators, cement hoppers, or lime storage – alkaline and acidic environments accelerate zinc corrosion.

!

Fire Hazard

Do not store J70 beams near open flames, welding operations, or flammable materials. The timber insert is combustible.

7.2 Warehouse / Depot Storage

- Store in a dry, enclosed space away from direct sunlight and moisture
- Use racking systems with rubber padding on shelf contact points to prevent galvanizing damage
- Maintain minimum 1.2m aisle width between stacks for safe access
- Clearly separate and tag damaged/quarantined beams from serviceable stock

8 HANDLING & TRANSPORT

8.1 Manual Handling

- Always carry J70 beams with the 70mm depth held VERTICALLY. Carrying flat increases risk of permanent bow under the beam's own weight.
- Two-person carry is recommended for all lengths of 2.4m and above (a 3.6m beam weighs ~16.2 kg).
- Do not carry more than two beams per person at a time.
- Always use cut-resistant gloves – galvanized tube edges and slot cuts can be sharp.
- Do not drag beams across the floor or across each other – this scratches the galvanizing.
- Never use J70 beams as levers, crowbars, or stepping platforms.

8.2 Crane & Sling Handling

1. Bundle same-length beams together – maximum 20 beams per lift for 3.6m lengths; 30 beams for 1.8m and below.
2. Use flat-woven polyester slings (minimum 2-tonne WLL) – never use chain slings or wire rope directly on J70 beams.
3. Place softwood timber packers between slings and beams at contact points to prevent crushing.
4. Use minimum 2 sling points spaced at approximately 1/3 of bundle length from each end.
5. Lift slowly, check bundle balance before hoisting above head height.
6. Never lift bundles over workers. Establish a clear exclusion zone below all lifts.

8.3 Vehicle Transport

1. Load beams on truck/trailer with timber packers at 1.0m intervals to prevent vibration damage.
2. Secure with ratchet straps. Do not over-tighten to the point of crushing beams.
3. Beams must not protrude more than 1.0m beyond the vehicle body without a red flag marker.
4. Do not stack heavy materials on top of J70 beams during transport.
5. Inspect beams for transport damage immediately upon every delivery.

9 SAFETY

9.1 Mandatory PPE

PPE Item	Requirement
Safety Helmet	EN 397 or IS 2925 – mandatory at all times on site
Safety Footwear	Steel toe-capped boots – mandatory when handling J70 beams
Work Gloves	Cut-resistant gloves when handling beams
Safety Harness	Full-body harness when working at heights above 2.0m
Safety Glasses	During drilling, nailing, or cleaning operations
High Visibility Vest	During all crane and hoisting operations

9.2 Critical Safety Rules

!

Rule 1 – Never Overload

Never exceed the design load on J70 beams. Concentrated loads from concrete buckets, pump lines, or equipment placed on unsupported beams are a leading cause of formwork failure.

!

Rule 2 – No Unauthorised Modifications

Never cut, weld, drill, or modify J70 beams in any way. The composite section depends on the integrity of both steel tube and timber insert acting together. Any modification voids the product warranty and creates a structural hazard.

!

Rule 3 – No Use as Scaffold

J70 beams must never be used as scaffold boards, walkway planks, or stepping platforms. They are not designed for this loading mode.

Rule 4 – Engineer Approval Required

A qualified structural engineer must design and approve all formwork using J70 beams before erection. Improvising beam spacings, spans, or prop arrangements on site without engineer approval is strictly prohibited.

Rule 5 – Inspect Before Every Use

Every beam must pass the pre-use inspection (Section 3) before placement. A beam that fails inspection must be withdrawn from service until assessed by Wallgreens.

9.3 Emergency – Signs of Formwork Distress

If any of the following are observed during or after concrete placement, stop work immediately, evacuate the area, and report to the engineer:

- Audible cracking sounds from the formwork system
- Visible sagging or excessive deflection of the slab soffit
- Cracking, bowing, or failure of any J70 beam
- Settlement or tilting of any prop
- Concrete blowout through joints or gaps in shuttering
- Any sudden or unexpected movement of the formwork

Evacuate First

In any sign of imminent formwork failure, evacuate all personnel from the affected zone IMMEDIATELY. Do not attempt to shore up or repair formwork while concrete is being placed or is in the green state.

10 DO'S & DON'TS – QUICK REFERENCE

✓ DO'S	✗ DON'TS
✓ Always inspect beams before every use	✗ Do not use damaged, bent, or rusty beams
✓ Orient 70mm depth vertically, slots upward	✗ Do not cut, weld, drill, or modify beams
✓ Nail only through slots – never through tube face	✗ Do not nail through the steel tube face
✓ Ensure minimum 100mm end bearing on supports	✗ Do not use beams as scaffold or walkways
✓ Place beam joints only over primary beams	✗ Do not lever against end caps during striking
✓ Use cut-resistant gloves when handling	✗ Do not drag beams across floor or each other
✓ Clean beams thoroughly after every use	✗ Do not store beams in standing water
✓ Clear all slots of concrete after every use	

✓ Store off ground with packers, covered ✓ Use an engineer-approved formwork design ✓ Two-person carry for beams 2.4m and above ✓ Apply release oil to plywood before every pour	✗ Do not use acid wash for cleaning ✗ Do not place beam joints in mid-span ✗ Do not exceed the approved concrete pour rate ✗ Do not strike formwork before engineer clearance ✗ Do not repair damaged beams on site

11 TROUBLESHOOTING

Symptom	Likely Cause	Corrective Action
Plywood not sitting flat on J70	Beam placed flat (50mm up) instead of on edge (70mm up)	Re-orient beam – 70mm face must be vertical with slots upward
Nails not going into timber through slot	Slot blocked with old concrete; beam incorrectly oriented	Clear slot with rod/screwdriver; check orientation
Beam visibly bowing under load	Span too long; beam overloaded; damaged beam in use	Verify against design span; replace beam; review prop spacing with engineer
Concrete leaking through slot	Plywood not flush on beam; gap between plywood sheets	Re-nail tightly; seal gaps with foam tape before pour
Galvanizing peeling or rust visible	Acid wash used; mechanical damage; old beam	Touch up with cold galv spray
Timber insert splitting	Repeated heavy nailing at same location; nail too large; beam dropped	Withdraw beam from service; use correct nail size
Plywood sticking to concrete	Insufficient or no release oil applied to plywood face	Apply release oil thoroughly before every pour
Difficult to separate plywood from J70	Nails bent or over-driven	Use proper nail puller braced against plywood, NOT against J70
Slot partially blocked by end cap	Wrong assembly or damaged end cap	Return beam to Wallgreens for inspection

12 RENTAL INFORMATION & CONTACT

12.1 Rental Rates (Reference)

Variant	Rental Rate	Minimum Period	Notes
J70 Basic (Spruce C24)	INR 20 / m / month	3 months	Standard grade; general use
J70 Plus (OSB Insert)	INR 23 / m / month	3 months	High repetition & moisture-prone sites
J70 Pro (Plastic LVL)	INR 25 / m / month	3 months	Aggressive environments, long-term use

NOTE Rental rates are indicative and subject to change. Confirm current rates with your Wallgreens representative at time of order. Damaged material will be charged at replacement cost. Minimum rental period applies even if material is returned early.

12.2 Contact Us

Company	Wallgreens Formsolutions LLP
Address	#717, Panchsheel Plaza, Hughes Road, Mumbai - 400007
Phone 1	+91 93219 17719
Phone 2	+91 93219 17724
Email	mumbai@wallgreens.in
Website	formwork.in
Brand Tagline	StiMBER – Economic. Ecofriendly. Everlasting.

12.3 Certifications & Testing Bodies

- Structural Bending & Shear Testing: IIT Madras (Chennai)
- Independent Structural Verification: Bureau Veritas, Bangalore
- Steel Tube Standard: YST 310 as per IS 4923
- Timber Standard: Spruce C24 as per EN 338
- End Cap Material: IS 2062 Grade A

StiMBER™ – Economic. Ecofriendly. Everlasting.

Wallgreens Formsolutions LLP | formwork.in | +91 93219 17719 | mumbai@wallgreens.in