CM8 Mobile gimbal

User Manual



V1.0

Content:

1.Introducing CM8 18
2.Charging 19
3.Turning On and Folding 19
4.Gimbal Leveling 20
5.Using the Gimbal 20
6.Firmware Update 27
7.Product Specifications 28
8.Disclaimer and Safety Guidelines 30
9.Product Warranty Services 31
10.Warranty Card 32

I Introducing CM8



① Phone Clamp	② Mounting Hole	③ Zoom Button
④ Zoom Wheel	⑤ Joystick	⑥ Folding Axis
⑦ Mode Indicator	⑧ Battery Indicator	⑨ Power Button
⑩ Shutter Button	⑪ M Button	⑫ Bottom 1/4" Hole
⑬ Folding Lock	⑭ Tilt Motor	⑮ Type-C Charging Port
⑯ Roll Motor	⑰ Pan Motor	⑱ Trigger
⑲ Lanyard Hole		

II Charging

Before using for the first time, please fully charge the gimbal. Use a 5V2A charging adapter and the Type-C charging cable included with your purchase to charge the gimbal.
A red light indicates that it is charging, and a green light (solid) means the battery is fully charged.

III Unfolding & Folding

Hold the phone clamp with your left hand and the handle with your right hand, then unfold the arm as shown in the picture.



After use, power off the gimbal. Rotate the tilt motor so that the phone clamp is facing downward, then fold the arm downward, allowing the mounting hole to slide into the mounting lock and lock in place.



IV. Gimbal Calibration

1.Unfold the gimbal.
2.Following the sticker guide on the phone clamp, attach the phone to the clamp. Ensure the tracking camera is on the left side and the phone' s camera is facing up.
3.Adjust the phone's position by sliding it left or right to achieve balance. If the phone tilts to the left, slide it right; if it tilts to the right, slide it left until it' s balanced, as shown in the picture.

Equilibrium state

Disequilibrium

Disequilibrium

4.Press and hold the power button for 3 seconds to power on the gimbal. The gimbal will start stabilizing (the first mode light and battery light will stay on).

V. Using the Gimbal

Button Function

1. Mode Indicator

Switch between five modes: PF, F, L, POV, and V. The corresponding mode is indicated by the light.

2. Mode Switch Button

Single press to switch between gimbal functions (PF, F, L, POV, V); double-click to switch from right to left.

3.Battery Indicator Light

Shows the remaining battery level:
100%-20%: Green battery indicator stays on.
20%-0%: Red battery indicator blinks.
Charging:
During charging: Red battery indicator stays on.
Fully charged: Green battery indicator stays on.

4.Shutter Button

Long press: Switch between video and photo mode.
Single press: Capture a photo or start video recording, depending on the current mode.
Double press: Switch between the front and rear cameras.

5.Joystick

Controls the gimbal's pitch and yaw movements. Double press the joystick to switch between portrait and landscape orientation.

6.Power Button

Long press (3 seconds): Power the gimbal on or off.
Single press: View the gimbal's battery level.

7.Zoom Wheel

Turn: Perform zooming or focusing actions.
Single press: Switch between zoom and focus modes.

8.1/4 Screw Hole

For connecting external devices.

9.Type-C Charging Port

9.Insert the charging cable to charge the gimbal.

10.Trigger Button

Double press: Reset the gimbal motors to their default position.
Long press: Enter the locking mode, where the corresponding mode indicator light will turn on.

11.Lanyard Hole

For attaching a lanyard for hanging.

Different Mode Usage

After powering on, the CM8 gimbal defaults to PF mode, and you can switch modes using the M button.
Double-click the joystick to switch to portrait mode.

1.PF Mode (Pan Follow)

Automatically enters PF mode after powering on. The phone' s camera follows the gimbal' s left-right movement, suitable for walking shots.

2.F Mode (Dual-Axis Follow)

In F mode, the phone' s camera follows both the left-right and up-down movements of the gimbal, ideal for capturing everyday life or object-focused footage.

3.L Mode (Lock Mode)

L mode locks the camera' s shooting angle. When you long-press the trigger button, the gimbal automatically enters this mode and will remain locked until you release it. This mode is for capturing fixed-direction shots.

4.POV Mode (All-Axis Follow)

The phone' s camera follows the gimbal' s movements, great for creative shots.

5.V Mode (Inception Mode)

The phone' s camera follows the gimbal' s movements. The joystick controls the roll of the camera, while push-pull movements create dreamlike visual effects.

Using the Phone's Built-in Camera

1.After properly mounting your phone on the gimbal, power on the gimbal.
2.Open the Bluetooth settings on your phone and search for the Bluetooth name "CM8-XXXX" (as shown in the image). Tap to pair and connect.
3.After successfully pairing in the phone's Bluetooth settings menu, you can use the gimbal's capture button to control the built-in camera, including taking photos, zooming, and switching lenses.

Note: After the first connection, the Bluetooth will automatically reconnect when the gimbal is powered on again.

Phone Brand	Operation	Function	Instruction
Huawei, Xiaomi,oppo	Long Press Shutter Button	One-Tap to ope the built-in camera	Long press the shutter button on any screen to directly open the built-in camera.
		Switch to photo/video mode	In the built-in camera interface, long press the shutter button to switch between photo and video modes.
	Single Press Shutter Button	Take a photo or start/stop recording	In the built-in camera interface, single press the shutter button to take a photo or start recording
	Rotate Zoom Wheel	Control zoom and adjust the frame	Using the Built-in Camera Interface
iPhone、Samsung、vivo	Single Press Shutter Button	Take a photo or start/stop recording	In the built-in camera interface, single press the shutter button to take a photo or start recording

Download Capture 2 APP

Please search for "Capture 2" in your phone's app store or scan the QR code with your phone to install it.

*The Capture 2 App requires iOS 11.0 or later, or Android 7.0 or later.

Capture 2 App Connection Steps:

1.Properly mount the phone on the gimbal, then press and hold the gimbal's "Power Button" for 3 seconds to power it on.
2.Turn on Bluetooth on your phone and launch the Capture 2 app. Tap search and connect to the device named "CM8."

Introduction to the main interface of the APP



1.Home

2.Camera Professional Settings: AUTO (automatic settings), M (manual settings)

3.Video Resolution Settings

4.Beauty Settings

5.Settings

***Camera Settings:**

Set flash, grid, image aspect ratio, joystick sensitivity, and adjust the joystick's speed to Slow, Medium, or Fast. Left-right reverse and up-down direction change the joystick's control direction opposite to the default.

***APP Parameters and Version Information**

(1) Panorama Image Quality: Low, Medium, High. This refers to the pixel quality when shooting panoramas. If the phone's performance is low, it's recommended to use low resolution to improve the stitching rate.
(2) Initialize Sensor: When the gimbal drifts slowly, click this button to initialize the sensor. It will function normally after restarting.
(3) Horizontal Fine-Tuning: Adjust the horizontal line in the default state after startup.
(4) Live Streaming Face Tracking: Click to enable face tracking in other live-streaming apps.
(5) Gimbal Version: Shows the current gimbal firmware version. When a "Upgrade" prompt appears in front of the version number, click to upgrade the gimbal firmware.
(6) Bluetooth Version: Shows the current Bluetooth firmware version. When a "Upgrade" prompt appears in front of the version number, click to upgrade the Bluetooth firmware.

6.Bluetooth Connection Status: Indicates whether the phone is connected to the stabilizer.

7.Stabilizer Battery Level

8.Phone Battery Level

9.Flashlight

10.Current Stabilizer Mode and Status

11. Smart Tracking

Smart tracking is divided into Face Tracking and Object Tracking.

*Face Tracking: When selected, it automatically locks onto and tracks the closest face in the frame.
*Object Tracking: When selected, manually draw a box on the screen around the object you want to track, and it will lock onto and track it.
Note: After detecting a face, a green selection box will appear. Similarly, after detecting an object, a green selection box will appear. If the tracked object is lost, the selection box will turn red. To stop tracking during the process, click the "X" icon at the top right corner of the green box.

12.Gesture Recognition

13. Shooting Modes

Swipe to select different shooting modes.

Panorama: Provides 180°, Magic Self, and 3x3 panorama modes.
*180° Panorama: Capture 5 photos to be stitched together.
*Magic Self: Follow the app's instructions to position the subject in the frame, then capture 3 photos to be stitched together.
*320° Panorama: Capture 8 photos to be stitched together.
*3x3 Panorama: Capture 9 photos to be stitched together.

Photo: Take a photo.
Video: Regular video shooting.
Slow Motion: Offers 8x slow-motion video recording.
Time-Lapse: Divided into Static Time-Lapse and Track Time-Lapse.
*For Static Time-Lapse, set the interval and duration at the top of the screen, then press the shutter button.
*For Track Time-Lapse, after setting the interval and duration, you can select up to 5 gimbal position points (controlled by the joystick). After pressing record, the gimbal will move the phone to the selected position points and take photos in sequence.

14. Shutter

15. Switch Front/Rear Camera

16. Album

VI. Firmware Update

Firmware updates can be done through the Capture 2 app. Before updating, make sure the gimbal has enough battery. Once connected to Bluetooth, ensure the app has network connectivity.
Then, in the app's shooting interface, open the settings menu on the left side, find and click "Gimbal Version" to begin the upgrade. A progress bar will show the update process, which typically takes around 3 minutes.

Note:
1. During the upgrade process, do not exit the Capture 2 app or switch to the background.
2. After a successful upgrade, the gimbal will automatically power off. To use it normally, you will need to power it on again manually.
3. If the upgrade fails, restart both the gimbal and the app, then reconnect the gimbal via Bluetooth through the app before trying the upgrade again.

VII. Product Specifications

Product Specifications

Product Weight	Standard Version: 369g AI Version: 380g
Product Dimensions	Folded: 175*103*48mm Unfolded: 275*117*60mm
Compatible Phone Weight	120g-300g
Compatible Phone Width	50-90mm
Compatible Phone Thickness	≤13mm
Mechanical Performance	Pan Axis: 335° Roll Axis: 335° Tilt Axis: 335°
Battery Model	18650 Lithium-ion Battery
Battery Capacity	2600mah/3.7v
Working Current/Voltage	200ma-3000ma/3.5-4.2V
Battery Life	10H
Charging Time	3.5H
Operating Temperature Range	-20°C-60°C

Names and Content of Hazardous Substances in the Product

Component Name	Hazardous Substances					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Cadmium (Cr+6)	Polybrominated Biphenyls (PBB)	Diphenyl ether (PBDE)
Shell	X	○	○	○	○	○
Metal Components	X	○	○	○	○	○
Circuit Board	X	○	○	○	○	○
Internal Wires	X	○	○	○	○	○
Other Accessories	X	○	○	○	○	○

This table is prepared according to SJ/T 11364.

○ indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit specified in GB/T 26572.

X indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit specified in GB/T 26572. (The product complies with the environmental requirements of the EU RoHS Directive)

VIII.Disclaimer and Safety Instructions

Disclaimer

Thank you for purchasing the "CM8" smartphone gimbal.

Before using this product, please read this document carefully as it concerns your safety and legal rights. Follow the instructions in this document for proper use and settings of the product. Failure to follow the instructions may result in harm to you, people around you, or damage to the "CM8" smartphone gimbal or surrounding products.

By using this product, you acknowledge that you have read the user manual, understood, accepted, and agreed to all terms and conditions, especially the disclaimer and safety instructions. Douying Technology will not be held responsible for any damages, injuries, or legal liabilities caused by direct or indirect misuse of the product. Users should follow all safety guidelines mentioned in the text.

This document and all related documents of the product are the roperty of FUNSNAP Douying. In case of updates, no separate notification will be given. Please visit the official website www.funsnap.cn for the latest product information.

Safety Instructions

1. The phone gimbal is not waterproof. Do not expose it to any liquids. Do not use the product in rainy or humid environments and do not immerse it in water or make it wet. Exposure to liquid may cause corrosion reactions, battery self-ignition, or even explosions.
2. In the event of a fire, extinguish it immediately to prevent severe damage.
3. Please use the product within the temperature range of -20°C to 60°C. Do not heat the product as excessive temperatures may shorten its lifespan.

4. Pay attention to the safe use of the product. Mechanical impact, crushing, or throwing heavy objects on the product is strictly prohibited.
5. It is strictly prohibited to disassemble the product in any way. Piercing the battery during disassembly may cause leakage of internal liquid, fire, or explosion.
6. When not in use for a long time, discharge the battery to a remaining capacity of 40% to 65% before storage. Do not store the product after completely discharging the battery for a long time, as it may lead to over-discharge and damage to the battery cells, making it unusable. It is recommended to recharge and discharge the battery every three months to maintain battery activity.

IX.Product Warranty Services

1. Within seven days from the date of purchase, if there is a performance failure in the product, and the product and its outer packaging remain intact without scratches, a replacement of the same model can be provided after inspection to confirm non-human damage.
2. Warranty service is limited to normal use.
3. Under normal use from the date of sale, free warranty service is provided for one year, and lifetime maintenance is provided. Accessories are not covered by the warranty.
4. Damage caused by accidents or human actions,self-disassembly, or improper use is not covered by thewarranty.
5. The warranty card must be presented during warranty service. In case of failure to provide the warranty card or any tampering or alteration of the warranty card, the company has the right to deem it void and not provide warranty service.

X.Warranty Card

User Name:
Order Number:
Purchase Platform:
Purchase Date:
Phone Number:

Repair Records

Repair Records	Date of Repair

The following cases are not covered by the warranty:

1.Malfunction or damage caused by transportation or loading and unloading after purchase of the product.
2.Any unauthorized modification, disassembly, or repair without the authorization of FUNSNAP Technology.
3.Product damage caused by accidents or subjective actions, such as liquid ingress, impact, inappropriate input voltage, excessive compression, or deformation of the motherboard.
4.Product malfunction or damage caused by failure to install, use, maintain, and store the product according to the instructions.
5.Inability to provide a legitimate and valid purchase certificate or document, or forgery or alteration of the document.
6.Labels, machine serial numbers, or waterproof and anti-tamper markings are torn off or altered, making them illegible.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction.