

Intermountain West Mesh

Region Scopes

(updated 9/12/2026 - see infographics for reference, and region structure)

Region Scopes act as routing labels (e.g., **imw** or **ut**).

Repeaters will only forward packets matching their allowed region list dropping out-of-area traffic at the boundary. This keeps local channel airtime clear and lowers the probability of congestion.

Repeaters

Add the appropriate region scopes. Check your area's infographic to see what tags to use. Deny unscoped traffic (based on your area's recommendations in the respective guide). The region tag for unscoped is *****.

CLI command is **region denyf ***

Companions

To replicate the same access to the mesh as before regions were implemented, set the **Public Channel Region Scope** to **imw**. This method applies to any public or private channel; simply set the smallest possible region a specific channel needs. **Keep local groups local!** You can also set the default scope of your companion to your local area if desired.

Let's run through an example. Let's assume we're in Ogden, UT and a Mount Ogden Repeater can see all of the below repeaters clearly.

John wants to send a message to imw scoped public channel.

Region tags in use:

- **Mount Ogden Repeater:** imw, ut, wf, n-ut,
- **Ogden Foothills Repeater:** wf, ogd
- **John's Roof Repeater:** ogd, and since he wants to use the imw scoped Public Channel, imw
- **John's Companion:** Public Channel scoped to imw

Since John's roof repeater can see Mount Ogden, and they both have the imw tag, off it goes to the public channel. Ogden Foothills is unused.

Now, John wants to talk in #ogden, an Ogden specific channel, scoped for ogd.

Mount Ogden ignores the traffic as it isn't scoped for ogd.
Ogden Foothill node delivers to the channel recipients.