

Installation and Care Instructions

Thank You for purchasing TV Armor. We are confident you will enjoy many years of Peace of Mind knowing your TV is protected. Please use the following instructions to install and care for your TV Armor. If you have any questions please don't hesitate to contact us. Tell your friends about TV

Armor! You could be saving their TV.

Step 1



Carefully open the box and remove the TV Armor. Be cautious using a knife to open the box as you may scratch the product. Save the cleaning instruction sheet that comes with the product for future reference. Remove the felt pads, and straps from the box and put them off to the side for the moment.

Step 2



membrane that covers the Armor and protects it during shipping from scratches. Remove the membrane on both sides. Do not use a tool or knife to remove the membrane as you may scratch the Armor.

Using your fingernail, gently pull back the corner of the

Step 3

TV Armor Customer Service
Email: CustomerService@tv-armor.com
Phone: 1-800-890-0073



Place the TV Armor unit on your TV. The Armor should be centered on your TV. Determine the best location in the four corners of the Armor to stick the felt pads (not over buttons or covering the picture area). The pads keep the Armor a 1/4" off your TV surface. The pads are an essential part of the Armor's protection system. Ensure that the Armor's felt spacers are pressing against the sides (Bezel) of the TV, not the picture area, as this may damage the TV. Remove the Armor and stick the felt pads to the Armor.

Step 4



Place the Armor back on your TV (centered) and feed one end of each VelcroTM strap through the top slots and hook it back onto itself. Drape the straps over the back of the TV. The top edge of the TV supports the TV Armor.

Step 5



Feed the straps from the back of the TV through the slots at the bottom of the Armor and attach the Velcro[™] to itself gently pulling the Armor tight to the TV. There is no need to use a lot of force to accomplish this. The weight of the Armor is supported by the top of the TV. Your're done!

Cleaning TV Armor:

The continued optical clarity of TV Armor depends on how you care for it. TV Armor should be cleaned with clean, lukewarm water or a good acrylic cleaner, available from our website, and a microfiber cloth. Do not use window cleaning products as they will haze the TV Armor over time.

TV Armor Customer Service
Email: CustomerService@tv-armor.com
Phone: 1-800-890-0073