

Creating Detention Ponds

Hydraflow Hydrographs Extension allows you to set up a maximum of 25 unique detention ponds for a project. Any detention pond can be used by any hydrograph at any time. Each detention pond can use up to 20 **stage** values to describe the **stage-storage** curve and can use up to four culvert-orifice outflow structures (one of which can be a perforated riser), four weir structures, and an exfiltration component. These structures can act as individual outlet structures or you can set them up in series as a multi-stage structure.

To maximize the accuracy of the routing calculations, Hydraflow Hydrographs Extension automatically computes ten intermediate **stage** values between each of the **stage** values that you enter.

To create a detention pond

1. Click the Ponds tab.

The Ponds view displays a list of 25 existing and available ponds.

2. In the pond list, double-click an empty row or on the toolbox, click  (Add/Edit Detention Pond).

3. In the **Stage / Storage / Discharge Setup** dialog box, set up a pond:

1. Click **Storage** and enter the required data for each storage type. See [Stage / Storage / Discharge Dialog Box Storage Tab](#). Click **Apply** and then click **Done**.

NOTE:

To modify the displayed values, you must edit the input parameters.

2. Click **Outlets** and enter the required data. See [Stage / Storage / Discharge Dialog Box Outlets Tab](#). Click **Compute**.
3. Click **Pond Tools** and enter the required data. See [Stage / Storage / Discharge Dialog Box Pond Tools Tab](#). Click **Estimate Storage**.
4. Click **Graphs** to view the plotted curve. See [Stage / Storage / Discharge Dialog Box Graphs Tab](#).
5. Click **Table** to view the data. See [Stage / Storage / Discharge Dialog Box Table Tab](#).