

1. Quick start

Connect the machine to a grounded power outlet.

Open the water tap before starting a program.

Load laundry evenly and do not exceed 8 kg for cotton programs.

Add detergent to compartment II for the main wash.

2. Washing programs

Cotton: temperature range 20 C to 90 C. Maximum spin speed is 1400 rpm.

Synthetics: temperature range 20 C to 60 C. Maximum load is 4 kg.

Delicate: temperature range 20 C to 40 C. Maximum load is 2 kg.

Wool: temperature range 20 C to 30 C. Maximum load is 1.5 kg.

Quick 15: temperature is fixed at 30 C. Use it only for lightly soiled clothes.

3. Safety and child lock

To turn on child lock, hold the Temp and Spin buttons together for 5 seconds.

To turn off child lock, hold the same buttons again for 5 seconds.

Do not open the door while the drum is rotating or water is visible inside.

4. Delayed start and cancellation

Delayed start can be set from 1 to 24 hours.

To cancel delayed start, hold Start/Pause for 3 seconds until the display resets.

To pause a running program, press Start/Pause once and wait until the door icon turns off.

5. Maintenance

Clean the detergent drawer once per month.

Clean the drain filter every 2 months or when error E21 appears.

Run Drum Clean at 90 C once every 40 wash cycles.

6. Error codes

E10 means water supply problem. Check the tap and inlet hose.

E21 means drain problem. Clean the drain filter and check the drain hose.

E40 means door is not closed properly. Close the door firmly and restart.

7. Warranty and service

The warranty period is 24 months from the purchase date.

The warranty does not cover damage caused by incorrect installation.
For service, contact support with the model number and serial number.