

Battery service

The battery supplies 12 kW to the drive system. Inspect the battery before every service visit.

The motor must remain stopped while the battery cable is disconnected. Never energize the motor during inspection.

Measure the voltage before closing the cover. The voltage must remain below 72 V during this check.

The current is electric current through the cable. Record the current at 15 A before the test ends.

Service the drive system every 100 km. The drive means the motor assembly in this manual.

Record the battery temperature before charging. Keep MODEL-X and <https://example.com/manual> unchanged.