

Isolated electrical return

Connect the measurement lead to ground before measuring the voltage. Disconnect the lead after the test.

Measure 12 V relative to ground. Ground is the common return reference for this isolated battery circuit.

The ground connection is attached to the chassis. It is not a protective earth connection to the soil.

Inspect the lead for damage before the motor starts. The lead is an insulated electrical cable, not the metal lead.

Keep the current below 15 A. Record the voltage and inspect the battery after the test.

Do not confuse ground with earth. The circuit remains electrically isolated during service.