

Inspection label

The seal must be replaced after every inspection. Photograph the seal before removing it.

Record inspection step 3 and the date before starting work. The motor must remain disconnected.

Attach the new seal across the cover joint. Confirm that the seal breaks if the cover is opened.

This inspection is performed every 100 km. Keep MODEL-X in the service record.

The seal is a tamper-evident adhesive security label. It is not a rubber gasket and has no fluid-sealing function.

A missing seal indicates that the cover may have been opened. Replace the seal after completing service.