levels

louder, softer, fade it in, fade it out, do it again

K3: switch between highlighted sections encoders: 1=a, 2=b, 3=c (one per bank)





overall level = pad level multiplied by the bank level
----encoders: change displayed pad's level
K1 hold + encoders: change bank's level
* useful for fading in a bank without





three envelope shapes: falling, rising, rise/fall optional cycling mode available
----encoders: adjust envelope for displayed pad
K1 hold + encoders: adjust envelope for all pads in the bank



adjust duration of specified envelope
for rise/fall, specifies total duration (vs. single stage)
----encoders: adjust envelope duration for displayed pad
K1 hold + encoders: adjust envelope duration for
all pads in the bank

changing pad levels