

# Instruction Manual

## SL SERIES

### High Voltage Power Supply

MODEL :

SERIAL# :

DATE :

**SPELLMAN  
HIGH VOLTAGE ELECTRONICS  
CORPORATION**  
475 Wireless Blvd.  
Hauppauge, New York, 11788

+1(631) 630-3000\*FAX: +1(631) 435-1620\*

E-mail: [sales@spellmanhv.com](mailto:sales@spellmanhv.com)

Website: [www.spellmanhv.com](http://www.spellmanhv.com)



Spellman's SL Series of high voltage power supplies are designed to meet uncompromising performance standards in a minimum of space. Their circuitry includes a resonant high frequency inverter with proprietary control which provides fault-free operation in extreme transient and arcing environments with greater than 85% efficiency. These full featured supplies are available in a wide range of outputs with many options.

## TYPICAL APPLICATIONS

Analytical X-ray  
CPT/CRT Testing  
Electrostatics  
E-Beam Systems

Capacitor Charging  
Hipot Testing  
General Laboratory  
CW Lasers

## OPTIONS

<b>AOL</b>	Adjustable Overload Trip
<b>FG</b>	Floating Ground (15V Standard)
<b>FGLL</b>	Low Leakage Floating Ground, 10nA
<b>LR</b>	Low Ripple, .05% p-p
<b>NSS</b>	No Slow Start
<b>SS(X)</b>	Non-Standard Slow Start (std. 6 sec.)
<b>APT</b>	Adjustable Power Trip
<b>CPC</b>	Constant Power Control
<b>SL</b>	Mounting Slides
<b>IO</b>	Instant ON
<b>PN</b>	Reversible Polarity
<b>EFR</b>	External Fault Relay
<b>ROV</b>	Remote Over Voltage Adjust
<b>CMS</b>	Current Mode Select
<b>IDR</b>	Improved Dynamic Response
<b>RLPS</b>	Remote/Local Program Select
<b>DPM4</b>	4½ Digit Digital Panel Meter
<b>AT</b>	Arc Trip
<b>BPM</b>	Bipolar Master
<b>BPS</b>	Bipolar Slave
<b>FCV</b>	Fine Control Voltage
<b>NAD</b>	No Arc Detect
<b>RFR</b>	Remote Fault Reset

- **VERY COMPACT AND LIGHTWEIGHT**
- **LOW EMI AND RFI**
- **VOLTAGE RANGE FROM 1KV TO 130KV**
- **REVERSIBLE POLARITY STANDARD UP TO 6KV**
- **SYSTEM STATUS INDICATORS**
- **EXTENSIVE ANALOG AND DIGITAL INTERFACE**
- **ARC QUENCH/ARC COUNT/ARC TRIP**
- **OEM CUSTOMIZATION AVAILABLE**

## SPECIFICATIONS

### Status Indicators:

Voltage and Current Control Mode, Interlock Open and Closed, High Voltage Inhibit, Overcurrent and Overvoltage, Arc, Regulation Error, Overtemperature, Over Power (Optional).

### Input:

115Vac or 220Vac±10%, 50/60Hz. Specify with order.  
1200W model available in 200/220Vac only.

### Output:

Models available from 1kV to 130kV. Each model is available in positive, negative or reversible polarity output.

### Front Panel Controls:

Voltage and current are continuously adjustable by ten-turn potentiometers with lockable counting dials, ON/OFF circuit breaker/lamp, high voltage ON switch/indicator and high voltage OFF switch/indicator.

### Voltage Regulation:

Load: 0.005% of maximum voltage for full load change.  
Line: ±0.005% of maximum voltage for a ±10% input line change.

### Current Regulation:

Load: 0.01% of maximum current ±100µA for full voltage change.  
Line: ±0.005% of maximum current for a ±10% input line change.

### Ripple:

0.1% p-p of maximum output.

### Temperature Coefficient:

100ppm/°C voltage or current regulated. Higher stability is available on special order.

### Ambient Temperature:

Operating: 0°C to 50°C.  
Storage: -40°C to 85°C.

### Stability:

100ppm/hour after 1/2 hour warm-up for both voltage and current regulation.

### Metering:

Digital voltage and current meters, 3½ digit ±1 least significant digit.

### Output Cable:

10' (3.3m) of shielded high voltage cable removable at the rear panel.

### AC Line Input Cable:

10 to 300W: IEC320 Cord Set, 6' (1.83m)  
600 to 1200W: 3-conductor, 12AWG, 6' (1.83m) cable permanently attached to unit.

### Dimensions:

10W – 300W: 1¾"H(1U) x 19"W x 19"D\*\*  
(4.45cm x 48.3cm x 48.3cm).

600W – 1200W: 3½"H(2U) x 19"W x 19"D\*\*  
(8.9cm x 48.3cm x 48.3cm).

\*\*Depth becomes 24" (60.7cm) for 80 to 130kV ranges.

### Weight:

17 to 30lbs (7.7 to 14kg) depending on model.

## SL SELECTION TABLE- 10W, 30W, 60W 1.75" (1U)

kV	10 Watt mA	Model	30 Watt mA	Model	60 Watt mA	Model
1	10	SL1PN10	30	SL1PN30	60	SL1PN60
2	5	SL2PN10	15	SL2PN30	30	SL2PN60
3	3.3	SL3PN10	10	SL3PN30	20	SL3PN60
6	1.7	SL6PN10	5	SL6PN30	10	SL6PN60
8	1.25	SL8PN10	3.75	SL8PN30	7.5	SL8PN60
10	1.0	SL10*10	3	SL10*30	6	SL10*60
15	0.67	SL15*10	2	SL15*30	4	SL15*60
20	0.50	SL20*10	1.5	SL20*30	3	SL20*60
30	0.33	SL30*10	1.0	SL30*30	2	SL30*60
40	0.25	SL40*10	0.75	SL40*30	1.5	SL40*60
50	0.20	SL50*10	0.60	SL50*30	1.2	SL50*60
60	0.17	SL60*10	0.50	SL60*30	1.0	SL60*60
70	0.14	SL70*10	0.43	SL70*30	0.85	SL70*60
80	0.13	SL80*10	0.38	SL80*30	0.75	SL80*60
100	0.10	SL100*10	0.30	SL100*30	0.60	SL100*60
120	0.10	SL120*10	0.25	SL120*30	0.50	SL120*60
130	0.10	SL130*10	0.25	SL130*30	0.46	SL130*60

\*Specify "P" for positive, "N" for negative, or "PN" for reversible polarity.  
Higher voltage models available on special order.

## SL SELECTION TABLE- 150W, 300W 1.75" (1U)

150 Watt			300 Watt		
kV	mA	Model	mA	Model	
1	150	SL1PN150	300	SL1PN300	
2	75	SL2PN150	150	SL2PN300	
3	50	SL3PN150	100	SL3PN300	
6	25	SL6PN150	50	SL6PN300	
8	18.75	SL8PN150	37.5	SL8PN300	
10	15	SL10*150	30	SL10*300	
15	10	SL15*150	20	SL15*300	
20	7.5	SL20*150	15	SL20*300	
30	5.0	SL30*150	10	SL30*300	
40	3.75	SL40*150	7.5	SL40*300	
50	3.00	SL50*150	6.0	SL50*300	
60	2.50	SL60*150	5.0	SL60*300	
70	2.1	SL70*150	4.28	SL70*300	
80	1.90	SL80*150	3.75	SL80*300	
100	1.50	SL100*150	3.00	SL100*300	
120	1.25	SL120*150	2.50	SL120*300	
130	1.15	SL130*150	2.30	SL130*300	

## SL SELECTION TABLE- 600W, 1200W 3.50" (2U)

600 Watt			1200 Watt		
kV	mA	Model	mA	Model	
1	600	SL1PN600	1200	SL1PN1200	
2	300	SL2PN600	600	SL2PN1200	
3	200	SL3PN600	400	SL3PN1200	
6	100	SL6PN600	200	SL6PN1200	
8	75	SL8PN600	150	SL8PN1200	
10	60	SL10*600	120	SL10*1200	
15	40	SL15*600	80	SL15*1200	
20	30	SL20*600	60	SL20*1200	
30	20	SL30*600	40	SL30*1200	
40	15	SL40*600	30	SL40*1200	
50	12	SL50*600	24	SL50*1200	
60	10	SL60*600	20	SL60*1200	
70	8.6	SL70*600	17	SL70*1200	
80	7.5	SL80*600	15	SL80*1200	
100	6.0	SL100*600	12	SL100*1200	
120	5.0	SL120*600	10	SL120*1200	
130	4.6	SL130*600	9.2	SL130*1200	

\*Specify "P" for positive,  
"N" for negative, or "PN"  
for reversible polarity.  
Higher voltage models  
available on special order.

## SL TERMINAL BLOCK 26 PIN

TB1	SIGNAL	SIGNAL PARAMETERS
1	Power Supply Common	Signal Ground
2	External Inhibit	Ground=Inhibit, Open=HV On
3	External Interlock	+15V at Open, <15mA at Closed
4	External Interlock Return	Return for Interlock
5	Current Monitor	0 to 10V=0 to 100% Rated Output
6	kV Test Point	0 to 10V=0 to 100% Rated Output
7	+10V Reference	+10.24V, 1mA Max
8	Remote Current Program In	0 to 10V=0 to 100% Rated Output
9	Local Current Program Out	Front Panel Program Voltage
10	Remote Voltage Program In	0 to 10V=0 to 100% Rated Output
11	Local Voltage Program Out	Front Panel Program Voltage
12	Power Monitor	0 to 10V=0 to 100% Rated Output
13	Remote Power Program In	(Optional)
14	Local HV Off Out	+15V at Open, <25mA at Closed
15	HV Off	Comment to HV OFF for FP Operation
16	Remote HV On	+15V, 10mA Max=HV Off
17	Remote HV Off Indicator	0=HV On, +15V, 10mA Max=HV Off
18	Remote HV On Indicator	0=HV Off, +15V, 10mA Max=HV On
19	Remote Voltage Mode	
20	Remote Current Mode	Open Collector 50V Max, 10mA Max
21	Remote Power Mode	On=Active
22	Remote PS Fault	0=Fault, +15V, 0.1mA Max=No Fault
23	+15V Output	+15V, 100mA Max
24	Power Supply Common	Signal Ground
25	Spare	Spare
26	Shield Return	Chassis Ground



A1693

ISO 9001




89/336/EEC


73/23/EEC

DIMENSIONS: in.[mm]


## 10W-300W




## 600W-1200W



## BACK VIEW



26 PIN TERMINAL BLOCK FOR  
REMOTE  
CONTROL  
MONITORING



6 ft OF LINE CABLE  
SUPPLIED WITH UNIT  
2 PIN TERMINAL BLOCK LOAD  
RETURN (CHASSIS GROUND)  
MATING CONNECTOR  
AND 10ft. OF  
HIGH VOLTAGE  
CABLE SUPPLIED

\* Depth becomes 24" [609.60] for 80kV to 130kV range.



A1693

ISO 9001



RvA

89/336/EEC  
73/23/EEC

## IMPORTANT SAFETY PRECAUTIONS

### SAFETY

THIS POWER SUPPLY GENERATES VOLTAGES THAT ARE DANGEROUS AND MAY BE FATAL.  
OBSERVE EXTREME CAUTION WHEN WORKING WITH THIS EQUIPMENT.

High voltage power supplies must always be grounded.

Do not touch connections unless the equipment is off and the  
Capacitance of both the load and power supply is discharged.

Allow five minutes for discharge of internal capacitance of the power supply.

Do not ground yourself or work under wet or damp conditions.

### SERVICING SAFETY

Maintenance may require removing the instrument cover with the power on.

Servicing should be done by qualified personnel aware of the electrical hazards.

**WARNING** note in the text call attention to hazards in operation of these units that  
could lead to possible injury or death.

**CAUTION** notes in the text indicate procedures to be followed to avoid possible  
damage to equipment.

Copyright © 2000, Spellman High Voltage Electronics Corporation. All Rights Reserved.

This information contained in this publication is derived in part from proprietary and patent data. This information has been prepared for the express purpose of assisting operating and maintenance personnel in the efficient use of the model described herein, and publication of this information does not convey any right to reproduce it or to use it for any purpose other than in connection with installation, operation, and maintenance of the equipment described.

# Table of Contents

	PAGE
<b>1. INTRODUCTION</b>	
1.1    Description Of The SL Series .....	1
1.2    SL Series Specifications.....	1
1.3    Standard Features.....	2
1.3.1    Remote Operating Features.....	2
1.3.2    System Status and Fault Diagnostic Display .....	2
1.4    Options .....	3
1.5    Interpreting The Model Number .....	4
<b>2. INSPECTION &amp; INSTALLATION</b>	
2.1    Initial Inspection .....	5
2.2    Mechanical Installation .....	5
<b>3. OPERATING INSTRUCTIONS</b>	
3.1    Operation.....	7
3.2    Standard Features.....	8
<b>4. PRINCIPLES OF OPERATION</b>	
4.1    Chassis .....	18
4.2    Line Rectification And Filtering .....	18
4.3    Inverter .....	19
4.4    High Voltage Transformer .....	20
4.5    High Voltage Assembly .....	20
4.6    Control/Power PWB .....	20
4.7    Front Panel Assembly .....	20
4.8    Options .....	20
<b>5. OPTIONS</b>	
5.1    Adjustable Overload Trip .....	21
5.2    220Vac Single Phase Input .....	21
5.3    Universal Input .....	21
5.4    No Slow Start.....	21
5.5    Non-Standard Slow Start .....	21
5.6    Extra Length Output Cable .....	21

5.7	Floating Ground .....	21
5.8	Floating Ground Low Leakage .....	22
5.9	Adjustable Power Trip/Constant Power Control .....	22
5.10	Arc Trip Option.....	22
5.11	Reversible Polarity Option.....	22
5.11.1	Models from 1 kV to 8kV .....	22
5.11.2	Models From 10kV to 130kV .....	22
5.12	Instant On.....	22
5.13	Bipolar Master/Slave Option .....	23
5.14	External Fault Relay Option .....	23
5.15	Custom Design Models.....	23
<b>6. MAINTENANCE</b>		
6.1	Periodic Servicing.....	28
6.2	Performance Test .....	28
6.3	High Voltage Dividers .....	28
<b>7. REPLACEMENT PARTS</b>		
7.1	Replacement Parts.....	29
7.2	Correspondence and Ordering Spare Parts .....	29
<b>8. FACTORY SERVICE</b>		
8.1	Warranty Repairs .....	30
8.2	Factory Service Procedures.....	30
8.3	Ordering Options and Modifications .....	30
8.4	Shipping Instructions .....	30

## LIST OF FIGURES

Figure 2.1	SL Series Dimensions .....	6
Figure 3.1	SL Series Typical Operating Set Up .....	10
Figure 3.2A	Wiring Diagram For Remote Programming Via Voltage Source .....	13
Figure 3.2B	Wiring Diagram For Remote Programming Via External Resistance .....	13
Figure 3.3	Remote Monitor Test Point Designations.....	14
Figure 3.4	Remote Control Of High Voltage On and Off .....	14
Figure 3.5	External Inhibit Interface Circuit .....	15
Figure 3.6	External Interlock Interface Circuit .....	15
Figure 3.7	Remote High Voltage On and Remote High Voltage Off Indicator Circuit...	16
Figure 3.8	Remote Indicators Interface .....	17
Figure 5.1	Floating Ground Interface Circuit .....	24
Figure 5.2	Adjustable Power Remote Interface TB1 Only.....	24
Figure 5.3	Polarity Reversal Procedure 1kV to 8kV (10W to 300W) .....	25
Figure 5.4	Polarity Reversal Procedures, 10kV to 130kV (10W to 300W) .....	25
Figure 5.5	Polarity Reversal Procedures, 1kV to 8kV (600W to 1200W) .....	26
Figure 5.6	Polarity Reversal Procedures 10kV to 130kV (600W to 1200W) .....	26
Figure 5.7	Instant On Option .....	27
Figure 5.8	Bipolar Master/Slave Option .....	27

## **LIST OF TABLES**

Table 1.1	SL Options .....	3
Table 3.1	Rear Panel Interface 26 pin Terminal Block.....	11
Table 3.2	Rear Panel Interface 25 pin Mini D .....	12
Table 4.1	List of Main Assemblies .....	19

## **APPENDIX**

- A. Specification Controls (Custom Models Only)
- B. Schematics

# Chapter 1

## INTRODUCTION

### 1.1 Description Of The SL Series

The SL Series of high voltage power supplies provides very well regulated, low ripple high voltage in a highly efficient, compact design. The improvements in size and performance over traditionally designed high voltage power supplies are due to the resonant topology and unique control circuitry of the SL design. A proprietary control system maintains high frequency over the operating output range. High frequency operation allows a dynamic response time of less than 5 milliseconds, and one of the lowest ripple specifications in the industry at this power level. The combination of proprietary control system and proprietary protection circuitry enables the supplies to operate under arcing and extreme transient conditions without damage or interruptions.

The DC output voltage and current are continuously adjustable from zero to the maximum rating via two front panel ten-turn locking potentiometers. These high voltage power supplies have 0.005% load regulation, 0.005% line regulation, and 0.1% p-p ripple.

The supplies operate from either a 115 or 220 Volt, single phase AC line. Other line voltages are available. Options are listed in Table 1.1 and are described in Section 5. Custom designed units to meet special needs are also available.

A three year warranty applies to standard SL units. Consult factory about the warranty for custom SL units.

### 1.2 SL Specifications

- Output Control:** Voltage and current are continuously adjustable over the entire range from zero to maximum rating via a ten-turn potentiometer with a lockable counting dial.

- Input Voltage:** 115 Vac $\pm$ 10%, 50-60Hz, single phase or 220 Vac $\pm$ 10%, 50-60Hz, single phase. Other line voltages and universal input (85V-265V) are also available. Specify the input voltage at the time of the order.
- Voltage Regulation:**  
**Load Regulation:** 0.005% of full voltage for a no load to full load change.  
**Line Regulation:**  $\pm$ 0.005% of full voltage over the specified input voltage range.
- Current Regulation:**  
**Load Regulation:** 0.05% of full current  $\pm$ 100 $\mu$ A for any voltage change.  
**Line Regulation:**  $\pm$ 0.05% of full current over the specified input voltage range.
- Ripple:** 0.1% p-p of rated output voltage.
- Polarity:** Positive, Negative and Reversible polarity with respect to ground are available.
- Stability:** 0.01% per hour after 1/2 hour warm up. 0.02% per 8 hrs (typical).
- Temperature Coefficient:** 100 ppm per °C. Higher stability (50 ppm per °C) available on special order.
- Ambient Temperature:** -20°C to +40°C operating; -40°C to +85°C storage.
- Metering:** Digital voltage and current meters are accurate to 1%.
- Weight:** 17 to 30 lbs (7.7 to 14kg) depending on the model.

- **Physical Dimensions:**

#### **10W-300W**

1 to 70kV: 1 3/4" H x 19" W x 19" D rack mount.  
(44.5 x 483 x 483mm).

80 to 130kV: 1 3/4" H x 19" W x 24" D rack mount.  
(44.5 x 483 x 610mm).

#### **600W-1200W**

1 to 70kV: 3 1/2" H x 19" W x 19" D rack mount  
(89 x 483 x 483mm).

80 to 130 kV: 3 1/2" H x 19" W x 24" D rack mount.  
(89 x 483 x 610mm).

## **1.3 Standard Features**

The SL Series incorporates several standard features designed to optimize user satisfaction and safety.

- **SLOW START:** This feature provides a gradual increase in high voltage until the preset operating point is reached. The slow start time is factory set for 6 seconds. Other slow start times are available as an option.
- **ARC DETECT / ARC QUENCH / ARC COUNT:** These features allow the user to tailor the power supply to meet specific needs in dynamic load applications. If an arc occurs, the output is inhibited for approximately one second, then the output is ramped up to the preset level with the slow-start circuitry. See Chapter 3 for operating details and information for user customization of these features.
- **INTERNAL FAULT PROTECTION:** The SL Series continually monitors internal circuits critical to the proper operation of the power supply. In the event that one of these circuits does not function correctly, the fault detection circuit latches the appropriate fault on the front panel display and turns off the output and reverts the unit to the POWER DOWN mode.
- **INDICATOR LAMPS:** LINE POWER, HIGH VOLTAGE OFF AND HIGH VOLTAGE ON indicators.
- **OUTPUT CABLE:** All models are provided with a ten foot shielded high voltage output cable. The cables are designed with a plug arrangement so that they can be easily removed from the mating receptacle located on the rear of the chassis.

### **1.3.1 Remote Operating Features**

- **REMOTE PROGRAMMING:** Allows remote adjustment of the output voltage and current via an external voltage source. The output power is also remotely controllable when the CPC or APT option is ordered, TB1 only.
- **REMOTE MONITOR:** Allows remote monitoring of the output voltage and current.

**NOTE:** Output power remote monitor is included with the CPC and APT options, TB1 only.

- **REMOTE HIGH VOLTAGE CONTROL:** Allows remote control of HIGH VOLTAGE ON and HIGH VOLTAGE OFF. Signals are also provided for remote indication of HV ON or HV OFF status.
- **EXTERNAL INHIBIT:** A control signal that will inhibit the high voltage output is provided on the external interface. A logic low, ground, will inhibit the high voltage output and a logic high, open, will restore the high voltage output to the preset level.

**NOTE:** The External Inhibit circuit should NOT be used for protection against injury or for safety interlock. See External Interlock for this type of safety control.

- **EXTERNAL INTERLOCK:** Interlock connections are provided on the external interface on the rear of the chassis for connection to a safety switch. The unit will not operate unless the interlock circuit is closed. During high voltage operation, opening the interlock circuit will cause the High Voltage to shut off. This circuit should be used for safety interlock circuits.

### **1.3.2 System Status and Fault Diagnostic Display**

“Dead Front” type indicators are provided to give the user complete indication of system operation and fault conditions. If a fault occurs, the power supply will revert to the POWER DOWN mode. This is indicated by both the HV ON and HV OFF lamps turning off. To reset, depress the HV OFF switch.

- **VOLTAGE (CONTROL):** Indicates the output voltage regulator circuit is maintaining voltage regulation.
- **CURRENT (CONTROL):** Indicates the output current regulator circuit is maintaining current regulation.

- **POWER (CONTROL):** Indicates the output power regulator circuit is maintaining power regulation (optional).
- **HV INHIBIT:** Indicates that the high voltage supply is being inhibited by either the EXTERNAL INHIBIT or internal protection circuitry.
- **INTLK CLSD:** Indicates the EXTERNAL INTERLOCK connections are in the closed position. This also indicates closure of internal power supply interlocks.
- **INTKL OPEN:** Indicates the EXTERNAL INTERLOCK connections are in the open position. This also indicates opening of internal power supply interlocks.
- **OVERVOLT:** Indicates the overvoltage protection circuitry has caused the power supply to turn off. Overvoltage protection is internally set to 110% of the rated output voltage.
- **OVERRCURR:** Indicates the output current has exceeded the programmed current trip level when the AOL (Adjustable Overload Trip) or the OL (Overload Trip) options are installed.
- **OVERPOWER:** Indicates the output power has exceeded the internally set level or the remote programmed level if the optional circuitry is installed.
- **ARC:** Indicates that an arc has occurred within the previous one second or that the ARC COUNT/TRIP has shutdown the power supply.
- **RGLT ERR:** Indicates a failure in the voltage, current or power regulation circuitry. This fault usually occurs when there is a lack of output power to maintain regulation.

The options available are listed in Table 1.1. See Section 5 for more information on these options along with operating and set-up instructions. With few exceptions, these options and modifications can be retrofitted to your power supply at the factory in a short time. For price and retrofit arrangements, contact the Spellman Sales Department.

AOL	Adjustable Overload Trip (0-103%)
OL	Overload Trip (103%)
APT	Adjustable Power Trip
AT	Arc Trip
FG	Floating Ground
FGLL	Floating Ground, Low Leakage (10mA)
CPC	Constant Power Control
SS(x)	Non-Standard Slow Start
NSS	No Slow Start
IO	Instant ON
LR	Low Ripple (0.05% p-p)
( )	Specify 220V or 100V or 200Vac Single Phase Input With Order.
UFPI	Unity Power Factor Input (Universal Input)
DPM4	4 1/2 Digit $\pm$ 1 Least Significant Digit Panel Mtr
PN	Reversible Polarity
FPS	Filament Power Supply
LL (x)	Extra Length Output Cable in Feet
MS	Bipolar Master/Slave
C	3 1/2" High (2U) Cabinet For Multiple Units
SL	Slides
EFR	External Fault Relay
BFP	Blank Front Panel

Table 1.1 SL Options


## 1.4 Options

## 1.5 Interpreting the Model Number

The model number of the power supply describes its capabilities. After the series name is:

1. the maximum voltage (in KV).
2. the polarity of the unit: positive (P), negative (N) or reversible (PN).
3. the maximum output (in watts).
4. the option codes for all options that are included.

Custom units have an X number after the option codes.



# Chapter 2

## INSPECTION & INSTALLATION

Initial inspection and preliminary checkout procedures are recommended. For safe operation, please follow the step-by-step procedures described in Chapter 3, Operating Systems.

### 2.1 Initial Inspection


Inspect the package exterior for evidence of damage due to handling in transit. Notify the carrier and Spellman immediately if damage is evident. Do not destroy or remove any of the packing material used in a damaged shipment.

After unpacking, inspect the panel and chassis for visible damage.



Fill out and mail the Warranty Registration card accompanying the unit. Standard Spellman SL Series high voltage power supplies and components are covered by warranty. Custom and special order models (with an X suffix and the model number) are also covered by warranty.

### 2.2 Mechanical Installation


Units in the SL Series have front panel holes for standard EIA rack mounting. The rack must allow rear access for cable connections. Units are fully enclosed and are suitable for bench or table top operation. Standard unit dimensions are shown in Figure 2.1. It is strongly recommended to support the chassis by guides or slides. Slides are available for ease of servicing (SL option).



**10-300W**




**600-1200W**



SIDE VIEW OF  
10-300W

OUTPUT VOLTAGE "KV"	"L"
1 TO 70	19.00
80 TO 130	24.00



SIDE VIEW OF  
600-1200W

**Figure 2.1 - SL Dimension**

# Chapter 3

## OPERATING INSTRUCTIONS

### 3.1 Operation

#### WARNING

**THIS EQUIPMENT GENERATES DANGEROUS VOLTAGES THAT MAY BE FATAL.**

**PROPER GROUNDING OF ALL HIGH VOLTAGE EQUIPMENT IS ESSENTIAL.**

#### WARNING

**BEFORE CONNECTING THE POWER SUPPLY TO THE AC LINE, FOLLOW THIS STEP BY STEP PROCEDURE.**

**DO NOT CONNECT THE POWER SUPPLY TO THE AC LINE UNTIL STEP H IS REACHED.**

Failure to follow these procedures may void the warranty.

- A) Insure that the Circuit Breaker is in the OFF position (0).
- B) Check the input voltage rating on the nameplate of the supply and make certain that this is the rating of the available power source. Spellman SL Series units operate on 115Vac (220Vac if 220Vac option is ordered), single phase unless ordered with a different input voltage.
- C) **PROPER GROUNDING TECHNIQUES:** The chassis of high voltage power supplies must be grounded, preferably to a water system ground using copper pipe or other earth ground using the ground stud B1 at the rear of the unit. See Figure 3.1 for a typical operating set-up.

The return line from the load should be connected to the ground pin terminal block TB2-1, on the rear of the power supply. Using a separate external ground at the load is not recommended.

10W-300W units are provided with IEC type line cable. 600W-1200W units are provided with a three conductor line cord.

- D) Attach the output cable to the load.
- E) Plug the high-voltage output cable provided with the unit into the rear of the supply and hand tighten the knurled collar.
- F) **OPTIONS NOTE:** See Section 5 for hook-up and operating instructions for the options on your unit. Custom models may also require set-up changes.
- G) For initial turn-on, rotate the KILOVOLT control fully counter-clockwise to the zero voltage position.
- H) The input power cable may now be connected to the AC power line.
- I) Switch the front panel circuit breaker to the ON position (1). (If the supply is to be turned off for an extensive period of time, the line cord should be disconnected). The light inside the circuit breaker should light up. The unit is now in the HIGH VOLTAGE OFF mode. The HIGH VOLTAGE OFF light should be lit.

## CAUTION

- J) Depress and hold the HIGH VOLTAGE OFF switch. The front panel meters will now read the preset value of the KILOVOLT control dial and the MILLIAMPERES control dial. To preset the desired level of current and voltage during operation, hold in the HIGH VOLTAGE OFF switch and rotate the appropriate control dial while noting its corresponding meter reading. Release the HIGH VOLTAGE OFF switch.

**NOTE:** no actual output is being produced at this stage.

- K) Depress the HIGH VOLTAGE ON switch. The light inside the switch should light up and the output will slow start to the preset level output voltage and/or output current.

**NOTE:** The SL Series is equipped with a slow start circuit that ramps the output up to its maximum setting in approximately 6 seconds after the HIGH VOLTAGE ON switch is depressed.

- L) To terminate the generation of output power, depress the HIGH VOLTAGE OFF switch. In the HIGH VOLTAGE OFF mode the power supply's fault and interface circuits are still active.
- M) To turn off the power supply, turn the circuit breaker to the off position (0).

**NOTE:** If a power supply fault, or system monitoring fault occurs, the power supply will revert to the POWER DOWN mode. In this mode the output power will be turned off. The HV OFF lamp will be off. To reset, depress the HV OFF switch.

## WARNING

**AFTER TURNOFF, DO NOT HANDLE THE LOAD  
UNTIL THE CAPACITANCE HAS BEEN  
DISCHARGED!**

**LOAD CAPACITANCE MAY BE DISCHARGED BY  
SHORTING TO GROUND.**

## WARNING

**THE VOLTMETER ON THE POWER SUPPLY  
FRONT PANEL DOES NOT READ THE OUTPUT  
VOLTAGE WHEN THE POWER IS TURNED OFF,  
EVEN IF A CHARGE STILL  
EXISTS ON THE LOAD.**

## ALWAYS OPERATE THE UNIT WITH THE COVER ON.

A fan maintains safe operating temperature in 600W-1200W power supplies by drawing air over the circuit components. The cover must be on in order to direct the air flow over the areas that need cooling. In operation, the unit must be placed so that the air intake and the fan exhaust are clear of obstructions that might impede the flow of air. The 10W-300W units do not use forced air cooling. Simply maintain ambient temperature specifications.

## 3.2 Standard Features

A note on remote interface circuitry and remote signal grounding. Whenever possible, electrical isolation should be provided when interfacing with any high voltage power supply. For power control signals such as EXTERNAL INTERLOCK, HIGH VOLTAGE OFF, AND HIGH VOLTAGE ON, isolated relay contacts should be used. For status signals and control signals such as HIGH VOLTAGE ON, HIGH VOLTAGE OFF, and EXTERNAL INHIBIT, etc., opto-isolation should be used. If possible, analog programming and monitoring signals should be isolated via analog isolation amplifiers. Spellman application engineers are available to assist in interface circuitry design. All interface cables should be properly shielded. All power supply signals should be referenced to the power supplies signal ground on the rear external interface.

- **REMOTE PROGRAMMING:** Allows remote adjustment of the output voltage and current via an external voltage source. (Output power is also remotely controllable with the CPC and APT options). In local control (front panel control), jumpers are installed on the external interface TB1 (or J5) in the rear of the chassis between TB-10 (J5-10) and TB1-11 (J5-11) for voltage control and between TB1-8 (J5-8) and TB1-9 (J5-9) for current control.

For remote programming, the jumpers are removed and a positive voltage source, from 0V to 10V, is applied to the appropriate terminals. Programming signals should be referenced to TB1-1 (J5-1), signal ground. By adjusting the voltage source from 0V (zero output) to 10V (full rated output), the desired output can be selected. See Figure 3.2A on page 13 for the wiring diagram and specifications.

An alternate method of controlling the output remotely is by using external resistance, such as a potentiometer or a resistor network. For remote control the jumpers are removed and the desired register configuration installed. See Figure 3.2B on page 13 for the wiring diagram.

- **REMOTE MONITOR:** Test points are made available at the terminal block on the rear of the chassis for monitoring the voltage and current output. (Output power monitor is included with the CPC and APT option). The test points are always positive regardless of the output polarity where 0V to 10V equals 0 to 100% of the output  $\pm 0.5\%$ . Test points have an output impedance of 5K ohms. See Figure 3.3 on page 14 for the test point designation.
- **REMOTE CONTROL:** Remote control of the HIGH VOLTAGE ON and HIGH VOLTAGE OFF can be accomplished via the rear panel interface. HIGH VOLTAGE OFF and HIGH VOLTAGE ON can be controlled by momentary normally closed and normally open contacts respectively. See Figure 3.4 on page 14 for the recommended interface.
- **EXTERNAL INHIBIT:** Allows the user to inhibit the power supply output without switching HIGH VOLTAGE OFF control. This circuit can be used to generate fast slewing output waveforms or control of high voltage generation as in Laser and Capacitor discharge applications. The maximum inhibit rate should not exceed 5Hz. Consult the factory for higher repetition rates or high pulse load applications. See Figure 3.5 on 15 for the recommended interface circuit.

### WARNING

**IT IS EXTREMELY DANGEROUS TO USE THIS INHIBIT CIRCUIT TO INHIBIT HIGH VOLTAGE GENERATION FOR THE PURPOSE OF SERVICING OR APPROACHING ANY AREA OR LOAD CONSIDERED UNSAFE DURING NORMAL USE.**

- **EXTERNAL INTERLOCK:** Interlock connections are provided on the terminal block TB1-3 (J5-3) and TB1-4 (J5-4) on the rear of the chassis for connection to a safety switch. The unit will not operate unless the interlock circuit is closed. If the interlock is not being used, the jumper installed on

the terminals before shipping must be in place. If the jumper is missing, or there is an opening between the interlock terminals, the unit's high voltage inverter will be disabled. During high voltage operation, revert to the HIGH VOLTAGE OFF mode.

Subsequent closing of the interlock circuit will NOT return the unit to the HIGH VOLTAGE ON mode. This must be accomplished by depressing the HIGH VOLTAGE ON switch. See Figure 3.6 on page 15 for the recommended interface circuit


- **ARC DETECT / ARC QUENCH / ARC COUNT:** The ARC DETECT circuit senses dynamic arcing or discharge conditions present at the output load. If an arc occurs, the output is inhibited for one second. After the one second period, the output is ramped up to the previous set level. This ramp is based on the standard six second slow start feature. The ARC DETECT ramp circuit may be disabled by removing CR32 on the Control/Power Pwb. Caution should be observed if this feature is disabled. Discharge rates of greater than 1Hz may cause excessive power dissipation in the power supply's output limiting resistors.

The ARC COUNT feature will allow the user to program the ARC fault parameters. The ARC indicator on the front panel will illuminate for approximately one second after each arc has occurred. The power supply can be programmed to trip the POWER DOWN mode if an arc occurs.

The standard feature is programmed to trip the power supply if 8 arcs occur within a twenty second period. Details for programming the ARC COUNT feature are provided on the Control/Power Board schematic, sheet 3 of 5, at the end of this manual.

- **REMOTE HIGH VOLTAGE ON & REMOTE HIGH VOLTAGE OFF:** Signals are provided for remote monitoring of the HIGH VOLTAGE ON/OFF status. See Figure 3.7 on page 16 for recommended interface.
- **REMOTE MODE INDICATORS:** Signals are provided for remote indication of the control mode status, voltage control, current control, and power control. See Figure 3.8 on page 17 for the recommended interface.

It is recommended to connect the load return directly to Pin 1 of TB2 terminal block located on the rear of the high voltage power supply.



**Figure 3.1 -- Typical Operating Setup**

**NOTE:**

**On standard units, TB2-1,-2 are connected to chassis ground internally.**

<b>TB1</b>	<b>SIGNAL</b>	<b>SIGNAL PARAMETERS</b>
	1	Power Supply Common
	2	External Inhibit
	3	External Interlock
	4	External Interlock Return
	5	Current Monitor
	6	kV Test Point
	7	+10V Reference
	8	Remote Current Program In
	9	Local Current Program Out
	10	Remote Voltage Program In
	11	Local Voltage Program Out
	12	Power Monitor (TB1 only)
		0 to 10V = 0 to 100% Rated Power (Optional)
	13	Remote Power Program In (TB1 only)
	14	Local HV OFF Out
		+15V at Open, < 25mA at Closed. Connect to HV OFF For FP Operation
	15	HV OFF
	16	Remote HV ON
	17	Remote HV OFF Indicator
	18	Remote HV ON Indicator
	19	Remote Voltage Mode
	20	Remote Current Mode
	21	Remote Power Mode
	22	Remote PS Fault
	23	+15V Output
	24	Power Supply Common
	25	Spare
	26	Shield Return
		Chassis Ground

**Table 3.1 - Rear Panel Interface 26 pin TB1**


<b>J5</b>	<b>SIGNAL</b>	<b>SIGNAL PARAMETERS</b>
	1	Power Supply Common
	2	External Inhibit
	3	External Interlock
	4	External Interlock Return
	5	Current Monitor
	6	kV Test Point
	7	+10V Reference
	8	Remote Current Program In
	9	Local Current Program Out
	10	Remote Voltage Program In
	11	Local Voltage Program Out
	12	EFR (Common)
		Optional External Fault Relay
	13	EFR (Normally Open)
	14	Local HV Off Out
		+15V at Open, < 25mA at Closed. Connect to HV OFF For FP Operation
	15	HV OFF
	16	Remote HV ON
	17	Remote HV OFF Indicator
	18	Remote HV ON Indicator
	19	Remote Voltage Mode
	20	Remote Current Mode
	21	Remote Power Mode
	22	Remote PS Fault
	23	+15V Output
	24	Power Supply Common
	25	Shield Return
		Chassis Ground

**Table 3.2 - Rear Panel Interface 25 pin Mini D**

Voltage Source 0-10V = 0-100% of Rated Output

It is recommended that analog signals be isolated via isolation amplifiers.


All cables should be shielded with the shields being returned to the chassis ground of the High Voltage Power Supply.



**Figure 3.2A -- Wiring Diagram For Remote Programming Via Voltage**


Fully Counterclockwise = Zero Output  
Fully Clockwise = 100% of Rated Output

All cables should be shielded with the shields being returned to the chassis ground of the High Voltage Power Supply.  
If connections to external potentiometers are excessively long (>10ft), motorized potentiometers are recommended.



**Figure 3.2B -- Wiring Diagram For Remote Programming Via External**


It is recommended that analog signals be isolated via isolation amplifiers. All cables should be shielded with the shield being returned to the chassis ground of the high voltage power supply.



**Figure 3.3 -- Remote Monitor Test Point Designations**

S1 must be closed to enable HIGH VOLTAGE. Momentary closure of S2 will enable HIGH VOLTAGE ON. Opening S1 will disable HIGH VOLTAGE ON and switch the unit to the HIGH VOLTAGE OFF mode.


It is recommended to use relay contacts for S1 and S2. Relays should be located as close as possible to the high voltage power supply. Coils should be driven from isolated sources. Signals are at 15Vdc, 25mA max., and are only to be used for contact closure.



**Figure 3.4 Remote Control Of High Voltage On and High Voltage Off Interface**


The transistor should be located as close as possible to the power supply

All cables should be shielded with the shields being returned to the chassis ground of the High Voltage Power Supply.



**Figure 3.5 -- External Inhibit Interface Circuit**

Relay contacts are recommended for S1. The relay should be located as close as possible to the power supply. Signals are at 15Vdc, 25mA max and are only to be used for contact closure.




All cables should be shielded with the shields being returned to the chassis ground of the High Voltage Power Supply.

**Figure 3.6 -- External Interlock Interface**


12Vdc lamps or relay coils may replace opto-couplers.  
 Opto-couplers, lamps or relays should be located as close  
 as possible to the high voltage power supply.  
 All cables should be shielded with the shields being  
 returned to the chassis ground of the High Voltage Power Supply.

### TB1/J5



**Figure 3.7 -- Remote High Voltage On and  
Remote High Voltage Off Indicator**

### TB1/J5



**Figure 3.8 -- Remote Mode Indicators Interface**

# Chapter 4

## PRINCIPLES OF OPERATION

The SL Series of high voltage power supplies utilizes sophisticated power conversion technology. A variety of analog, digital and power conversion techniques are used throughout. The intention of the Principles of Operation is to introduce the basic function blocks that comprise the SL power supply. For details on a specific circuit, consult Spellman's Engineering Department.

See Table 4.1 for a list of the main assemblies found in a typical SL power supply.

- Due to the many variations within the SL Series, drawing numbers may differ from unit to unit.

The SL power supply is basically an AC to DC power converter. Within the power supply, conversions of AC to DC then to high frequency AC, then to high voltage DC take place. By reviewing further the sub-assemblies, a basic understanding of the process can be gained.

### 4.1 Chassis

The SL is a compact, high efficiency, high voltage power supply. The power supply can supply up to 1200 watts of DC power. (Output power capability may be higher or lower depending upon the model ordered). Output voltages of up to 130kV can be generated.

### WARNING

**The energy levels used and generated by the power supply can be lethal! Do not attempt to operate the power supply unless the user has a sufficient knowledge of the dangers and hazards of working with high voltage. Do not attempt to approach or touch any internal or external circuits or components that are connected or have been connected to the power supply. Be certain to discharge any stored energy that may be present before and after the power supply is used. Consult IEEE recommended practices for safety in high voltage testing #510-1983.**

### 4.2 Line Rectification And Filtering

Basic single phase rectification provides the DC voltage for the high frequency inverter. The line input voltage can vary from 90V up to 242V (85V to 265V with the universal input option) within the SL Series.

ASSEMBLY TITLE	ASSEMBLY DRAWING NO.	SCHEMATIC DRAWING NO.		
	J5	TB1	J5	TB1
SL Chassis (10W-300W)	403919-016	403917-001	440643-003	440530-001
SL Chassis (600W-1200W)	403920-001	403918-001	440643-004	440617-001
Control / Power PWB (to 300W)	404065-005	403911-001	440570-002	440528-001
Control / Power PWB (600W-1200W)	404581-001	403935-TAB	440687-002	440538-001
High Voltage Assy (to 300W)		403930-TAB		440533-001
High Voltage Assy (600W-1200W)		403931-TAB		440534-001
Front Panel PWB		403895-001		440525-001

**Table 4.1-List of Main Assemblies**

In general, the following variations can be ordered:

- Universal Input 85-265Vac, 50 to 60Hz, single phase.
- 100Vac  $\pm$  10%, 50 to 60Hz, single phase.
- 115Vac  $\pm$  10%, 50 to 60Hz, single phase.
- 200Vac  $\pm$  10%, 50 to 60Hz, single phase.
- 220Vac  $\pm$  10%, 50 to 60Hz, single phase.

Other input voltages can be accommodated. If the user is unsure of which input voltage option is supplied, check the serial tag on the rear of the power supply or consult Spellman's Sales Department.

Circuit protection is provided by a front panel circuit breaker (SYSTEM BLOCK DIAGRAM CHASSIS SL SCHEMATIC). The circuit breaker is a fast acting magnetic trip type circuit breaker. The line input is connected directly to the line side of the circuit breaker whereas the load side is connected to the CONTROL/POWER PWB. The load side of the breaker is also connected to a step-down type line transformer. This transformer provides voltage for housekeeping and control circuit power.

### **WARNING**

**LINE VOLTAGE IS PRESENT WHENEVER THE POWER SUPPLY IS CONNECTED TO EXTERNAL LINE VOLTAGES. BE SURE TO DISCONNECT THE LINE CORD BEFORE OPENING THE UNIT.**

**ALLOW 5 MINUTES FOR INTERNAL CAPACITANCE TO DISCHARGE BEFORE REMOVING ANY COVER.**

When the circuit breaker is ON, voltage is applied to an isolated diode rectifier bridge which contains the rectifier diodes used for line voltage rectification. The output of this bridge rectifier is connected to a capacitor filter.

Capacitors are initially charged through NTC type or resistive inrush limiters.

For 150W and higher configurations, approximately 3 seconds after the circuit breaker is turned on, a relay is energized to short the NTC or resistor limiters. This DC voltage is supplied to the high frequency inverter.

The DC rails are connected to the high frequency rail capacitors. These capacitors are high frequency, low loss type which provides the energy storage for the high frequency inverter.

For SL units with Universal Input, an active power factor control circuit is used. This circuit operates in boost topology mode which is inserted in between the line bridge rectifier and the filter capacitors. The boost converter accepts a rectified line range of 85V to 265Vrms and provides 400Vdc rail to the high voltage power converter. A DC-DC flyback converter is also employed to provide  $\pm$ 15V auxiliary power to the booth converter and the high voltage power converter control sections.

### **4.3 Inverter**

The inverter is a series resonant, series/parallel loaded topology. A proprietary control scheme is used for regulating the power generated from the inverter. The switching devices are Mosfets up to 300W, and IGBT's for power levels above 300W. These devices provide high frequency switching to control the resonant current flow. The typical resonant operating period is approximately 10  $\mu$ Seconds. The gate control for the switching devices is provided by the application circuitry located on the CONTROL/POWER PWB. The CONTROL/POWER PWB also provides circuitry for sensing shoot thru and overcurrent conditions in the inverter.

### **4.4 High Voltage Transformer**

The output of the High Frequency Resonant Inverter is connected to the primary of the High Voltage Transformer. The High Voltage Transformer is a set up type. Typical secondary voltages are in the range of 1kV to 4.5kV depending upon the output voltage ratings.

## 4.5 High Voltage Assembly

The High Voltage Assembly will vary depending upon the model ordered. The circuitry typically consists of a full wave, full bridge, or full wave doubler for voltage outputs in the range of 1kV to 8kV. The higher voltage ranges utilize various parallel, series arrangements of a full wave voltage doubler.

Output filtering is typically provided by an R-C type filter. Voltage feedback for regulation and monitoring is provided by a high bandwidth resistive/capacitive divider. Current feedback for regulation and monitoring is provided by a sense resistor connected at the low voltage end of the High Voltage Rectifier/Multiplier Circuit.

## 4.6 Control/Power PWB

The majority of control circuits for power supply controls are located on the CONTROL/POWER PWB. +15VDC, -15VDC, and +10VDC is generated on the CONTROL/POWER PWB. High Voltage On/Off control is accomplished by K3, and its associated circuitry. Interlock control is provided by K4.

Voltage feedback from the high voltage divider is sent to the control board via a mass terminated ribbon cable. Gain adjustment is provided on the HV PWB. The KV feedback signal is sent to the front panel DVM and to the REAR PANEL TERMINAL BLOCK for remote monitoring. K2 provides switching between feedback and program signal for the front panel DVM's. This allows the user to preset the desired output before energizing high voltage.

Program voltages are typically ramped up to set level by a slow start circuit.

An arc sense circuit provides sensing, quench and indicator of arc conditions. Consult the operation manual for a detailed description of the arc sense control.

Current feedback from the high voltage rectifier is sent to sense resistors located on the High Voltage Assembly. Calibrated feedback is then sent to the applicable circuitry on the Control/Power Board.

U12 and U13 circuits provide visual indication of the control mode which is in operation. These signals are sent to the FRONT PANEL ASSEMBLY for front panel status indication.

The resonant control circuitry consists of a voltage to frequency and a voltage to pulse width converter. U17 generates all frequency and pulse width control signals. U16 provides specific control functions for the resonant control.

Power supply inhibit circuits are provided by U22 and K3. System Fault control and Indication is provided by U19, U20 and U21, and associated circuitry. Diagnostic signals are latched and then sent to the FRONT PANEL ASSEMBLY for status indication.

## 4.7 Front Panel Assembly

Front Panel controls, meters and status indications are connected to the FRONT PANEL PWB. The FRONT PANEL PWB interfaces directly to the CONTROL/POWER PWB.

## 4.8 Options

Due to the many variations of models and options provided in the SL Series, details of actual circuits used may differ slightly from the above descriptions. Consult Spellman's Engineering Department for questions regarding the principles of operation for the SL Series.

# Chapter 5

## OPTIONS

The options available for this power supply are described in this section. Interface diagrams are shown where required. Options are specified by including the option code in the model number as described in Section 1.5.

### 5.1 Adjustable Overload Trip --AOL

The overload trip protection feature rapidly shuts down the high voltage output when the current exceeds the limit set by the current control dial on the front panel. A fast acting circuit inhibits the generation of high voltage and reverts the unit to POWER DOWN mode, illuminating the OVER CURRENT indicator. When adjustable overload trip is provided, it replaces the standard current regulation feature.

### 5.2 220Vac Single Phase Input--220

SL Series power supplies with the 220Vac input option will operate from an input voltage of 220Vac RMS  $\pm 10\%$ , 50 to 60Hz, single phase.

### 5.3 Universal Input--UFPI

SL Series power supplies with the 85V-265Vac input option will operate from a single phase, 47 to 63Hz with a line voltage range of 85V-265Vac, and a nominal power factor of 0.99.

### 5.4 No Slow Start--NSS

The no slow start option causes the output voltage of the power supply to rise (within 50 msec) to the rated voltage upon depressing the HIGH VOLTAGE ON switch.

second component is the leakage current caused by the coupling of the HVDC circuits to the chassis. The

### 5.5 Non-Standard Slow Start--SS(x)

The non-standard slow start option allows the gradual rise time of the output voltage to be different from the standard of six seconds. To order the option place the time desired in seconds after the suffix letter, i.e. SS(10) denotes a 10 second rise time.

### 5.6 Extra Length Output Cable--LL(ft)

Standard output cable is 10 feet of shielded high voltage cable. Other lengths may be specified in multiples of 10 feet.

### 5.7 Floating Ground--FG

The floating ground option allows isolation of the power supply common from the chassis ground. TB2 located on the rear panel provides connection to the power supply common circuit and to the chassis ground. This signal can be used for a variety of applications. A typical application for FG is for connection of an external meter or circuit into the FG signal point. This circuit can monitor actual current flow at a low voltage level. See Figure 5.1 for typical connection to the floating ground terminal.

**NOTE:** On standard units, TB2-1 and TB2-2 are connected to the chassis grounded internally. Maximum floating ground voltage is 15V. Typically, the total leakage current of the floating terminal to the chassis terminal is less than 1 $\mu$ A. It is important to realize there are two separate components to this leakage current. The first component is leakage current caused by the coupling of the 60Hz line magnetics to the power supply circuitry. This component can be measured when the power supply is ON and in the HIGH VOLTAGE OFF mode. The

component can be measured by first recording the leakage current in the HV OFF mode, and then recording the

leakage at the desired HV setting. The difference between the two values is the HVDC leakage current.

## 5.8 Floating Ground Low Leakage--FGLL

The Low Leakage floating ground option also provides isolation of the power supply common from the chassis ground with a maximum leakage current of 10nA. The typical connections are the same as for the regular Floating Ground Option described in Section 5.6. As stated above in the FG Option description, the FGLL leakage current is also comprised of two components. The 60Hz component is the same as the FG option (<1 $\mu$ A). However, in the FGLL option the HVDC leakage current is less than 10 nanoAmps.

### IMPORTANT

**The power supply common must be connected to the chassis ground through a low impedance circuit. The power supply common is clamped to the chassis ground using a power zener diode.**

**This diode is not intended to clamp under continuous operation. On higher current units the power dissipation within the zener diode can be excessive if allowed to clamp.**

## 5.9 Adjustable Power Trip/Constant Power Control

### (TB1 only)--APT/CPC

The power control options allow monitoring and control of the power supply output power. The APT option allows the user to remotely adjust the power limit for the power supply. If the power limit is exceeded, the unit will shut down with an OVERPOWER fault. The CPC option allows power regulation via an internal preset potentiometer, or a remote program source. When the unit is in power regulation, the POWER CONTROL status indicator will be illuminated. See Figure 5.2 for remote interface.

## 5.10 Arc Trip Option--AT

When this option is ordered, the Arc Count circuit is set so the unit trips to Standby after 1 count. One of the applications for this option is for sensing a material breakdown under an applied high voltage.

## 5.11 Reversible Polarity Option--PN

### 5.11.1 Models from 1 kV to 8kV

For units from 1 kV to 8kV, the polarity may be reversed in the field by following the procedures shown in Figure 5.3.

### 5.11.2 Models From 10Kv To 130Kv

When this option is ordered, a second multiplier is provided to permit the user to replace the existing multiplier with another of reverse polarity. See Figure 5.4 for a step by step procedure.

## 5.12 Instant On--IO

When the Instant On Option is ordered, the High Voltage is enabled as soon as line voltage is applied when the circuit breaker is in the ON position. (See Figure 5.7).

To enable Instant On, keep the jumper between TB1-14 and TB1-15 attached. Connect an additional jumper from TB1-15 to TB1-16 as shown in Figure 5.7.

### CAUTION

**The Power Supply will generate programmed High Voltage whenever the circuit breaker is in the ON position, and line voltage is applied.**

## **5.13 Bipolar Master/Slave Option--MS**

The Bipolar Master/Slave option allows two supplies of the same voltage rating but opposite polarities to function as a single tracking bipolar power supply. The positive supply is configured as the Master, the negative supply is configured as the Slave. This is accomplished by connecting the Voltage Test Point of the positive (Master) unit to the Voltage programming of the negative (Slave) unit. See Figure 5-8. The Master's voltage programming signal will provide control of both power supplies from zero to rated output voltage. The negative polarity will track the positive polarity within  $\pm 1\%$  from 10% to full rated output. Performance specifications are governed by individual unit characteristics. The two units must be connected independently to their respective loads and ground.

## **5.14 External Fault Relay Option EFR**

The external fault relay option provides a set of customer accessible relay contacts that are controlled by the fault status circuitry of the applicable SL Series power supply. A standard SL power supply will revert to the "power down" mode with a visual front panel indication if any of the following fault conditions occur:

- **Oversupply:** Greater than 110% of maximum output voltage was produced by the power supply.
- **Overcurrent:** Greater than 104% of maximum output current was produced by the power supply or the AOL circuitry was activated.
- **Overtemperature:** Excessive temperature has been sensed within the chassis.
- **Regulation Error:** Lack of required output power to maintain regulation

- **Arc (Shutdown):** Arc sensing circuit has shut down the supply due to excessive arcing.
- **Overpower:** The power supply has exceeded the internally set power limit level, if such circuitry is installed.

With the installation of the EFR option for TB1, if any of these faults occur, a relay will be activated to provide a remote indication that the power supply has reverted to the "power down" mode. The common, normally open and normally closed set of contacts are provided. Relay contacts are rated at 1A at 30Vdc or 0.5A at 48Vac.

Connections on the rear panel Terminal Block (TB1) can be made as follows:

TB1-23	(J5-12)	Relay Common
TB1-24	(J5-NA)	Normally Closed
TB1-25	(J5-13)	Normally Open


Resetting the front panel and EFR relay is accomplished by depressing the green front panel HV OFF push-button switch which reverts the power supply back to the "standby" mode. Removal and reapplication of the AC line input voltage will also reset any fault.

The circuitry and components required for the EFR option are installed at the factory when this option is ordered.


## **5.15 Custom Designed Models-X#**

Units built to customer specification are assigned an X number by the factory. If this unit is an X model, a specification control sheet is added at the end of the test of this instruction manual.


Spellman welcomes the opportunity to customize units to fit your requirements or to develop new products for your applications. Contact the Spellman Sales Department with your needs.




**Figure 5.1 -- Floating Ground Interface Circuit**




**Figure 5.2 -- Adjustable Power Remote Interface TB1 Only**



**Figure 5.3 -- Polarity Reversal Procedure  
10W to 300W, 1kV to 8kV Chassis**




**Figure 5.4 -- Polarity Reversal Procedure  
10W to 300W, 10kV to 120kV Chassis**



TURN UNIT OFF, UNPLUG LINE CORD FROM AC OUTLET AND WAIT FOR 5 MINUTES BEFORE PROCEEDING TO CHANGE THE HIGH VOLTAGE MULTIPLIER.


- ① REMOVE COVER BY UNSCREWING AND REMOVING 12 SCREWS THAT MOUNT COVER TO CHASSIS AND FRONT PANEL.
- ② REMOVE 4 SETS OF HARDWARE THAT HOLD THE LEXAN COVER TO THE HIGH VOLTAGE BOARD, AND REMOVE COVER.
- ③ SWAP BLACK AND WHITE WIRES BETWEEN J4 AND J5 AS FOLLOWS:  
FOR POSITIVE POLARITY:  
BLACK WIRE ON J4 AND WHITE WIRE ON J5.  
FOR NEGATIVE POLARITY:  
WHITE WIRE ON J4 AND BLACK WIRE ON J5.
- ④ REINSTALL LEXAN COVER AND RELATED HARDWARE.  
REINSTALL POWER SUPPLY'S COVER AND ALL HARDWARE BEFORE TURNING UNIT ON.

**Figure 5.5 -- Polarity Reversal Procedures**  
**600W to 1200W, 1kV to 8kV Chassis**




- ① TURN UNIT OFF, UNPLUG LINE CORD FROM AC OUTLET AND WAIT FOR 5 MINUTES BEFORE PROCEEDING TO CHANGE THE HIGH VOLTAGE MULTIPLIER.
- ② REMOVE COVER BY UNSCREWING AND REMOVING 12 SCREWS THAT MOUNT COVER TO CHASSIS AND FRONT PANEL.
- ③ UNPLUG HIGH VOLTAGE LEADS FROM ASSEMBLY.
- ④ UNPLUG CABLE FROM JB1 AND REMOVE CABLE SHIELD FROM FASTON TAB ON BOARD.
- ⑤ UNPLUG CONNECTOR FROM JB2.
- ⑥ REMOVE 2 SCREWS THAT HOLD THE POLYETHYLENE ENCLOSURE AND THE BOARD TO THE CHASSIS
- ⑦ CAREFULLY TILT UP AND SLIDE OUT MULTIPLIER.
- ⑧ INSTALL NEW MULTIPLIER BY FOLLOWING STEPS 6 THRU 2 IN REVERSE.
- ⑨ INSTALL COVER AND ALL HARDWARE BACK BEFORE TURNING UNIT ON.

**Figure 5.6 -- Polarity Reversal Procedure**  
**600W to 1200W, 10kV to 120kV Chassis**



**Figure 5.7 -- Instant ON**



INSTALLATION NOTE

Keep Interconnecting Wires as Short as possible.  
Use of Twisted Wire Pair or Shielded/Coaxial wire is recommended.

**Figure 5.8 -- Bipolar/ Slave Option**

# Chapter 6

## MAINTENANCE

This section describes periodic servicing and performance testing procedures.

### WARNING

**THIS POWER SUPPLY GENERATES VOLTAGES THAT ARE DANGEROUS AND MAY BE FATAL . OBSERVE EXTREME CAUTION WHEN WORKING WITH HIGH VOLTAGE.**

### 6.1 Periodic Servicing

Approximately once a year (more often in high dust environments), disconnect the power to the unit and remove the top cover. Use compressed air to blow dust out of the inside of the unit. Avoid touching or handling the high voltage assembly. Be sure that the fan (600W-1200W units only) is not obstructed and spins freely. The fan has sealed bearings and does not need lubrication. Be sure to replace the top cover before operating for proper cooling.

### 6.2 Performance Test

#### WARNING

**HIGH VOLTAGE IS DANGEROUS.**

**ONLY QUALIFIED PERSONNEL SHOULD PERFORM THESE TESTS.**

High voltage test procedures are described in Bulletin STP-783, Standard Test Procedures for High Voltage Power Supplies. Copies can be obtained from the Spellman Customer Service Department. Test equipment, including an oscilloscope, a high impedance voltmeter, and a high voltage divider such as the Spellman HVD-100 or HVD-200, is needed for performance tests. All test components must be rated for operating voltage.

### 6.3 High Voltage Dividers

High voltage dividers for precise measurements of output voltage with an accuracy up to 0.1% are available. An HVD-100 is used for voltages up to 100KV. An HVD-200 measures up to 200KV. The Spellman divider is designed for use with differential voltmeters or high impedance digital voltmeters. The high input impedance is ideal for measuring high voltage low current sources, which would be overloaded by traditional lower impedance dividers.

# Chapter 7

## REPLACEMENT PARTS

### 7.1 Replacement Parts

Contact the Spellman Customer Service Department for parts lists for specific models.

Parts and subassemblies for Spellman's high voltage power supplies are available. It is recommended that only qualified personnel perform the repairs. High voltage is dangerous; even minor mistakes in repairs can have serious consequences.

When requesting parts please give the model number and serial number of the power supply.

### 7.2 Correspondence And Ordering Spare Parts

Each power supply has an identification label on the rear of the chassis that bears its model and serial number.

When requesting engineering or applications information, please state the model and serial number of the power supply. If specific components or circuit sections are involved in the inquiry, it is helpful to indicate the component symbol number(s) shown on the applicable schematic diagram.

When ordering spare parts, please specify the part number, the component function and symbol from the schematic, and the model and serial number of the unit.

# Chapter 8

## FACTORY SERVICE

### 8.1 Warranty Repairs

During the Warranty period, Spellman will repair all units free of charge. The Warranty is void if the unit is worked on by other than Spellman personnel. See the Warranty in the rear of this manual for more information. Follow the return procedures described in Section 8.2. The customer shall pay for shipping to and from Spellman.

### 8.2 Factory Service Procedures

Spellman has a well-equipped factory repair department. If a unit is returned to the factory for calibration or repair, a detailed description of the specific problem should be attached.

For all units returned for repair, please obtain an authorization to ship from the Customer Service Department, either by phone or mail prior to shipping. When you call, please state the model and serial numbers which are on the plate on the rear of the power supply, and the purchase order number for the repair. A Return Material Authorization Code Number (RMA Number) is needed for all returns. This RMA Number should be marked clearly on the outside of the shipping container. Packages received without an RMA Number will be returned to the customer. The Customer shall pay for shipping to and from Spellman.

A preliminary estimate for repairs will be given by phone by Customer Service. A purchase order for this amount is requested upon issuance of the RMA Number. A more detailed estimate will be made when the power supply is received at the Spellman Repair Center. In the event that repair work is extensive, Spellman will call to seek additional authorization from your company before completing the repairs.

### 8.3 Ordering Options and Modifications

Many of the options listed in Chapter 5 can be retrofitted into Spellman's power supplies by our factory. For prices and arrangements, contact the Spellman Sales Department.

### 8.4 Shipping Instructions

All power supplies returned to Spellman must be sent shipping prepaid. Pack the units carefully and securely in a suitable container, preferably in the original container, if available. The power supply should be surrounded by at least four inches of shock absorbing material. Please return all associated materials, i.e. high voltage output cables, interconnection cables, etc., so that we can examine and test the entire system.

All correspondence and phone calls should be directed to:

**Spellman High Voltage Electronics Corp.**  
475 Wireless Boulevard  
Hauppauge, New York 11788  
TEL: (631) 630-3000 FAX: (631) 435-1620  
E-Mail: sales@Spellmanhv.com

# **WARRANTY**

**Spellman** High Voltage Electronics (“**Spellman**”) warrants that all power supplies it manufactures will be free from defects in materials and factory workmanship, and agrees to repair or replace, without charge, any power supply that under normal use, operating conditions and maintenance reveals during the warranty period a defect in materials or factory workmanship. The warranty period is twelve (12) months from the date of shipment of the power supply. With respect to standard SL power supplies (not customized) the warranty period is thirty-six (36) months from the date of shipment of the power supply.

This warranty does not apply to any power supply that has been:

- altered, repaired or worked on by persons unauthorized by **Spellman**;
- subjected to misuse, negligent handling, or accident not caused by the power supply;
- installed, connected, adjusted, or used other than in accordance with the instructions furnished by **Spellman**.

THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THOSE OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

The buyer's sole remedy for a claimed breach of this warranty, and **Spellman's** sole liability is limited, at **Spellman's** discretion, to a refund of the purchase price or the repair or replacement of the power supply at **Spellman's** cost. The buyer will be responsible for shipping charges to and from **Spellman's** plant. The buyer will not be entitled to make claim for, or recover, any anticipatory profits, or incidental, special or consequential damages resulting from, or in any way relating to, an alleged breach of this warranty.

No modification, amendment, supplement, addition, or other variation of this warranty will be binding unless it is set forth in a written instrument signed by an authorized officer of **Spellman**.

## **Factory Service Procedures**

For an authorization to ship, contact Spellman's Customer Service Department. Please state the model and serial numbers which are on the plate on the rear panel of the power supply and the reason for return. A Return Material Authorization Code Number (RMA number) is needed from **Spellman** for all returns. The RMA number should be marked clearly on the outside of the shipping container. Packages received without an RMA Number may delay return of the product. The buyer shall pay shipping costs to and from **Spellman**. For out-of-warranty repairs, the Standard Cost will be given by Customer Service. A purchase order for this amount is requested upon issuance of the RMA Number. A more detailed estimate may be made when the power supply is received at **Spellman**. If initial investigation indicates that the cost of completing the repair will exceed the Standard Cost for that unit, **Spellman** will contact the customer to authorize the repair.

## **Factory Service Warranty**

Spellman will warrant for three (3) months or balance of product warranty, whichever is longer, the repaired assembly/part/unit. If the same problem shall occur within this warranty period Spellman shall undertake all the work to rectify the problem with no charge and/or cost to the buyer.

## **Spellman Worldwide Service Centers**

**Spellman High Voltage Electronics Corporation** • 475 Wireless Boulevard Hauppauge • New York 11788 USA • Tel: + 1 631-630-3000 • Fax: + 1 631-435-1620 • Email: [service@spellmanhv.com](mailto:service@spellmanhv.com)

**Spellman High Voltage Electronics Limited** • Broomers Park • Broomers Hill Lane • Pulborough West Sussex • RH20 2RY UK • Tel: + 44 (0) 1798 877000 • Fax: + 44 (0) 1798 872479 • Email: [service@spellmanhv.co.uk](mailto:service@spellmanhv.co.uk)

**Spellman Japan** • 3-15 Kanayama-cho • Kawaguchi-shi • Saitama-ken • Japan 332-0014 • Tel : + 81 (0) 48-288-3222 • Fax : + 81 (0) 48-228-3224 • Email: [service@spellmanhv.co.jp](mailto:service@spellmanhv.co.jp)