

C64uRemote for M5Stack CoreS3

User Manual

Version 1.0

Contents

Welcome	2
What you need	2
First-time setup	2
Touch operation	3
The home screen	3
The status lamp	3
The battery indicator	4
Changing the CPU speed	4
Swapping the joystick ports	4
Launching games by card (RFID)	5
Just present the card (automatic)	5
Through the RFID tile	5
Which files work	5
Command cards	6
Creating a command card	6
PowerOff with prompt	6
What is stored on the card	6
Launching games directly from SD (no card)	7
Writing and managing NFC cards	7
NFC-Write: assign a game to a card	7
NFC-Info: read out a card	7
NFC-Dump and NFC-Restore: copying cards	7
Setting up Wi-Fi	8
Route 1: scan, then hand over the password on a card	8
Presenting a card is enough	8
Route 2: a file on the SD card	8
Route 3: the setup portal	9
Settings overview	9
NFC and Wi-Fi	9
Powering off	9
Display and effects	9
C64 options	10
Miscellaneous	10
Frequently asked questions	10

License	10
How this was made	11

Welcome

C64uRemote turns an **M5Stack CoreS3** into a convenient remote control for the **Commodore 64 Ultimate (c64u)** and the **Ultimate64 Elite-II**. Over Wi-Fi you control the machine remotely: reset, reboot, power off, open the Ultimate menu and change the CPU speed.

With the optional **RFID2 reader** and a **microSD card** it becomes a tap-to-launch console: you hold an NFC card to the device and the matching game starts on the C64. The cards are compatible with the TeensyROM and Zaparoo format - the same card works on both systems.

This project builds on the original idea by Karl Prosser (@klumsy) and was extended for the M5Stack CoreS3 by Martin Oswald (@mad, 1MHz.de).

What you need

Required:

- An M5Stack CoreS3, CoreS3 SE or CoreS3 Lite
- A Commodore 64 Ultimate or Ultimate64 Elite-II on the same Wi-Fi

Optional, for the NFC features:

- M5Stack Unit RFID2 (WS1850S), connected to **Port A** (the CoreS3 has no built-in NFC reader)
- An M5Stack Unit RGB (three SK6812) on **Port B** as a status lamp - nice to have, not needed
- A microSD card (formatted FAT32, up to 16 GB) in the CoreS3
- NFC cards: NTAG215 recommended, NTAG213/216 and MIFARE Classic also work

Without the reader or SD card, all other functions keep working normally.

First-time setup

For the CoreS3 to find your C64, the Wi-Fi credentials and the C64's address must be stored once. You can do that **right on the device** under *Setup* → *WiFi* - the source code no longer has to be touched. The credentials go into internal memory and survive every restart. The *Setting up Wi-Fi* chapter walks through the details.

If you would rather supply the credentials while programming the device, put them into `build_env.h` as before (see the technical documentation). They then serve as the initial values for the very first start.

The connection status is always shown in the top left of the display:

Display	Meaning
C64U OK (green dot)	Everything connected, ready
NO C64U (blue)	Wi-Fi present, but the C64 does not respond
AUTH? (yellow)	C64 reachable, but the password is wrong
NO WIFI (red)	No Wi-Fi connection

To the right you see the IP address, the current CPU speed and whether the RFID reader and SD card were detected.

Touch operation

The CoreS3 no longer has buttons A, B and C – only **POWER** and **RESET** on the left-hand side. It is operated entirely through the **touchscreen**.

Gesture	Effect
Tap	select and run a tile or list row
Swipe	the list follows your finger, row by row
Drag the scrollbar on the right	quickly through long lists
Back (bottom left)	one level back
▲ / ▼ (bottom right)	one row up or down
Long tap	in the SD browser: one folder up

The bar along the bottom edge is a control surface in its own right: the back field is always on the left, on list pages the two paging fields appear on the right, and between them a short hint says what a tap does here right now.

Paging through long lists. When a list does not fit on the screen, a **scrollbar** appears on the right. It shows where you are and how long the list is – and it can be dragged directly with a finger. With many entries that takes you from one end to the other in a single movement.

Swiping in the middle of the list works the same way: it follows your finger. As soon as it moves, it is clear that you meant to page rather than select – so a swipe never triggers an entry by accident, not even a slow one. If a list fits on the screen entirely there is nothing to push; every tap stays a tap there.

POWER and **RESET** are hardware buttons of the CoreS3 and have nothing to do with the C64: a short press of POWER switches the CoreS3 on, holding it for 6 s switches it off. RESET restarts it.

The home screen

At the top the status bar, in the middle the animated logo, below it all commands as tiles:

RESET	REBOOT	MENU	POWER	CPU
JOY	RFID	SD	STATUS	SETUP

You simply tap a tile – one tap selects it and runs it straight away.

Tile	What happens
RESET	The C64 is reset (like the reset button)
REBOOT	The C64 restarts completely
MENU	Opens or closes the Ultimate menu on the C64
POWER	Powers off the C64 – tap twice for safety
CPU	View and change the CPU speed
JOY	Swap the joystick ports on the C64 (Normal ↔ Swapped)
RFID	Tap a card and start the game stored on it
SD	Pick a game directly from the SD card and start it
STATUS	Detailed connection info; a tap starts a connection test
Setup	Settings and NFC tools

Powering off (POWER): Turning off by accident would be annoying, so the prompt *POWER OFF? TAP AGAIN!* appears first. Only a second tap on the same tile within the time window actually powers off; a tap anywhere else cancels.

The status lamp

If an **M5Stack Unit RGB** (three SK6812) is attached to **Port B**, it shows the state even when you are not looking at the display:

Lamp	Meaning
all three red	no Wi-Fi connection
all three blue	Wi-Fi up, but the C64 does not answer
all three yellow	C64 reachable, the password is wrong
all three green	everything connected, ready
magenta , running light	the setup portal is running
cyan as a bar	a game is being loaded into the C64 right now
short green (all)	card read or written successfully
short red (all)	card empty, unreadable, or a write error

The colours are the same as the dot at the top left of the display.

While loading the three LEDs become a progress bar: the first shines fully once a third has been transferred, then the second, then the third. The section in progress pulses so you can see things are moving. If the file size happens to be unknown, a running light takes over instead.

Under *Setup* → *Status-LED* you switch it off, under *LED Bright* you set the brightness (10 to 255; 60 is the factory setting and comfortable in most rooms).

The CoreS3 **cannot** detect whether an LED is actually connected – a lamp like this sends nothing back. If none is plugged in, simply nothing happens. You only need to switch it off if you want Port B for something else.

The battery indicator

The CoreS3 has a built-in battery. How full it is can be seen in two places in the status bar.

The line below the status bar doubles as the level gauge: the filled part is slightly thicker and coloured, the rest stays the dimmed line.

At the right-hand end two displays take turns every 15 seconds – RFID and SD as before, and a battery symbol with the percentage inside.

The colour means the same in both places:

Colour	Level
green	from 50 %
yellow	from 20 %
red	from 10 %
red, blinking	below 10 %
turquoise	on the charger

While the CoreS3 is on external power a small **bolt** sits in front of the battery symbol. It appears as soon as the cable is plugged in – the charge controller reports the USB voltage, so it stays on with a full battery too.

The **status page** shows the level as a number as well.

Changing the CPU speed

Tap the **CPU** tile. The current speed is shown at the top, the list of options below – just tap the step you want. The CoreS3 reads the available steps directly from the C64, so you get exactly the values your device supports.

Swapping the joystick ports

Some games expect the joystick in port 1, others in port 2. Instead of moving the cable, the mapping can be swapped inside the C64.

Tap the **JOY** tile — every trigger toggles between *Normal* and *Swapped*, and *JOY Swapped* or *JOY Normal* appears briefly.

SETUP → *Joystick* shows the current state and steps through every value your C64 offers: besides *Normal* and *Swapped* there may be *WASD P1* and *WASD P2*, depending on the firmware — the keyboard then drives that port.

The Ultimate firmware has no dedicated remote command for this. The CoreS3 sets the *Joystick Swapper* item in the C64 configuration, exactly like the CPU speed. The state therefore survives until it is changed again, a reset included.

Launching games by card (RFID)

Requirements: RFID2 reader connected, a microSD with your games inserted, and the card written beforehand (see below).

Just present the card (automatic)

Normally you do not have to operate anything at all: the CoreS3 checks in the background whether a card is present. As soon as it finds one it switches to read mode on its own and launches the stored program.

That applies not only on the home screen but also while you are **browsing the SD card**, on the **STATUS** page and in the **CPU** menu. Afterwards the CoreS3 returns exactly to where you were.

It deliberately does **not** react while you are working with cards yourself: picking a file for *NFC-Write*, restoring a dump, in the setup and in the Wi-Fi configuration. Launching a program there would be the exact opposite of what you are doing.

After the launch the reading screen stays up for about 20 seconds, so you can present the next card right away. After that — or as soon as you tap the screen — it goes back.

How often it looks is set under *Setup* → *Auto-NFC*:

Setting	Meaning
Off	no background polling, cards only through the RFID tile
1.5s	very frugal
0.7s	factory default, a good compromise
0.3s	quickest to react

The probe is short enough that even at 0.3s it slows neither the animation nor the controls noticeably.

Through the RFID tile

If you want to read a card deliberately — or if *Auto-NFC* is switched off — the manual route still works:

1. Tap the **RFID** tile.
2. Place the NFC card on the reader.
3. The CoreS3 reads the stored path, fetches the file from the SD card and sends it to the C64.
A progress bar shows the upload.
4. After *GESTARTET: ...* (“started”) the game runs.

Remove the card, tap the next one – the screen stays in read mode, so you can play several cards one after another.

Which files work

Extension	What it is
.prg	Program (loaded and started)
.crt	Cartridge
.sid	SID music
.mod	Amiga MOD music
.d64 .d71 .d81 .g64 .g71	Disk images

For disk images the image is mounted as drive 8. What happens next is set under *Disk Action* in the setup: mount only, mount and reset, or mount and automatically start the first program.

Command cards

A card does not have to point at a game – it can also carry a **command**. Present it and the command runs immediately, with no menu and no SD card needed.

Card	Effect
Reset	Resets the C64
Reboot	Restarts the C64 completely
Ultimate Menu	Opens or closes the Ultimate menu
PowerOff direct	Powers off immediately
PowerOff with prompt	Asks first – present the same card a second time within the time window to confirm
CPU x MHz	Sets the CPU to the value stored on the card
Swap Joystick	Swaps the joystick ports (Normal ↔ Swapped)
Joystick Normal / Swapped / WASD P1 / WASD P2	Sets the port mapping to that fixed value

Creating a command card

1. Choose **NFC-Cmd** in the settings.
2. Pick the command from the list. After the fixed entries come the joystick mappings and then all CPU steps your C64 offers, so a “CPU 10 MHz” card is a single click. *JOY* or *CPU* on the right tells the two blocks apart.
3. Present the card; *KARTE OK* means written and verified.

PowerOff with prompt

The waiting time lives **on the card**, not in the device. When writing, the value comes from *NFC-Cmd PowOff* (3, 5, 8 or 15 seconds, 8 s by default). Presenting such a card shows *POWER OFF? NOCHMAL!* with a countdown. To power off:

- present the **same card** again, or
- **tap the screen**

If the countdown expires or a different card appears, nothing happens. A card with a time of **0** powers off immediately without asking.

What is stored on the card

The command is plain text in an NDEF record – you can inspect or write it with any NFC app on your phone:

```
CMD:RESET
CMD:REBOOT
CMD:MENU
CMD:POWEROFF=0      power off immediately
CMD:POWEROFF=8      ask first, 8 seconds to confirm
```

CMD:CPU=10 set the CPU to 10 MHz
CMD:JOY toggle the joystick ports
CMD:JOY=SWAPPED set the ports fixed; also NORMAL, WASD1, WASD2

Case does not matter. The M5Dial and M5Stack Core editions understand the same format, so one card works on both.

Launching games directly from SD (no card)

Open the **SD** tile. You see the files and folders on your SD card. This lets you start something without an NFC card – handy for trying things out.

In the SD browser the following also applies:

Gesture	Function
Tap	start a file or open a folder
Swipe	the list follows the finger; scrollbar on the right for long lists
Long tap	one folder up
Back (bottom left)	one folder up; at the top level back to the home screen
.. in the list	also moves one folder up

The title bar shows *long tap* = **..** as a reminder.

Writing and managing NFC cards

All card tools are found under **Setup** at the very top. Open the setup with the Setup tile; the first four entries are the NFC actions.

NFC-Write: assign a game to a card

1. Open the setup and tap **NFC-Write**.
2. Tap the game file you want on the SD card.
3. Place the NFC card on the reader.
4. The path is written and immediately read back for verification. *KARTE OK* means success.

The format is compatible with the TeensyROM/Zaparoo system. A card written this way works on both devices, as long as the folder structure on both SD cards is the same. You can also write cards with your phone (the *NFC Tools* app, text record).

NFC-Info: read out a card

Shows everything on the card: UID, card type, memory size, the stored path and whether the file actually exists on the SD card. A tap pages to **page 2**, which shows technical raw data, lock bits, access protection and the read counter.

Handy: this is how you find cards whose game you renamed or moved – the *Datei* (“file”) line then reports “NICHT auf SD” (“not on SD”).

NFC-Dump and NFC-Restore: copying cards

- **NFC-Dump** saves the complete card content as a text file in the folder /NFC-DUMPS/ on the SD card. Works with any card, including foreign MIFARE cards without text.
- **NFC-Restore** writes such a dump back onto a (blank) card.

This lets you clone cards. One note: a card’s serial number (UID) is fixed in the chip and cannot be copied – but the content is copied completely. For game cards that is enough, because what matters there is the stored path.

Setting up Wi-Fi

Everything for this sits under **Setup → WiFi**. Tap an entry directly; swipe to page. The CoreS3 remembers up to **four networks** and tries them one after another when connecting – handy if you move between home and a phone hotspot.

Entry	Effect
Scan networks	Search the area and pick a network from the list
Load from SD	Read <code>wifi.txt</code> from the microSD
Setup portal	Access point of its own with a web interface
Saved	Pick a stored network and connect
To NFC card	Write a stored network to an NFC card
Save to SD	Write all stored networks to the microSD as <code>wifi.txt</code>
Delete network	Remove a single entry
Delete all	Discard all credentials

Route 1: scan, then hand over the password on a card

Scan networks shows the networks found after a few seconds, along with their signal strength. A network that is already stored is marked *known* and connects straight away; an *open* network needs no password.

For everything else the CoreS3 asks for the password and waits for an NFC card. The card carries an ordinary text record in the same scheme that Wi-Fi QR codes use:

```
WIFI:S:MyWiFi;T:WPA;P:MyPassword;;
```

Write the card with a phone, for example with the **NFC Tools** app (*Write → Add a record → Text*). If the card holds only the password without the `WIFI:` prefix, it is assigned to the network you picked beforehand.

The password sits unencrypted on the card. Once you are set up, overwrite the card – the device keeps the password in internal memory anyway.

Presenting a card is enough

A complete `WIFI:` card also works **outside** the setup: present it on the home screen and the CoreS3 stores the network and connects to it right away. It waits up to eight seconds and then reports *WIFI ACTIVE* with the IP address, or *NETWORK NOT THERE* if the network is out of range. If that network is already connected, nothing happens (*ALREADY CONNECTED*) – so the card may simply stay on the reader.

That gives a second device its credentials in a matter of seconds.

Route 2: a file on the SD card

Put a text file `wifi.txt` in the root directory of the microSD:

```
ssid = MyWiFi  
pass = MyWiFiPassword
```

```
ssid = Hotspot  
pass = secret123
```

```
host      = 192.168.0.64  
hostpass =
```

Every new `ssid` line begins a new entry; lines starting with `#` are comments. The file is read at start-up (as long as no network is stored yet) and at any time through *Load from SD*.

The other way round, **Save to SD** writes all stored networks together with `host` and `hostpass` back out in exactly this format. An existing `wifi.txt` is renamed to `wifi.bak` first, so nothing is

lost. That makes setting up a second device a no-typing affair – bear in mind that the passwords sit on the card in plain text.

Route 3: the setup portal

Setup portal turns the CoreS3 into an access point of its own for five minutes. The display shows the network name, the password and the address you open in a browser. There you enter SSID and password – either from the list of networks found or by hand – and optionally the address and password of the C64.

After saving, the CoreS3 shuts the access point down and connects to the new network. The browser connection breaking off in the process is normal.

Settings overview

In **Setup**, after the NFC actions, you find all settings. They are stored permanently and reloaded after power-cycling.

NFC and Wi-Fi

Setting	Options
NFC-Random	Create a random-pick card for a directory
NFC-Cmd	Create a command card (see the <i>Command cards</i> chapter)
NFC-Cmd PowOff	Default prompt time for a PowerOff command card: 3, 5, 8, 15 s
WiFi	Wi-Fi setup submenu (see the <i>Setting up Wi-Fi</i> chapter)
Auto-NFC	Background polling interval: <i>Off</i> , 1.5s, 0.7s, 0.3s

Powering off

Setting	Options
PowerOff Zeit	How long the prompt of the POWER tile stays valid (0.5 to 3.0 s)

Display and effects

Setting	Options
Animations	Logo animations on/off
Effect	Which effect: Auto (cycle), Static, Water, RotoZoom, SineWave, Ripple, Raster
FX Detail	Half or Full – thanks to its PSRAM the CoreS3 runs Full smoothly too
Anim Speed	Animation speed: Slow / Normal / Fast
Effect Time	How long an effect runs: Short / Normal / Long
Static Time	How long the calm logo is shown in between
Brightness	Display brightness (32 to 255)
Status-LED	Switch the lamp on Port B on or off
LED Bright	Brightness of the lamp (10 to 255)

C64 options

Setting	Options
Disk Action	After mounting a disk image: mount only, mount + reset, or mount + start the first program
Disk Drive	Target drive: Auto (bus 8), or fixed A / B
Joystick	Port mapping in the C64: <i>Normal</i> , <i>Swapped</i> , and depending on firmware <i>WASD P1</i> / <i>WASD P2</i>

Miscellaneous

Setting	Options
Beep	Confirmation tone on/off
Factory Reset	Reset all settings to factory defaults

Frequently asked questions

Now and then *Not reached* or *Not verified* shows up and clears again. The HTTP server in the c64u occasionally refuses a connection (“connection refused”) although network and address are fine – this happens even with only a single device on the network. Since v1.2.1 the firmware retries a refused call by itself after a short pause, so you will usually not notice. If it stays that way, restarting the c64u helps.

The CoreS3 shows “NO WIFI”. Check that the Wi-Fi name and password are stored correctly and the router is in range. The CoreS3 retries the connection every few seconds.

“AUTH?” in the status bar. A network password is set on the C64 that is not stored on the CoreS3. Check the password in the C64 menu or enter it in `build_env.h`.

A card starts nothing / “TYP UNBEKANNT” (unknown type). The Ultimate can only start the file types listed above. Use **NFC-Info** to check which path and extension are on the card and whether the file is on the SD.

The SD card is not detected. Format as FAT32, 32 GB maximum, and if needed try a different card. The CoreS3 automatically tries two speeds.

The PowerOff command reports an error. That is normal – when powering off the C64 often no longer responds cleanly.

Can I use the same cards on the TeensyROM? Yes. The card format is identical. The only important thing is that the folders on both SD cards have the same names.

License

C64uRemote is released under the **MIT License**. The full text is in the file LICENSE in the project root.

It originates from **C64uRemote by Karl Prosser (@klumsy)**, <https://github.com/ReadyOS-C64/C64uRemote>, which he published under the MIT License. This version is a derivative work and is released under the same terms:

- Copyright (c) 2026 Karl Prosser – original project
- Copyright (c) 2026 Martin Oswald (@mad, <https://1MHz.de>) – port and extensions

The MIT License allows you to use, modify and redistribute the software, including commercially. The only condition: **the copyright notice and the license text must be kept** and included with every copy. There is no warranty and no liability.

The libraries used carry their own licenses: M5Unified and M5GFX (MIT, © M5Stack), ArduinoJson (MIT, © Benoit Blanchon) and MFRC522_I2C (https://github.com/kkloesener/MFRC522_I2C). PlatformIO fetches them at build time.

How this was made

The port, the extensions and these manuals were written with the help of Claude (Anthropic). Concept, idea, hardware decisions and every test on real devices: Martin Oswald (@mad).