CONFIDENTIAL

Table of Contents

1.Over	view	1
1.1	Overview of this Software	1
1.2	Configuration of this Software	1
1.3	Development Environments	4
1.3	3.1 Hardware Development Environment	4
1.3	3.2 Software Development Environment	4
2.Insta	llation Procedures	5
2.1	Building the shared library	5
2.2	Building the Kernel image and the Kernel module	6
2.3	Storing the shared library, the Kernel module and Kernel image	8
2.4	Device tree configuration	9
3.Modu	ıle Configuration	10
4.List o	of API	12
•	ole Sequence	
6.API S	Specification	15
6.1	Allocate Memory Space	15
6.2	Free Memory Space	18
6.3	Map the Address for H/W IP to the User Space (Debug API)	19
6.4	Unmap the Mapping Space (Debug API)	21
6.5	Start the export of dmabuf fd	22
6.6	End the export of dmabuf fd	24
6.7	Start the import of dmabuf fd	25
6.8	End the import of dmabuf fd	
7.Head	er Files	27
8.Defin	lition	28
8.1	Structure	28
8.1	,	
8.2	Macros	
8.2		
8.2	2.2 Parameter Definition	29
8.2	•	
9.Restr	rictions and Notices	
9.1	Restrictions	
9.2	Notices	
	endix	
10.1	Legacy API	
10.2	Relationship between mem_param and Lossy mem return value	32
10.3	IPMMU MMU support	33
10	.3.1 Enable IPMMU MMU support	33
10	.3.2 Map CMA areas to IPMMU virtual address space	36

CONFIDENTIAL

10.3.3	Sample memory map	38
--------	-------------------	----