Home

SPIKE Prime

Icon Blocks

Word Blocks

Block Descriptions

Motor Blocks Category

Movement Blocks

Light Blocks Category

Turn On 5x5 Light Matrix for Se...

Turn On 5x5 Light Matrix

Write on 5x5 Light Matrix

Turn off 5x5 Light Matrix

Set 5x5 Light Matrix Brightness

Set Pixel Brightness on 5x5 Lig...

Rotate Orientation of 5x5 Light...

Set Orientation of 5x5 Light Ma...

Turn On 3x3 Color Matrix for Se...

Turn On 3x3 Color Matrix

This block sets the speed of a moving Driving Base. The speed range is -100 to 100. Negative values change the direction of the movement. The default value is 50%.

Set Movement Motors



This block defines the Ports to which the 2 driving motors are connected.

Set 1 Motor Rotation to Distance Moved



This block calibrates the distance of a Driving Base so that the distance unit (i.e., centimeters/inches) specified in the Movement Blocks will be accurate.

Light Blocks Category

Light Blocks enable you to turn the lights of different elements (e.g., 5x5 Light Matrix of the Hub, Distance Sensor lights) on and off.

Turn On 5x5 Light Matrix for Seconds



This block creates a pattern and makes it light up on the 5x5 light matrix for a specified length of time. The Block will turn the pixels off when the time is up.

Turn On 5x5 Light Matrix

This block creates a pattern and makes it light up on the 5x5 light matrix. The pattern stays lit up until the light matrix is told to do something else or the program is stopped.