

표. ERROR TROUBLE CODE 및 원인 일람표

	ERROR 분류								
	SYSTEM ERR 1	FLOOR ERR 2	CAN ERR 3	DOOR ERR 4	INVERTER ERR 5	BRAKE ERR 6	SWITCH ERR 7	ETC ERR 8	ETC ERR 9
F1	# X29 SAFETY ERROR	* MT_TERMAL ERR(gl) * ccs_sw err(gl/gd)	* Com line off err	# X40,X41 ERROR (running state)	# X30B ERROR (5초후)	# BRAKE ON 고장 (연속 2회)	# ULS/DLS ERROR	DUPLEX COMM. ERROR	
F2	# ANTI-STALL ERROR	* floor "0 flno" auto state * FLOOR UNMATCH	* com Bus off error	* door JUMPER err	# e/l move error (stop state)	* BRAKE ON 고장 (rope brake error)	* up/dn limit err	RMS COMM. ERROR	
F3	# MCU <-> INV.DPRAM CABLE ERROR			* DCL/door close err(3회)	# INV.SET ERROR	#BRAKE OFF 고장 (BRAKING 후 2초)	* dz signal err	Run By Error	
F4	# FWD/REV OUT ERROR	* init fault(HIGH) (autostate)		* dol/ door open err(3회 3층)	# inv tq's, run signal error (at start)		* RELEVEL ERROR	Water Over Error	
F5	# MC1 contactor err	* PULSE ERROR		* Close Fault1 Err X40,X41 close err (DCL OK 후 2초)	# inv tq's, speed agree signal err (after start)		* up run uls err dn run dls err	load set error	
F6	# auto->hand err. (in auto run state)	# init fault LCD/vane 이상	* can serial err	* Close Fault2 Err DCL close err (X40,X41 OK 후 2초)	# inv zero speed singal err (after start)		* up/dn run limit decel err	HALL DEVICE ERROR	
F7	# during running safety off err		* serial check sum	# 개문발차시 ROPE BRAKE 작동	# inv 30b off err (running state)		* floor confirm err	en_code mc2 err (at start)	
F8									
NOTE :									