THT Current Sense Transformers







UL/C-UL recognized components

3000Vrms gate to drive winding test

Useful operating frequency from 50kHz to 500 kHz

Most popular winding configurations

Electrical Specifications @ 25°C – Operating Temperature –40°C to +130°C								
Part ⁶ Number	Turns Ratio	Primary Inductance (1-10) (mH MIN)	DCR Pri (1-10) (Ω MAX)	DCR Sec1 (3-7) (m Ω ±15%)	DCR Sec2 (4-8) (m Ω ±15%)	Hipot (Pri-Sec) (Vrms)		
P0581NL	200:1:1	76	2.8	1.7	1.7	3000		
PO582NL	100:1:1	19	1.4	1.7	1.7	3000		
P0583NL	50:1:1	5	0.7	1.7	1.7	3000		

Additional Specifications								
		Referer	Calculation Data					
Part Number	RT	lpk (Amps)	Droop (%)	Max Flux Density	Kb	$\begin{array}{c} \text{Req} \\ (\text{m}\Omega) \end{array}$		
P0581NL	200	34	1.00	2000	17.12	.9		
P0582NL	100	35	1.98	2000	68.49	.8		
P0583NL	15	36	1.19	2000	273.97	.75		

Notes:


- These current sense transformers have two one turn primaries that can be used in parallel. The listed current ratings are for parallel connection.
- The reference values are for an application using the termination resistor (Rt) and operating with unipolar waveform at 100kHz, 40% duty cycle.
 The estimated temperature rise is 55°C.
- 3. The peak flux density should remain below 2100 Gauss to ensure that the core does not saturate. Use the following formula to calculate the peak flux density: Bpk = Kb * lpk * Rt * don/(Ff * freq. in kHz) where: Rt is the terminating resistor in the application and the Ff is 1 for unipolar waveform and 2 for bipolar waveform.
- 4. To calculate the droop: Droop Exponent (D) = Rt * don/(Lpri in mH * Freq. in kHz %Droop = $(1-e^{-D})$ * 100

- 5. The temperature rise of the component is calculated based on the total core loss and copper loss:
 - A. To calculate total copper loss (W): P(cu) = lpk²* Req * Ff * don where Ff is 1 for unipolar waveform and 2 for bipolar waveform
 - B. To calculate total core loss (W): P (core) = $0.000073 * (Freq. in kHz)^{1.67} * (Bop in kG)^{2.552}$ where: Bop in kG = Kb * lpk * Rt * don/(2000 * Freq. in kHz)
 - C. To calculate temperature rise: Temperature Rise (C) = $60.18 * (Core Loss (W) + Copper Loss (W))^{.833}$

USA 858 674 8100 Germany 49 7032 7806 0 Singapore 65 6287 8998 Shanghai 86 21 62787060 China 86 755 33966678 Taiwan 886 3 4356768

pulseelectronics.com P516.C (06/15)

THT Current Sense Transformers



For More Information

Pulse Europe

Einsteinstrasse 1

D-71083 Herren-

berg

Germany

Pulse Worldwide
Headquarters
12220 World Trade Drive
San Diego, CA
92128
U.S.A.

Tel: 858 674 8100 Tel: 49 7032 7806

Pulse China Headquarters B402, Shenzhen Academy of

Aerospace Technology Bldg.
10th Kejinan Road
High-Tech Zone
Nanshan District
Shenzen, PR China
518057

Pulse North China

Room 2704/2705 Super Ocean Finance Ctr. 2067 Yan An Road West Shanghai 200336 China

Pulse South Asia

135 Joo Seng Road #03-02 PM Industrial Bldg. Singapore 368363

Tel: 65 6287 8998 Fax: 65 6287 8998

Pulse North Asia

3F, No. 198 Zhongyuan Road Zhongli City Taoyuan County 320 Taiwan R. O. C. Tel: 886 3 4356768 Fax: 886 3 4356823 (Pulse)

Performance warranty of products offered on this data sheet is limited to the parameters specified. Data is subject to change without notice. Other brand and product names mentioned herein may be trademarks or registered trademarks of their respective owners. © Copyright, 2015. Pulse Electronics, Inc. All rights reserved.



Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Pulse:

P0581 P0583 P0582 P0582NL P0581NL P0583NL